

Instructions

95-8533

Eagle Quantum[™] Premier[™]
Fire and Gas Detection/Releasing System




Table of Contents

Section 1 - Safety	Section 3 - Installation
ALERT MESSAGES1-1	SAFETY SYSTEM DESIGN REQUIREMENTS3-1
	Identifying the Area of Protection3-1
Section 2 - Introduction	Identifying Wiring, Network (LON), and System Power Requirements3-1
SYSTEM DESCRIPTION2-1	General Wiring Requirements3-1
Communications Loop2-1	Power Wiring3-1
LON Communication Heartbeat2-2	Determining Power Requirements3-3
Theory of Operation2-2	EQ211xPS, EQ213xPS and EQ217xPS Power
Controller Logs2-4	Supplies3-5
Controller User Logic2-4	Backup Battery3-5
Communication Network Fault Operation2-4	Battery Charger3-5
Multiple Wiring Faults2-5	Shield Grounding3-6
MAJOR COMPONENT DESCRIPTIONS2-5	Junction Box Grounding3-6
	Response Time vs. System Size3-6
System Controller2-5	Moisture Damage Protection3-7
Local Operating Network (LON)2-6	Electrostatic Discharge3-7
Network Extenders2-6	GROUND FAULT MONITOR (GFM) INSTALLATION3-7
EQ21xxPS Series Power Supplies and EQ2100PSM Power Supply Monitor2-7	Mounting3-7
EQ211xPS, EQ213xPS and EQ217xPS Power Supplies2-7	Wiring3-7
EQ2220GFM Ground Fault Monitor2-7	NETWORK AND NETWORK EXTENDER INSTALLATION3-8
Field Devices2-7	
Flame Detectors2-7	Mounting3-8
EQ3730EDIO Enhanced Discrete I/O Module2-8	Wiring3-8
EQ3700 8 Channel DCIO Module2-8	INITIATING DEVICE CIRCUIT (IDC) INSTALLATION3-10
EQ3720 8 Channel Relay Module2-9	EQ22xxIDC Series Initiating Device Circuit3-10
EQ3710AIM Analog Input Module2-9	Mounting3-10
EQ3740IPM Intelligent Protection Module2-10	Wiring3-10
EQ25xxARM Agent Release Module2-10	EQ22xxIDCGF Series Initiating Device Circuit Ground
EQ25xxSAM Signal Audible Module2-11	Fault3-11
EQ22xxIDC Series Initiating Device Circuit2-12	Mounting3-11
EQ22xxDCU / EQ22xxDCUEX Digital	Wiring3-11
Communication Units2-12	EQ22xxIDCSC Series Initiating Device Circuit Short
	Circuit
	Mounting3-12

Wiring3-12

Table of Contents – Continued

EQ300X CONTROLLER INSTALLATION	3-13	ANALOG INPUT MODULE INSTALLATION	3-35
Enclosure Requirements	3-13	Mounting	3-35
Mounting	3-13	Wiring	3-35
Serial Interface Board	3-13	Configuration	3-36
Wiring	3-14	INTELLIGENT PROTECTION MODULE INSTALLATION	ON 3-37
Power Wiring	3-14		
Electrical Connections	3-14	Wiring Configuration	
Configuration	3-20	•	
Software Defined Addresses	3-20	GAS DETECTOR LOCATION AND INSTALLATION	3-41
EQ300X REDUNDANT CONTROLLER INSTALLA		Environments and Substances that Affect Gas D Performance	
Enclosure Requirements		EQ22xxDCU Digital Communication Unit used w	ith Det-
Mounting		Tronics H2S/O2 Sensors or other Two-Wire	
Wiring		mA Devices	
LON Wiring		Assembly and Wiring Procedure	
High Speed Serial Link (HSSL)		Sensor Separation for DCU with H2S and C Sensors	
Configuration		EQ22xxDCU Digital Communication Unit used w	
S3 Configuration		PointWatch/DuctWatch	
Controller Addresses		Assembly and Wiring Procedure	3-44
Modbus ControlNet		Sensor Separation for DCU with PointWatch	າ3-44
		EQ22xxDCUEX Digital Communication Unit (use	
POWER SUPPLY AND POWER SUPPLY MONIT		Det-Tronics Combustible Gas Sensors)	
INSTALLATION		Mounting	
Mounting		Wiring	
Wiring		Sensor Separation with DCUEX	
Startup		EQ25xxARM Series Agent Release Module	
Measuring Battery Voltage and Charging Curi	rent3-23	Mounting	
EDIO MODULE INSTALLATION	3-24	Wiring	
Configuration	3-28	Jumpers	
8 CHANNEL DCIO INSTALLATION		Address Setting	
		EQ25xxSAM Series Signal Audible Module	
Mounting		Mounting	
Wiring		Wiring	
Configuration	3-33	Jumpers Address Setting	
8 CHANNEL RELAY MODULE INSTALLATION	3-33	-	
Mounting	3-33	SYSTEM CONFIGURATION	3-52
Wiring	3-33	Setting Device Network addresses	3-52
Configuration	3-34	Overview of Network Addresses	3-52
		Setting Field Device Addresses	3-52
		TYPICAL APPLICATIONS	2 50

Table of Contents – Continued

Section	4 - 0	peration
---------	-------	----------

SYSTEM CONTROLLER	4-1
Pushbuttons	4-1
Controller Status Indicators	4-2
Text Display	4-2
Controller Menu Options	4-2
Controller Audible Alarm	_
ControlNet Status Indicators (Optional)	4-7
Sequence of Events During a Configuration Data Download	4-7
Controller Redundancy	
ENHANCED DISCRETE I/O MODULE	4-11
Power-Up Sequence	4-11
8 CHANNEL DCIO MODULE	4-12
Power-Up Sequence	4-12
8 CHANNEL RELAY MODULE	4-13
Power-Up Sequence	4-13
ANALOG INPUT MODULE	4-14
Power-Up Sequence	4-14
INTELLIGENT PROTECTION MODULE	4-15
Power-Up Sequence	4-15
Embedded Logic - Purpose	4-15
Embedded Logic - Control Transfer Sequence Description	on4-15
Embedded Logic - S3 Configurable Options	4-16
Embedded Logic - Operation	4-17

EQ21XXPS POWER SUPPLY MONITOR	4-18
EQ2220GFM GROUND FAULT MONITOR	4-18
EQ22XXIDC SERIES INITIATING DEVICE CIRCUIT	4-19
EQ22XXDCU AND EQ22XXDCUEX DIGITAL COMMUNICATION UNITS	4-19
EQ25xxARM AGENT RELEASE MODULE	4-20
EQ25xxSAM SIGNAL AUDIBLE MODULE	4-20
EQ24xxNE NETWORK EXTENDER	4-20
SYSTEM STARTUP	4-21
Pre-Operation Checks	4-21
General Start-up Procedures	4-22
Startup Procedure for Controller	4-23
Startup Procedure for EDIO Module	4-23
Startup Procedure for DCIO Module	4-24

Table of Contents - Continued

Section 5 - Maintenance

ROUTINE MAINTENANCE5-1
Batteries5-1
Manual Check of Output Devices5-1
O-Ring Maintenance5-1
GAS SENSOR MAINTENANCE5-1
CALIBRATION AND ADJUSTMENTS5-2
Calibration Algorithm A For Manual Calibration of Universal DCU5-2
Normal Calibration5-2
Sensor Replacement5-3
Calibration Algorithm C For Combustible Gas DCUs and Automatic Calibration of Universal DCUs5-3
Routine Calibration5-3
Sensor Replacement — Combustible Gas5-4
Sensor Replacement — Toxic Gas5-4
Calibration Algorithm D For Universal DCUs with O2 Sensor5-5
Normal Calibration5-5
Sensor Replacement5-5
Calibration Algorithm G For DCUs with PointWatch or DuctWatch5-6
Routine Calibration
Sensor Replacement5-6
DEVICE CALIBRATION LOGS AND RECORDS5-6
TROUBLESHOOTING5-7
REPLACEMENT PARTS5-8
DEVICE REPAIR AND RETURN5-8

ORDERING INFORMATION.....5-8

Section 6 - Specifications

EQ300X Controller	6-1
LON Termination Module	6-2
EQ3730EDIO Enhanced Discrete I/O Module	6-3
EQ3700 DCIO Module	6-5
EQ3720 Relay Module	6-6
EQ3710AIM Analog Input Module	6-7
HART Interface Module	6-7
EQ3740IPM Intelligent Protection Module	6-8
EQ21xxPS Power Supplies	6-9
EQ21xxPSM Power Supply Monitor	6-10
EQ22xxIDC Series Initiating Device Circuit	6-10
EQ2220GFM Ground Fault Monitor	6-11
EQ22xxDCU Series Digital Communication Unit	6-12
EQ25xxARM Agent Release Module	6-12
EQ25xxSAM Signal Audible Module	
EQ24xxNE Network Extender	6-13
Combustible Gas Sensor	
Electrochemical Sensors	6-14
EQ21xxPS Power Supply	6-14
APPENDIX A — FM APPROVAL DESCRIPTION	A-1
APPENDIX B — CSA CERTIFICATION DESCRIPTION	NB-1
APPENDIX C — CE MARK	C-1
APPENDIX D — BOCKER SWITCH TABLE	D-1







Eagle Quantum™ Premier Fire and Gas Detection/Releasing System

Section 1 Safety

ALERT MESSAGES

The following Alert Messages, **DANGER**, **WARNING**, **CAUTION**, and **IMPORTANT** are used throughout this manual and on the system to alert the reader and operator to dangerous conditions and/or important operational or maintenance information.

MDANGER!

Identifies immediate hazards that **WILL** result in severe personal injury or death.

△WARNING!

Identifies hazards or unsafe practices that **COULD** result in severe personal injury or death.

∆CAUTION!

Identifies hazards or unsafe practices that **COULD** result in minor personal injury or damage to equipment or property.

⚠IMPORTANT!

A brief statement of fact, experience or importance that is given as an aid or explanation.

△WARNING!

The hazardous area must be de-classified prior to removing a junction box cover or opening a detector assembly with power applied.

*Oi is Detector Electronics' Trademark for its patented Optical Integrity Systems, U.S. Patent 3,952,196, United Kingdom Patent 1,534,969, Canada Patent 1,059,598.

A CAUTION!

- Be sure to read and understand the entire instruction manual before installing or operating the Eagle Quantum Premier system. Only qualified personnel should install, maintain or operate the system.
- 2. The wiring procedures in this manual are intended to ensure proper functioning of the devices under normal conditions. However, because of the many variations in wiring codes and regulations, total compliance with these ordinances cannot be guaranteed. Be certain that all wiring complies with the NEC as well as all local ordinances. If in doubt, consult the authority having jurisdiction before wiring the system.
- 3. Some Eagle Quantum Premier devices contain semiconductor devices that are susceptible to damage by electrostatic discharge. An electrostatic charge can build up on the skin and discharge when an object is touched. Always observe the normal precautions for handling electrostatic sensitive devices, i.e. use of a wrist strap (if available) and proper grounding.
- 4. To prevent unwanted actuation, alarms and extinguishing devices must be secured prior to performing system tests.

NOTES

Wiring and equipment installation must meet or exceed the latest revisions of the appropriate NFPA Standards, National Electrical Code (NEC), and Authorities Having Jurisdiction (AHJ).

All wiring shall be installed in accordance with the manufacturer's recommendations.

Section 2 Introduction

SYSTEM DESCRIPTION

The Eagle Quantum Premier (EQP) system combines "fire detection and extinguishing agent release" and "hazardous gas monitoring" in one complete package. The system is intended for use in hazardous locations and is designed to meet the requirements of approval agencies from around the world.

The system consists of a Controller and a number of addressable microprocessor based field devices. The Controller coordinates system device configuration, monitoring, annunciation, and control, while the field devices communicate their status and alarm conditions to the Controller.

The EQP controller can be arranged in a redundant configuration, thereby increasing the availability of the system. The controllers work in "Master" and "Hot Standby" mode.

Various combinations of field devices can be configured as part of the system. The actual selection depends on the requirements of the application and the regulations that cover the type of protection required. See Figure 2-1 for a block diagram of the Eagle Quantum Premier system.

All field devices are tied into a communication loop that starts and ends at the Controller. Each device connected to the communication loop is assigned a unique identity by setting its address switches. All other device operation parameters are configured through Det-Tronics "Safety System Software". These selections define the type of device and how it is to operate. This system configuration data is then downloaded into the Controller.

A programmed Controller is configured to automatically download the configuration data into the individual devices when they first communicate with the Controller.

In addition to Det-Tronics advanced flame and gas detectors, Eagle Quantum Premier offers the capability of incorporating third party fire and gas protection equipment into the system. These can be either input or output devices. Typical input devices include manual fire alarm "call boxes", heat detectors, and analog combustible or toxic gas measurement instruments. Typical output equipment includes solenoids, strobes, and horns. All equipment is monitored for wiring fault conditions.

For complete system integration, the Controller has the capability to communicate with other systems such as PLCs and DCSs. Different communication protocols are supported, allowing the Controller to communicate with other systems either directly or through communication gateways.

NOTE

Existing Eagle Quantum field devices such as EQ22xxUV, EQ22xxUVIR and EQ22xxUVHT are supported by the Eagle Quantum Premier system (not FM Approved).

COMMUNICATIONS LOOP

Eagle Quantum Premier utilizes a Det-Tronics Signaling Line Circuit (SLC), a version of Echelon's Local Operation Network (LON) customized specifically for Eagle Quantum Premier. This network provides several key advantages:

- ANSI/NFPA Class A, Style 7 performance of SLC
- Peer-to-peer communications
- Short message formats
- Expandability

The Controller utilizes several mechanisms to continuously check the LON loop for fault conditions, thereby providing the highest level of reliable communication.

Every device on the LON loop has the ability to communicate with the Controller at any time. This is typically referred to as distributed peer-to-peer communications. This design allows for immediate alarm messages to be sent from the field devices to the Controller.

All messages are kept short in order to maximize network performance. This minimizes network bottlenecks.

The Eagle Quantum Premier system is easily modified to accommodate design changes or plant expansions. This can involve adding LON sections, repositioning LON sections, or removing LON sections from the loop. There are LON communication implementation details that affect and limit how the LON loop is changed.

Only devices that have been approved for use with Eagle Quantum Premier can be connected up to the LON. All approved devices have been tested and certified to operate properly on the LON.




Figure 2-1—Block Diagram of Eagle Quantum Premier System

LON COMMUNICATION HEARTBEAT

The Controller continuously broadcasts a heartbeat signal over the LON loop. This heartbeat is used for verifying the integrity of the LON loop and for keeping the field devices from going into a fault isolation mode. Once every second, the heartbeat contains the current time and date, which are used by the field devices to log status events and calibrations.

The Controller continuously tests LON continuity by sending out a heartbeat on one LON port and then listening for it on the other LON port. The Controller also broadcasts the heartbeat signal in the opposite direction around the loop. This ensures that all field devices, the LON Network Extenders (NE), and communication wiring are correctly passing the digital information around the loop.

The field devices use the heartbeat as a mechanism to ensure that there is a communication path back to the Controller. If the field device does not receive a

heartbeat for a period of time, the device will go into a LON fault isolation. In this situation, the device opens one side of the LON and listens for a heartbeat on the other side. If the device doesn't receive a heartbeat, it listens on the other side of the LON and opens the opposite LON connection.

THEORY OF OPERATION

During normal operation, the Controller continuously checks the system for fault conditions and executes user defined programmed logic that coordinates the control of the field devices. At the same time, the field devices are continuously monitoring for device based fault and alarm conditions.

When a fault condition occurs, the Controller displays the fault condition on the Vacuum Fluorescent Text Display, activates the appropriate fault LED(s), activates the Trouble signal using the Controller's internal enunciator, and de-energizes the Controller's Trouble relay.

Table 2-1—Controller Based Faults

Controller Faults Shown on Text Display	Trouble LED	LON Fault LED	Trouble Relay
Device Offline	Х		Х
Extra LON Device	Х		Х
Invalid Config	Х		Х
Lon Fault	Х	Х	Х
LON Ground Fault	Х		Х
Power Fail 1	Х		Х
Power Fail 2	Х		Х
RTC Fault	Х		Х
Redundancy Fault*	Х		Х

^{*}Only for controller pair configured for redundancy.

Controller based fault conditions include the Controller status and LON communications such as the heartbeat being sent around the loop and the field device loss of communications. Controller based fault conditions are listed in Table 2-1.

Field device based fault conditions are transmitted to the Controller, where they are then annunciated. Refer to Table 2-2 for a listing of field device faults. Each field device transmits its status to the Controller on a regular basis.

When an alarm condition occurs, the Controller displays the alarm condition on the text display, activates the appropriate Alarm LED(s), and activates the alarm signal using the Controller's internal annunciator.

Field Device Faults Shown on Text Display	Trouble LED	Trouble Relay
290 Volt Fault	Х	Х
AC Failed	Х	Х
Battery Fault	Х	Х
Calibration Fault	Х	Х
Channel Open	Х	Х
Channel Short	Х	Х
Dirty Optics	Х	Х
Ground Fault Negative	Х	Х
Ground Fault Positive	Х	Х
IR Auto Oi Fault	Х	Х
IR Fault	X	Х
IR Manual Oi Fault	Х	Х
Low Aux Power Fault	Х	Х
Missing IR Sensor Fault	Х	Х
Missing UV Sensor Fault	X	Х
Power Supply Fault	Х	Х
Sensor Fault	Х	Х
Supply Voltage Fault	X	Х
Supply Voltage Fault	Х	Х
UV Auto Oi Fault	Х	Х
UV Fault	Х	Х
UV Manual Oi Fault	Х	Х

Each field device must communicate alarm and fault conditions to the Controller. The timing for transmitting alarms and faults to the Controller is displayed in Table 2-3.

Table 2-3—Eagle Quantum Premier Status Update Rates

Number of Devices	Output Devices	Old Input Devices	Newer Input Devices
	ARM	IDC	DCU*
	SAM	UV Detector	DCIO*
		UVIR Detector	X3301*
			X3302*
			Eclipse*
			X5200*
			X2200*
			X9800*
			AIM*
			IPM*
			PSM
1 to 100	1 Second	1 Second	1 Second
101 to 200	2 Seconds	2 Seconds	2 Seconds
201 to 246	5 Seconds	2 Seconds	3 Seconds

^{*}Alarms are transmitted immediately. For Eclipse, the Status Update Rate is 1 second for all network sizes.

NOTE

All fault and alarm conditions are latched on the Controller. To reset the Controller, conditions indicated on the text display must currently be in the OFF state. Pushing the reset button then initiates a Controller reset. Active alarms will remain through a Controller reset.

CONTROLLER LOGS

The controller has an internal alarm and event log. The logs can be accessed via the S³ software configuration ports (Configuration Port or Port 3) using a RS-232 serial cable and a Windows™ computer. The controller can save up to 4,095 alarms and events in the controller memory.

CONTROLLER USER LOGIC

The Controller continuously executes the user logic programs that are programmed using S³ software. The user logic programs are set up in the same fashion as IEC 61131-3 programmable logic programmed into Programmable Logic Controllers (PLCs). Block diagram logic gates are tied together with inputs, outputs, and other logic gates to perform a specific task. A number of tasks can be tied together to perform a system function.

Typical programmed functions include flame/gas voting, timing delays, timing executions, latching conditions, alarm and trouble notification, suppression control, condition control, and process shutdown notification.

The Controller executes program logic by starting with the first logic page of the first program and then progressing onto subsequent pages of the same program. In turn, subsequent programs are then executed.

Every one hundred milliseconds, the Controller will start executing the user logic that is programmed into the Controller. Within this logic execution cycle, the Controller will execute as many of the logic pages as possible. If all programmed logic is executed in a cycle, the Controller will start executing program logic with the next cycle. Otherwise, subsequence logic execution cycles are used to finish executing the remaining logic gates. Only when all the logic gates have been executed will the Controller start over. The Controller will start executing the first logic page of the first program at the beginning of the next logic cycle.

COMMUNICATION NETWORK FAULT OPERATION

During normal operation, the Controller is continuously broadcasting a heartbeat around the communication loop as shown in Figure 2-2. The Controller broadcasts the heartbeat in both directions. At the same time, the field devices are transmitting status information to the Controller over the communication loop.

Every field device except the network extender has two LON fault isolation relays. Each relay is tied to a communication port on the device. When a field device fails to receive the heartbeat from the Controller, the device initiates a LON fault isolation routine. The isolation routine disconnects one of the communication ports via one of the LON fault isolation relays. The device listens for a heartbeat on the communication port that is connected. If a heartbeat is not found, the routine then disconnects the other communication port and listens for a heartbeat on the connected side. The process is repeated until either a heartbeat is located or a LON fault timeout period of two hours is reached. The LON fault isolation routine is disabled and the LON fault isolation relavs are closed when the LON fault timeout period has elapsed. The LON fault isolation routine will be enabled when the device again receives a heartbeat.

For a single wiring fault, the field devices with the fault will isolate the fault by opening LON fault isolation relays. After the field devices isolate the wiring fault, communications will be resumed between the Controller and field devices. Refer to Figure 2-3.




Figure 2-2—Normal Communication over the LON




Figure 2-3—Communication over the LON with a Single Wiring Fault




Figure 2-4—Communication over LON with Multiple Wiring Faults

MULTIPLE WIRING FAULTS

In the event of multiple wiring faults on the LON, the devices between the faults will continue to function, but the faults will prevent them from communicating with the Controller. See Figure 2-4. In this example, nodes 1 to 4 communicate using one Controller port (path A) and nodes 7 and 8 use the other Controller port (path B). Nodes 5 and 6 are unable to report to the Controller because they are isolated by the two wiring faults. If a device is prevented from communicating with the Controller, the text display on the Controller will show the message "Device Offline".

⚠IMPORTANT!

Since it is impossible to predict where a network fault might occur or exactly what effect it will have on actual system operation, it is important to diagnose and repair any fault as soon as possible after it is detected to ensure continuous, uninterrupted system operation.

MAJOR COMPONENT DESCRIPTIONS

The system has three (3) main component groups—the System Controller, LON (Local Operating Network), and Intelligent Field Devices.

SYSTEM CONTROLLER

The Controller (see Figure 2-5) performs all communication, command, and control functions for the system. The Controller supports both "Static" and "Programmable" logic. Other features include:

- Redundant controller capability
- User pushbutton controls (reset, acknowledge, etc.)
- "Real time" system clock
- Internal alarm sounder
- Vacuum fluorescent text based display that shows current system status
- 8 programmable unsupervised inputs

- 8 programmable unsupervised relay outputs
- RS-485 Modbus RTU communication interface that supports coils, discrete inputs, and holding registers
- Optional ControlNet communication board that supports redundant communication channels.
- Optional Serial Interface Board (required for controller redundancy).



Figure 2-5—System Controller

Controller Redundancy

The EQP controllers can be configured as a redundant pair. See Figure 2-6. The redundancy scheme is a hot standby system that offers the following primary features:

- Automatic configuration of the standby controller
- Bumpless transfer
- Forced and automatic switchover
- No downtime on controller replacement
- Automatic synchronization between controllers
- Increased system availability




Figure 2-6— Block Diagram of EQP System with Redundant Controllers

During normal operation one controller acts as the "Master" while the other acts as the "Hot Standby".

Terminology used for redundancy:

Master controller

This is the normal mode for non-redundant and master controllers. User logic is executed, outputs are being controlled and all serial ports are active.

Standby controller

This controller is receiving all inputs but does not have any control over the outputs and user logic is not executed. The standby controller receives update information from the master controller to ensure a bumpless transfer should a controller switchover occur.

Primary controller

The controller assigned address 1.

Secondary Controller The controller assigned address 2.

Bumpless transfer

During a controller switchover no change in output will occur due to the switchover.

Serial Interface Board

An optional serial board is available that supports up to four additional serial ports. See Table 2-4. For a redundant controller configuration, the board is required in both controllers.

Table 2-4—Ports on Optional Serial Interface Board

Port Name	Comm	Function
Serial Port 2	RS485	ModBus (Master/Slave) Ground Fault Monitored, Isolated
Serial Port 3	RS232	ModBus (Master/Slave) S3 Configuration
Serial Port 4	RS232	ModBus (Master/Slave)
HSSL Redundancy Port	RS232	Redundant Controller to Controller Only

LOCAL OPERATING NETWORK (LON)

The LON is a fault tolerant, two wire, digital communication network. The circuit is arranged in a loop starting and ending at the Controller. The circuit supports up to 246 intelligent field devices spread over a distance of up to 10,000 meters (32,500 feet).

NOTE

All LON devices support ANSI/NFPA 72 Class A, Style 7 communication with the Controller.

Network Extenders

Transmitted signals can travel a maximum distance of 2,000 meters through LON communication wire. At the end of this distance, a network extender (see Figure 2-7) must be installed to rebroadcast the communications into the next wire segment. For every network extender added, the length of the communications loop extends up to 2,000 meters. Due to propagation delays around the loop, the maximum loop length is limited to 10,000 meters.



Figure 2-7—Eagle Quantum Premier Network Extender

NOTES

A network extender is required for communication loops greater than 60 nodes.

Communication wire segment lengths are dependent upon physical and electrical characteristics of the cable. Refer to the installation section for LON cable wire information.

No more than six network extenders may be used on the communication loop.

Only 40 field devices can be installed in a network segment when a network extender is installed in the communication loop. The network segment is the wiring segment between two network extenders or between a network extender and a controller.

EQ21xxPS Series Power Supplies and EQ2100PSM Power Supply Monitor

The Power Supply, Power Supply Monitor, and backup batteries are used to provide power to the system. The power supply monitor communicates trouble conditions to the Controller. Monitored status conditions include: power supply failure, loss of AC power, loss of battery power, power ground fault, AC and DC voltage (hi/low level), and backup battery current charge levels.

EQ211xPS, EQ213xPS and EQ217xPS Power Supplies

The Power Supply provides main and backup power to the EQP System. The device includes many features such as voltage regulation, high efficiency, and high power factor.

An equalize switch is located on the front panel of the charger for manual activation, or a multi-mode electronic timer can be used for automatic activation. Steady state output voltage remains within +/- 1/2% of the setting from no load to full load for AC input voltages within +/- 10% of the nominal input voltage.

EQ2220GFM Ground Fault Monitor

The EQ2220GFM Ground Fault Monitor (see Figure 2-8) provides ground fault monitoring in a system that includes a floating 24 Vdc power source. The device detects ground fault conditions on +/- power and all secondary I/O circuits. A positive or negative ground fault condition is indicated immediately by local LEDs, and by a relay contact after a 10 second time delay. The ground fault monitor is intended to be mounted in the same enclosure as the controller.



Figure 2-8—Ground Fault Monitor

FIELD DEVICES

Flame Detectors

For flame detector installation, operation, maintenance, specifications and ordering information, refer to Table 2-5.

Table 2-5—Flame Detector Manuals

Detector	Manual Number
X3301	95-8527
X3301A	95-8527 & 95-8534
X3302	95-8576
X5200	95-8546
X2200	95-8549
X9800	95-8554
UVHT	95-8570

EQ3730EDIO Enhanced Discrete Input/Output Module

The 8 Channel EDIO Module (see Figure 2-9) expands the Input and Output capability of the Eagle Quantum Premier System.

The unit is designed to provide continuous and automated fire/gas protection, while ensuring system operation through continuous supervision of System Inputs/Outputs.

The EDIO module provides eight channels of configurable input or output points that can be programmed for supervised or unsupervised operation. Each input point can accept fire detection devices such as heat, smoke, or unitized flame detectors. Each output point can be configured for signaling or releasing output operation. Each channel on the module is provided with individual indicators for active and fault conditions.

IMPORTANT

For Class A wiring, two input/output channels are combined, thereby supporting up to four input/output circuits.

NOTE

An input must be active for at least 750 milliseconds in order to be recognized.

The EDIO module can be mounted directly to a panel, or it can be DIN rail mounted. System status can be determined using the trouble-shooting procedures, Eagle Quantum Safety System Software (S3) and the status indicators on the module.

Refer to the Enhanced Discrete Input/Output Module Specification Data sheet (form number 90-1189) for additional information.



Figure 2-9—Enhanced Discrete Input/Output Module

EQ3700 8 Channel DCIO Module

The 8 Channel Direct Current Input/Output (DCIO) Module (see Figure 2-10) consists of eight individually configured channels. Each channel is configured as either an input or output with the appropriate wiring supervision. Wiring supervision includes none, open circuits, and "open and short" circuits. In addition to defining the type of supervision, an input channel is also configured to generate the appropriate static logic alarm message to the controller.

NOTE

NFPA 72 requires wire supervision selection for fire detection and notification devices (IDC, NAC, supervisory and releasing devices).

Heat, smoke, or unitized flame detectors can be wired into channels defined as inputs. Horns, strobes/beacons, and solenoids can be wired into channels defined as outputs.

NOTE

The DCIO outputs only support equipment that operates on 24 vdc (not to exceed 2 amperes per channel).

The DCIO has two device status LEDs, as well as two LEDs for each channel. On the device level, one green LED indicates power, while the other amber LED indicates a LON CPU fault. For each channel, one red LED indicates channel activation and the other amber LED indicates a fault condition when wiring supervision is defined for the channel.

Refer to the DCIO Specification Data sheet (form number 90-1149) for additional information.



Figure 2-10—DCIO Module

EQ3720 8 Channel Relay Module

The 8 Channel Relay Module (see Figure 2-11) consists of eight individually configured output channels.

NOTE

The relay module only supports equipment that operates on 24 vdc (not to exceed 2 amperes) at each output channel.

The relay module has two LEDs for the device and two LEDs for each channel. On the device level, one green LED indicates power, while the other amber LED indicates a LON CPU fault. For each channel, one red LED indicates channel activation and the other amber LED indicates that the module operating voltage is low or that the module has not been configured (all eight channel LEDs blink).

Refer to the Relay Module Specification Data sheet (form number 90-1181) for additional information.



Figure 2-11—Eight Channel Relay Module

EQ3710AIM Analog Input Module

The 8 Channel Analog Input Module (see Figure 2-12) provides a means of connecting devices with a calibrated 4-20 mA output signal to the Eagle Quantum Premier System.

The Analog Input Module (AIM) provides 8 configurable channels that can be set for either combustible gas mode or universal mode. The combustible gas mode provides a number of automatically programmed settings, and alarm thresholds that are limited to approval body requirements. The universal mode is used for generic devices where control over all configuration parameters is required. All devices must provided their own calibration facilities.

For fire detector 4-20 mA inputs, the Analog Input Module (AIM) is certified for use as an NFPA 72 Class B, Style B Approved input.

Refer to the Analog Input Module Specification Data sheet (form number 90-1183) for additional information.



Figure 2-12—Eight Channel Analog Input Module

EQ3740IPM Intelligent Protection Module

The IPM (see Figure 2-13) is designed to provide continuous and automated local area fire protection, while monitoring system operation through continuous supervision of its Inputs/Outputs and Local Operating Network/Signalling Line Circuit (LON/SLC) connection to the EQP controller.

In addition the module contains a unique "embedded logic program" that if enabled during configuration allows the IPM to perform local area protection in a "back-up mode" without controller interaction.

The IPM utilizes eight pre-configured Input/Output (I/O) channels to perform its monitoring, supervison and mitigation functions.

On the input side, three supervised channels provide connections for an Abort station, a Manual Release station and a Supervisory device. Two additional input channels (zones) provide connections for "two-wire" conventional (non-relay based) smoke and heat detectors.

On the output side, three supervised outputs provide connections for a notification appliance such as a bell, horn or lamp and two releasing circuits for a main and reserve or secondary agent release.

Each channel on the module is provided with individual indicators for active and fault conditions.

Refer to the Intelligent Protection Module Specification Data sheet (form number 90-1184) for additional information.



Figure 2-13—Intelligent Protection Module

EQ25xxARM Agent Release Module

The EQ25xxARM Series Agent Release Module (ARM) (see Figure 2-14) provides agent release or deluge pre-action capability. The device is controlled by programmable logic in the Controller. Time delay, abort and manual release sequences allow the device output to be programmed for use in unique applications.

The device is field programmed to operate in one of the following modes:

Squib— Output is activated for a factory-set

time period to set off the explosive

device.

Timed- Output is activated for a field

selectable duration from 1 to 65,000

seconds.

Continuous— Output latches until reset.

Non-latching— Output follows the input.

The device can monitor and control two output devices (24 vdc rated) that are programmed and energized together. The release circuits are compatible with a variety of solenoid or initiator (squib) based suppression systems.

The release circuit is supervised for open circuit conditions. If a trouble condition occurs (open circuit or solenoid supply voltage less than 19 volts), it will be indicated at the Controller. Each output is rated at 2 amperes and auxiliary input terminals are provided for additional 24 vdc output power where needed.

NOTE

For deluge and pre-action applications, the input voltage to the ARM or DCIO must be 21 VDC minimum with connection to any solenoid listed in Table 2-6 or 2-7. Wiring must be in accordance with the listed maximum wiring lengths.

Refer to the EQ25xxARM Specification Data sheet (form number 90-1128) for additional information



Figure 2-14—Agent Release Module

Table 2-6—Solenoid Compatibility with Agent Release Module for Deluge and Pre-Action Applications

FM Group	Device					
В	ASCO T8210A107					
D	ASCO 8210G207					
Е	Skinner 73218BN4UNLVNOC111C2					
F	Skinner 73212BN4TNLVNOC322C2					
G	Skinner 71395SN2ENJ1NOH111C2					
Н	Viking HV-274-0601					

Table 2-7—Maximum Wiring Length for FM Approved Solenoids for Deluge and Pre-Action Applications

	Solenoi	ds	Maximu	m Wire Lengtl	h in Feet (Me	eters)
FM Solenoid Group	Manufacturer	Model	12 AWG	14 AWG	16 AWG	18 AWG
В	ASCO	T8210A107	183 (56)	115 (35)	72 (22)	46 (14)
D	ASCO	8210G207	314 (96)	198 (60)	124 (38)	78 (24)
E	Skinner	73218BN4UNLVNOC111C2	331 (101)	208 (63)	131 (40)	82 (25)
F	Skinner	73212BN4TNLVNOC322C2	130 (40)	82 (25)	51 (16)	32 (10)
G	Skinner	71395SN2ENJ1NOH111C2	331 (101)	208 (63)	131 (40)	82 (25)
Н	Viking	HV-274-0601	180 (55)	110 (34)	70 (21)	45(14)

EQ25xxSAM Signal Audible Module

The EQ25xxSAM Series Signal Audible Module (SAM) (see Figure 2-15) provides two indicating circuits for controlling UL Listed 24 vdc polarized audible/visual indicating appliances.

The device is located on the LON and is controlled by programmable logic in the Controller.

Each output circuit is independently programmable to allow notification of separate events. Each output can be individually activated for any one of the following pre-defined outputs:

- 1. Continuous
- 2. 60 beats per minute
- 3. 120 beats per minute
- 4. Temporal pattern.

Device outputs operate in the reverse polarity manner when activated. Each output is rated at 2 amperes. Auxiliary power input terminals are provided for additional 24 vdc signaling power where required. The output circuits are supervised for open and short circuit conditions. If a wiring fault occurs, a trouble condition will be indicated at the Controller.

Refer to the EQ25xxSAM Specification Data sheet (form number 90-1129) for additional information



Figure 2-15—Signal Audible Module

EQ22xxIDC Series Initiating Device Circuit (IDC)

There are three IDC models available (see Figure 2-16):

The **EQ22xxIDC** allows discrete inputs from smoke/heat detectors, manual call stations or other contact devices.

The IDC accepts two dry contact inputs for use with devices such as relays, pushbuttons, key switches, etc. The IDC supports ANSI/NFPA 72 Class B, Style B supervised input circuits

Each circuit requires its own end of line (EOL) resistor for monitoring circuit continuity. Nominal resistance of the resistor is 10 k ohms.

The **EQ22xxIDCGF** Initiating Device Circuit Ground Fault Monitor (IDCGF) responds to the presence of a ground fault within the power circuitry of the system. It provides an unsupervised dry contact input and ground fault monitoring circuitry for indicating a power supply trouble condition. It is intended for use with a third party power supply.

The **EQ22xxIDCSC** Initiating Device Circuit Short Circuit (IDCSC) is similar to the IDC, but supports ANSI/NFPA 72 Class B Style C supervised input circuits. (Not FM Approved.)

Refer to the EQ22xxIDC Specification Data sheet (form number 90-1121) for additional information.



Figure 2-16—Initiating Device Circuit

NOTE

Input types (e.g. fire alarm, trouble, and gas alarms) are configurable through Det-Tronics Safety System Software (S³).

EQ22xxDCU and EQ22xxDCUEX Digital Communication Units

The EQ22xxDCU Digital Communication Unit (DCU) is an analog signal input device that accepts a 4 to 20 milliampere signal. The device is typically connected to gas detectors, where the analog signal represents the gas concentration.

Calibration of the DCU involves a non-intrusive procedure that can be performed by one person at the device without declassifying the area.

The device supports two alarm setpoints that are defined as part of the device's configuration setup. When detecting combustible gases, the alarm setpoints represent low and high gas alarm levels. When detecting oxygen, the alarms represent the range for the acceptable oxygen level. If oxygen drops below the alarm range, a low alarm is generated by the device.

PointWatch/DuctWatch IR gas detector as well as electrochemical sensors (hydrogen sulfide, carbon monoxide, chlorine, sulfur dioxide, and nitrogen dioxide) are examples of devices that can be connected to the DCU.

NOTE

A catalytic sensor can be connected to a DCU through a transmitter, which converts the millivolt signal to a 4 to 20 milliampere signal.

The EQ22xxDCUEX is a specialized version of the DCU that contains a transmitter for connection to a Det-Tronics Model CGS catalytic combustible gas sensor.

Refer to the EQ22xxDCU Specification Data sheet (form number 90-1118) for additional information

PIRECL PointWatch Eclipse

For PIRECL installation, operation, maintenance, specifications and ordering information, refer to form number 95-8526.

Section 3 Installation

SAFETY SYSTEM DESIGN REQUIREMENTS

Many factors need to be considered when determining proper EQP System design. The following paragraphs will discuss these factors and other issues useful in designing, installing and configuring the Eagle Quantum Premier System.

IDENTIFYING THE AREA OF PROTECTION

In order for the system to provide optimum coverage and protection, it is critical to properly define the required "Area of Protection" (total area being monitored by the system). The area of protection should include all hazard sources requiring monitoring, as well as suitable locations for mounting detection, extinguishing, notification, and manual devices. In order to accurately define the area of protection and provide maximum protection, all potential "Real" and "False" hazard sources must be identified. The number and location of Real Hazards determines the extent of the area of protection, and impacts all subsequent design decisions.

AWARNING!

When drilling through surfaces in the process of mounting equipment, verify that the location is free of electrical wiring and electrical components.

IDENTIFYING WIRING, NETWORK (LON), AND SYSTEM POWER REQUIREMENTS

General Wiring Requirements

MWARNING!

DO NOT open any junction box or device enclosure when power is applied without first declassifying the hazardous area.

CAUTION!

Any deviation from the manufacturer's recommended wiring practices can compromise system operation and effectiveness. ALWAYS consult the factory if different wire types or methods are being considered.

NOTE

All wiring must be marked per NFPA 70 Article 760.

NOTE

Specific installation requirements may differ depending on local installation practices and compliance with third party certifications. For local installation practices, consult the local authority having jurisdiction. For compliance with third party certifications, consult the appropriate appendix in this manual for additional installation requirements.

Power Wiring

△IMPORTANT!

For deluge and pre-action applications, input voltage to the DCIO or ARM must be 21 vdc minimum to ensure proper operation of the connected output device.

△IMPORTANT

To ensure proper operation of field devices, the voltage input to the device (measured at the device) must be within the range indicated for that device in the "Specifications" section of this manual (18 Vdc minimum).

The Eagle Quantum Premier system utilizes a power supply that provides an isolated 24 vdc battery backed-up power to the fire protection devices as described in NFPA 72. More than one power supply may be used in a system to provide power to different sets of equipment as part of the system.

The power supply wiring may consist of one or more daisy-chained wire segments providing power to the devices. For each of the daisy-chained wire segments, the installer must calculate the voltage drops that occur across the devices in order to determine the gauge of the wire that will be installed.


A power supply wiring diagram should contain information describing wire distances and current draws associated with all devices connected to the wire segment. A typical power supply wiring recommendation is that the voltage drop from the power source to the end device should not exceed ten percent. Using 24 vdc as a reference, the maximum voltage drop should not exceed 2.4 vdc. A wire gauge must be selected to ensure that the end device has at least 21.6 vdc or higher.

In order to calculate the power supply voltage for the end device, calculate the voltage drops that occur due to each wire segment between the devices. This involves determining the total current draw and the two conductor wire resistance per each wire segment.

Example:

Can 18 AWG wire be used to power three devices from the 24 vdc power supply? Refer to the figure below for wiring and device current draw information along with voltage drop calculations.

Answer: If the Authority Having Jurisdiction (AHJ) requires a voltage loss of 10% or less, only 16 AWG wire could be used, since the end device would require 21.4 vdc. If there is no local requirement, then 18 AWG wire could be used to provide power to the devices.



Determining Power Requirements

Tables 3-1 and 3-2 are provided for calculating the total current requirements for those parts of the system requiring battery backup.

Table 3-1—Standby Current Requirements at 24 vdc

Device Type	Number of Devices		Standby Current		Total Current for Device Type
EQP Controller		Х	0.360	=	
EDIO Module		Х	0.075	=	
DCIO Module		Х	0.075	=	
Power Supply. Monitor		Х	0.060	=	
IDC/IDCGF/IDCSC		Х	0.055	=	
X3301/X3301A - w/o heater		Х	0.160	=	
X3301/X3301A - with heater		Х	0.565	=	
X3302 - without heater		Х	0.160	=	
X3302 - with heater		Х	0.565	=	
X2200		Х	0.135	=	
X9800 - without heater		Х	0.085	=	
X9800 - with heater		Х	0.420	=	
X5200 - without heater		Х	0.155	=	
X5200 - with heater		Х	0.490	=	
DCUEX		Х	0.145	=	
DCU with EC Sensor		Х	0.060	=	
DCU with PointWatch		Х	0.300	=	
DCU with DuctWatch		Х	0.300	=	
Relay Module		Х	0.120	=	
Analog Input Module		Х	0.160	=	
Intelligent Protection Module		Х	0.075	=	
EQ2220GFM		Х	0.018	=	
PointWatch Eclipse		Х	0.270	=	
ARM		Х	0.075	=	
SAM		Х	0.060	=	
Network Extender		Х	0.090	=	
EQ21xxPS Power Supply		Х	0.350	=	
Other		Х		=	
•	Total Standby Curre	nt for	System (in amperes)	=	

Note: Standby current is the average current draw for the device in normal mode. This table is for battery calculations only.

Table 3-2—Alarm Current Requirements at 24 vdc

Device Type	Number of Devices		Alarm Current		Total Current for Device Type	
EQP Controller		Х	0.430	=		
EDIO 8 Inputs		Х	0.130	=		
EDIO 8 Outputs		Х	0.075	=		
DCIO 8 Inputs		Х	0.130	=		
DCIO 8 Outputs		Х	0.075	=		
Relay Module		Х	0.120	=		
Power Supply Monitor		Х	0.060	=		
IDC/IDCGF/IDCSC		Х	0.090	=		
X3301/X3301A - w/o heater		Х	0.160	=		
X3301/X3301A - with heater		Х	0.565	=		
X3302 - without heater		Х	0.160	=		
X3302 - with heater		Х	0.565	=		
X2200		Х	0.135	=		
X9800 - without heater		Х	0.085	=		
X9800 - with heater		Х	0.420	=		
X5200 - without heater		Х	0.155	=		
X5200 - with heater		Х	0.490	=		
DCUEX		Х	0.160	=		
DCU with EC Sensor		Х	0.075	=		
DCU with PointWatch		Х	0.320	=		
DCU with DuctWatch		Х	0.320	=		
Analog Input Module		Х	0.300	=		
Intelligent Protection Module		Х	0.150	=		
EQ2220GFM		Х	0.018	=		
PointWatch Eclipse		Х	0.275	=		
ARM		Х	0.120	=		
SAM		Х	0.120	=		
Network Extender		Х	0.090	=		
EQ21xxPS Power Supply		Х	0.350	=		
Other		Х		=		
Total Sol	Total Solenoid Load +					
Total Sig	+					
Total Ala	Total Alarm Current for System (in amperes) =					

Note: This table is for battery calculations only.

EQ211xPS, EQ213xPS and EQ217xPS Power Supplies

Refer to Table 3-3 for Power Supply ratings.

Backup Battery

Refer to Table 3-4 or 3-5 to calculate the minimum size of the backup battery (in amp hours). Select a sealed lead-acid battery with an adequate amp hour rating.

NOTE

Connect two batteries in series for 24 volts. Be sure that the battery enclosure is adequately ventilated.

Battery Charger

Use the following formula to calculate the minimum battery charger size:

Minimum
Charge Rate = Alarm Current + Total Amp Hours
48

△ CAUTION!

Care should be taken when considering the final voltage at the device during AC power loss. With loss of AC power, the device voltage will drop over time as the batteries lose their charge. If extended periods of AC power loss are to be expected, either consider a heavier wire gauge or specify batteries with higher amp-hour ratings.

Table 3-3—EQ21xxPS Power Supply Specifications

Characteristic	Power Supply					
Cital acteristic	EQ2110PS/EQ2111PS	EQ2130PS/EQ2131PS	EQ2175PS/EQ2176PS			
Input Voltage	120 vac	120/208/240 vac	120/208/240 vac			
Input Current	4 Amps	11/6/6 Amps	24/15/12 Amps			
Input Frequency	60 Hz – EQ2110PS	60 Hz – EQ2130PS	60 Hz – EQ2175PS			
Input Frequency	50 Hz – EQ2111PS	50 Hz – EQ2131PS	50 Hz – EQ2176PS			
Supply Rating	10 Amps	30 Amps	75 Amps			
Maximum Alarm Current	10 Amps	30 Amps	75 Amps			
Maximum Standby Current	3.33 Amps	10 Amps	25 Amps			
Recharge Current	6.67 Amps	20 Amps	50 Amps			
Maximum Battery Capacity	100 AmpHours	300 AmpHours	750 AmpHours			
Maximum Deluge Standby Current*	1 Amp	3 Amps	7.5 Amps			

^{*}Only applies to 90 hour back-up applications.

Table 3-4—Backup Battery Requirements for Automatic Release of Extinguishing Systems Except Deluge

Standby Current	Ţ	Standby Time*		Standby Amp Hours	
	X	24 Hours =			
Alarm Current		5 Minute Alarm Time*		Alarm Amp Hours	
	X	0.083 Hours	=		
Sum of Standb	=				
Multiply by 1.1 (10% Safety Factor)					
Total Battery Amp Hour Requirement —					

Table 3-5—Backup Battery Requirements for Deluge and Pre-Action Applications

Standby Current		Standby Time*		Standby Amp Hours	
	X	90 Hours	=		
Alarm Current		10 Minute Alarm Time*		Alarm Amp Hours	
	X	0.166 Hours	=		
Sum of Standb	=				
Multiply by 1.1 (10% Safety Factor)					
Total Battery Amp Hour Requirement —					

^{*} FM MINIMUM REQUIREMENT FOR DELUGE SYSTEMS IS 90 HOURS STANDBY TIME AND 10 MINUTES ALARM TIME.

Shield Grounding

Two shield ground terminals are provided inside the junction box of each device, and also at the System Controller. Connect shield ends to the terminals provided (not to each other) inside the junction box.

⚠ CAUTION!

Insulate the shields to prevent shorting to the device housing or to any other conductor.

Junction Box Grounding

All junction boxes must be electrically connected to earth ground.

Response Time vs. System Size

When designing a system, it is important to realize that by increasing the number of nodes (devices) on the communication loop, the amount of time required for a status change message from a detection device to reach the System Controller also increases.

The System Controller requires a specific length of time to process each bit of information that is transferred along the communication loop. As the number of nodes increases, so does the amount of data being processed as well as the time required for processing by the Controller.

If the fastest possible communication response time is an important criteria for a large system, it is recommended that the number of nodes on an individual loop be kept as small as possible. Consider using multiple controllers with fewer nodes per loop.

^{*} FM MINIMUM REQUIREMENT FOR EXTINGUISHING SYSTEMS IS 24 HOURS STANDBY TIME AND 5 MINUTES ALARM TIME.

Moisture Damage Protection

Moisture can adversely affect the performance of electronic devices. It is important to take proper precautions during system installation to ensure that moisture will not come in contact with electrical connections or components.

In applications where the network wiring is installed in conduit, the use of watertight conduit seals, drains, breathers, or equivalent is recommended to prevent damage caused by condensation within the conduit.

Electrostatic Discharge

An electrostatic charge can build up on the skin and discharge when an object is touched. ALWAYS use caution when handling devices, taking care not to touch the terminals or electronic components.

⚠CAUTION!

ALWAYS discharge static charges from hands before handling electronic devices or touching device terminals. Many devices contain semiconductors that are susceptible to damage by electrostatic discharge.

NOTE

For more information on proper handling, refer to Det-Tronics Service Memo form 75-1005.

GROUND FAULT MONITOR (GFM) INSTALLATION


Mounting

The GFM is a DIN rail mountable device designed to be mounted in the same enclosure as the EQP controller.

Wiring

- 1. Connect power wiring from the EQP controller power terminals 1 and 2 to the GFM terminals 1 and 2.
- 2. Connect power wiring from the GFM terminals 3 and 4 to the EQP controller power terminals 3 and 4.
- 3. Connect earth ground to terminal 5 or 10.
- 4. Connect the relay contacts as required.

Refer to Figure 3-1 for terminal block identification.



NOTE: RELAY CONTACTS ARE SHOWN IN THE REST STATE, NO POWER APPLIED. RELAY IS ENERGIZED WITH POWER APPLIED AND NO GROUND FAULT (TERMINALS 6 & 7 CLOSE, TERMINALS 6 & 8 OPEN).

Figure 3-1—Terminal Configuration for Ground Fault Monitor

NETWORK AND NETWORK EXTENDER INSTALLATION

Mounting

The device should be securely mounted to a vibration free surface. (See the "Specifications" section in this manual for device dimensions.)

Wiring

All devices on the LON are wired in a loop that starts and ends at the System Controller. To ensure proper operation, the LON should be wired using high speed communication grade cable.

NOTE

Cable meeting the specifications listed in Table 3-6 is suitable for distances up to 2000 meters.

Any of the cable types listed in Table 3-7 can be used for wiring the LON for the distances indicated.

NOTE

If no network extenders are used, the distances listed are for the entire loop. If network extenders are used, the distances listed are for the wiring length between network extenders or between a network extender and the System Controller.

Table 3-7—LON Maximum Cable Lengths

LON Cable	Maximum Length**			
(Manufacturer and Part No.)*	Feet	Meters		
Belden 8719	6,500	2,000		
Belden 3073F (Tray Rated)	6,500	2,000		
Det-Tronics NPLFP	6,500	2,000		
Technor BFOU	4,900	1,500		

Note: *Use the same type of cable in each wiring segment between network extenders.

**Maximum wire lengths represent the linear wire distance of LON communications wiring between network extenders.

Be sure that selected cable meets all job specifications. If necessary, consult factory for further suggested cable types.

Table 3-6—Specifications for LON Wiring Cable

		Minimum	Typical	Maximum	Units	Condition
DC Resistance, each conductor		14	14.7	15.5	ohm/km	20 C per ASTM D 4566
DC Resistance Unbalanced				5%		20 C per ASTM D 4566
Mutual Capacitance				55.9	nF/km	per ASTM D 4566
Characteristic Impeda	ance	92	100	108	ohm	64 kHz to 1 MHz, per ASTM D 4566
Attenuation	20 kHz			1.3	dB/km	20 C per ASTM D 4566
	64 kHz			1.9		
	78 kHz			2.2		
	156 kHz			3		
	256 kHz			4.8		
	512 kHz			8.1		
	772 kHz			11.3		
	1000 kHz			13.7		
Propagation Delay	_			5.6	nsec/m	78 kHz

Length: 6,500 feet/2000 meters maximum (basic loop or between Network Extenders).

Type: Single twisted pair.

Wire Gauge: 16 AWG, stranded (19 x 29), tinned copper with overall shield.

Cables meeting these specifications are good for up to 2000 meters.

T0049B

⚠IMPORTANT!

Det-Tronics recommends the use of shielded cable (required by CENELEC) to prevent external electromagnetic interference from affecting field devices.

△IMPORTANT!

Be sure that the selected cable meets the specifications. The use of other cable types can degrade system operation. If necessary, consult factory for further suggested cable types.

- 1. Remove the cover from the Network Extender enclosure.
- 2. Connect 24 vdc power lead wires and communication network cable to the terminal block. (See Figure 3-2 for terminal location and Figure 3-3 for terminal identification).

See Table 3-8 to determine maximum wiring length.

- COM 1 Communication network connections: Connect to COM 2 terminals of the next device on the loop, A to A and B to B.
- COM 2 Communication network connections: Connect to COM 1 terminals of the previous device on the loop, A to A and B to B.
- 24 VDC Connect the "+" terminal to the positive side of the 24 vdc power source. (Both "+" terminals are connected internally.)

Connect the "-" terminal to the negative side of the 24 vdc power source. (Both "-" terminals are connected internally.)

Table 3-8—Maximum Wiring Length from Nominal 24 vdc Power Source to Network Extender (Maximum wire lengths are based upon the cable's physical and electrical characteristics.)

Wire Size	Maximum Wiring Distance			
VVII e Size	Feet	Meters		
18 AWG (1.0 mm ²)*	2200	650		
16 AWG (1.5 mm ²)*	3500	750		
14 AWG (2.5 mm ²)*	5600	1700		

^{*} Approximate Metric Equivalent.

3. Connect shields to the designated "shield" terminals. The two shield terminals are connected internally to ensure shield continuity.

CAUTION!

Do not ground either shield at the network extender enclosure. Insulate the shields to prevent shorting to the device housing or to any other conductor.

- 4. Check ALL wiring to ensure that proper connections have been made.
- 5. Inspect the junction box O-ring to be sure that it is in good condition.
- 6. Lubricate the O-ring and the threads of the junction box cover with a thin coat of grease to ease installation and ensure a watertight enclosure.

NOTE

The recommended lubricant is a silicone free grease, available from Det-Tronics.

7. Place the cover on the enclosure. Tighten only until snug. **Do not over tighten.**




Figure 3-2—Network Extender Wiring Terminal Location




Figure 3-3—Network Extender Wiring Terminal Identification

INITIATING DEVICE CIRCUIT (IDC) INSTALLATION

EQ22xxIDC SERIES INITIATING DEVICE CIRCUIT (IDC)

The following paragraphs describe how to properly install the EQ22xxIDC Initiating Device Circuit.

Mounting

The device should be securely mounted to a vibration free surface. (See "Specifications" in this manual for device dimensions.)

MWARNING!

The hazardous area must be de-classified prior to removing a junction box cover with power applied.




Figure 3-4—IDC Terminal Wiring Board Mounted in Six-Port Junction Box

Wiring

- 1. Remove the cover from the device junction box.
- 2. Connect external system wiring to the appropriate terminals on the terminal block. (See Figure 3-4 for terminal block location and Figure 3-5 for terminal identification). The input to the IDC consists of one or more normally open switches (momentary pushbuttons are not recommended), with a 10K ohm, 1/4 watt EOL resistor in parallel across the furthest switch from the input.

MIMPORTANT!

An EOL resistor must be installed on both IDC inputs (including unused inputs). Wiring impedance must not exceed 500 ohms.

3. Check wiring to ensure that ALL connections have been properly made.

△IMPORTANT!

Be sure that the keyed ribbon cable is properly connected to the terminal board.

- 4. Inspect the junction box O-ring to be sure that it is in good condition.
- 5. Lubricate the O-ring and the threads of the junction box cover with a thin coat of grease to ease installation and ensure a watertight enclosure.

NOTE

The recommended lubricant is a silicone free grease, available from Det-Tronics.

- 6. Set the node address for the device. (See "Setting Device Network Addresses" in this section.)
- 7. Place the cover on the junction box and tighten only until snug. DO NOT over tighten.




Figure 3-5—Terminal Configuration for IDC

EQ22xxIDCGF SERIES INITIATING DEVICE CIRCUIT GROUND FAULT

The following paragraphs describe how to properly install and configure the EQ22xxIDCGF Initiating Device Circuit Ground Fault.

Mounting

The device should be securely mounted to a vibration free surface. (See "Specifications" in this manual for device dimensions.)

Wiring


MWARNING!

The enclosure must be electrically connected to earth ground.

- 1. Remove the enclosure cover from the device.
- Remove the communication module from the junction box. Connect external wiring to the appropriate points on the device terminal block. (See Figure 3-4 for terminal block location and Figure 3-6 for terminal identification)
- 3. Check wiring to ensure that ALL connections have been properly made.
- 4. Inspect the enclosure O-ring to be sure that it is in good condition. Lubricate the O-ring and the threads of the enclosure cover to ease both installation and future removal of the cover.

NOTE

The recommended lubricant is a silicone free grease available from Detector Electronics.



NOTE: ENCLOSURE AND/OR MOUNTING BRACKET
MUST BE CONNECTED TO EARTH GROUND.

Figure 3-6—Terminal Configuration for IDCGF



If the installation uses catalytic type combustible gas sensors, it is imperative that lubricants containing silicone not be used, since they will cause irreversible damage to the sensor.

Install the communication module in the device enclosure.

NOTE

Be sure the ribbon cable is properly connected.

Set the node address for the device. (See "Setting Device Network Addresses" in this section)

When configuring the EQ22xxIDCGF, its "device type" should be configured as an initiating device circuit (IDC).

Both inputs must be configured for a trouble condition.

- Circuit 1 "Open" indicates a –24 VDC ground fault condition. "Active" indicates a +24 VDC ground fault condition.
- Circuit 2 "Active" indicates a loss of AC input power.
 "Open" indicates a loss of battery

power.

7. Place the cover on the enclosure and tighten until snug. DO NOT over tighten.

EQ22xxIDCSC SERIES INITIATING DEVICE CIRCUIT SHORT CIRCUIT (Not FM Approved)

The following paragraphs describe how to properly install and configure the EQ22xxIDCSC Initiating Device Circuit Short Circuit.

Mounting

The device should be securely mounted to a vibration free surface. (See "Specifications" in this manual for device dimensions.

Wiring

△ CAUTION!

The enclosure should be electrically connected to earth ground.

- 1. Remove the cover from the device enclosure.
- 2. Remove the communication module from the junction box. Connect external wiring to the appropriate terminals on device terminal block. (See Figure 3-4 for terminal block location and Figure 3-7 for terminal identification.) The input to the IDCSC consists of a normally open switch with a 3.3k ohm series resistor, and a 10K ohm, 1/4 watt EOL resistor in parallel across the switch.

NOTE

An EOL resistor must be installed on both IDCSC inputs (including unused inputs). Wiring impedance must not exceed 500 ohms. A 3.3K ohm resistor must be installed in series with the switch. For correct operation, only one switch per input can be connected.

- 3. Check wiring to ensure that ALL connections have been properly made.
- 4. Install the communication module in the device enclosure.
- 5. Inspect the enclosure O-ring to be sure that it is in good condition. Lubricate the O-ring and the threads of the enclosure cover to ease both installation and future removal of the cover.

NOTE

The recommended lubricant is a silicone free grease available from Detector Electronics.

NOTE

Be sure the ribbon cable is properly connected.

- 6. Set the node address for the device. (See "Setting Device Network Addresses" in this section.)
- 7. Place the cover on the enclosure and tighten until snug. Do not over tighten.




Figure 3-7—IDCSC Terminal Identification

EQ300X CONTROLLER INSTALLATION

The following paragraphs describe how to properly install and configure the EQ300X Controller.

ENCLOSURE REQUIREMENTS

The Controller must be properly installed in a suitable enclosure that is rated for the location. The enclosure must provide space to install and wire the Controller and must also provide for ground wire termination. The enclosure must contain either a keyed lock or a special tool to gain access into the enclosure. The enclosure should be rated for the temperature range of the location plus the temperature rise of all equipment installed inside the enclosure. The enclosure must be rated for electrical equipment that is going to be installed.

NOTE

The Controller and enclosure must be connected to earth ground.

For ordinary locations when entry is required to operate the equipment, the cabinet should be a dead-front construction and 16-gauge cold-rolled steel. The door lock system shall accept different keys for entry. An Authorized Persons key and a Person-in-charge key will allow entry into the cabinet. The cabinet should contain a window to view the Controller's text display and LED indicators.

NOTE

For any selected enclosure, the enclosure must conform to all applicable regulations and requirements.

NOTE

The Trouble signal must be located in an area where it is likely to be heard.

Classified locations require the appropriate hazardous rated enclosure. It is recommended that operators/switches be installed in the enclosure. This avoids the need to declassify the area in order to operate the Controller. Regulations require that key switches be installed for certain operations. An appropriate window should be part of the enclosure in order to allow an operator to view the text display and LED indicators.

NOTE

If an enclosure does not have a keyed entry, a special tool is required to gain entry into an enclosure.

Det-Tronics offers several approved (FM/CSA/CENELEC/CE) hazardous area enclosures that have Eagle Quantum Premier equipment installed in the enclosure. Contact Det-Tronics for further information.

MOUNTING

The Controller is designed for direct panel mounting or DIN rail (optional) mounting. See "Specifications" section of this manual for mounting dimensions.

NOTE

Clips for DIN rail mounting are available, but must be specified at the time of ordering.

NOTE

A minimum clearance of 4 inches between the Controller and nearby equipment is required to provide room for wiring and ventilation.

SERIAL INTERFACE BOARD

An optional Serial Interface Board is available for the EQP Controller. See Figures 3-8 and 3-9 for details on the electrical connections.

WIRING

Power Wiring

CAUTION!

Input voltage at the Controller must be 18 vdc minimum to ensure proper operation.

It is important to consider both the wire gauge and the distance from the Controller to the power supply. As the distance between the Controller and the power supply increases, so must the diameter of the power wiring in order to maintain a minimum of 18 vdc at the Controller.

⚠IMPORTANT!

To ensure proper operation of devices, the voltage input to the device (measured at the device) must be within the range indicated for that device in the "Specifications" section of this manual.

Electrical Connections

Figure 3-8 shows the location of wiring connectors on the Controller module. Figure 3-9 identifies individual terminals.

Connector P1, Terminals 1 to 4 — 24 vdc Input Power

Connect the power supply to terminals 1 and 2 of the Controller. Terminals 3 and 4 must also be connected to power.

Two power cables are recommended so that if one is lost, the controller will continue to operate and signal a trouble condition.

Shields on power cables must be connected to chassis ground (earth).




Figure 3-8—Location of Wiring Terminals on EQP Controller




Figure 3-9—EQP Controller Terminal Identification




Figure 3-10—Unsupervised Input Wiring




Figure 3-11—Unsupervised Relay Output

Connector P2, Terminals 5 to 12 — Unsupervised Digital Input Channels 1 to 4

Connector P3, Terminals 13 to 20 — Unsupervised Digital Input Channels 5 to 8

See Figure 3-10 for example. Only channel 1 is shown in Figure 3-10. The information is typical for channels 2-8.

Connector P4, Terminals 21 to 32 — Unsupervised Relay Output Channels 1 to 4

Connector P5, Terminals 33 to 44 — Unsupervised Relay Output Channels 5 to 8

See Figure 3-11 for example. Only channel 1 is shown in Figure 3-11. The information is typical for channels 2-8.

NOTE

Channel software configurations include all panel indicator functions to automatically mimic the controller front panel indicators.

Connector P6, Terminals 45, 46 & 47 — Trouble Relay

The Trouble relay is not configurable. In the normal condition, the relay coil is energized, closing the N.O. contact (terminals 45-46) and opening the N.C. contact (terminals 45-47). The relay coil is deenergized in the trouble condition.

Connector P7, Terminals 48 to 53 — LON Signaling Line Circuit Terminals

The LON loop is wired so that the controller's LON COM 1 is connected to the field device's COM 2 connection. The field device's COM 1 is wired to the next device's COM 2 connection. This continues through the last field device on the loop. The last field device's COM 1 is then wired back to the Controller's COM 2 connection. LON A and B polarities must be maintained throughout the loop (i.e., always wire A to A and B to B between the devices).

Port Pinout (6-position connection terminal block)

48 — COM 1 shield connection

49 — "B" side of signaling circuit for COM 1

50 — "A" side of signaling circuit for COM 1

51 — COM 2 shield connection

52 — "B" side of signaling circuit for COM 2

53 — "A" side of signaling circuit for COM 2

NOTE

Refer to Figure 3-12 for location of termination jumpers.

Jumper P25 – LON COM 1 Termination

- 1-2 COM 1 Terminated (factory setting)
- 2-3 COM 1 Unterminated (Redundancy)

Jumper P26 - LON COM 2 Termination

- 1-2 COM 2 Terminated (factory setting)
- 2-3 COM 2 Unterminated (Redundancy)

Connector P8, Terminals 54, 55 & 56 , Port 1—RS- 485 Modbus RTU Master/Slave

Configuration data downloaded into the controller configures the serial interface transmission baud rate, parity check for the serial port, and Modbus device address. Software selectable baud rates are 2400, 4800, 9600,19200, 38400, 57600, and 115200. Software selectable parity is None, Odd, and Even. The controller uses 8 data bits with 1 stop bit.

Port Pinout (3-position terminal block)

54 — GND

55 - B

56 — A

Jumper P27 – RS-485 Termination Jumper

- 1-2 Unterminated
- 2-3 Terminated 121 ohms (factory setting)
 Transceiver input impedance: 68 kohm

Connector P9, Terminals 57, 58 & 59 — RS-232 Serial Interface or S3 Configuration Port

Configuration data downloaded into the controller configures the serial interface transmission baud rate and parity check for the serial port. Software selectable baud rates are 2400, 4800, 9600,19200, 38400, 57600, and 115200 (factory default is 115200). Software selectable parity is None, Odd, and Even. The controller uses 8 data bits with 1 stop bit.

Port Pinout (3-position terminal block)

57 — GND

58 — RXD

59 — TXD

Connector P10, Terminals 60, 61 & 62, Port 2—RS-485 Modbus RTU Master/Slave

Configuration data downloaded into the controller configures the serial interface transmission baud rate,




Figure 3-12—Location of Termination Jumpers, Communication Indicator LEDs and Communication Ports

parity check for the serial port, and Modbus device address. Software selectable baud rates are 9600,19200, 38400, 57600, 115200 and 230400. Software selectable parity is None, Odd, and Even. The controller uses 8 data bits with 1 stop bit.

Port Pinout (3-position terminal block)

60 — A

61 — B

62 — GND

Jumper P28 – RS-485 Termination Jumper

- 1-2 Terminated 121 ohms (factory setting)
- 2-3 Unterminated

Transceiver input impedance: 68 kohm

Jumper P29 - RS-485 Ground Fault Monitor

- 1-2 Enabled
- 2-3 Disabled (factory setting)




Figure 3-13—Controller to Controller Communication with Signaling Line Circuit Classification per NFPA 72

Use Port 2 to pass safety critical information between controllers. User logic can pass all alarm, trouble, and supervisory information between the controllers. Watchdog timers must be implemented in user logic to verify the integrity of the SLC. Consult the local authority having jurisdiction for annunciation requirements.

Controller to Controller Communication with Signaling Line Circuit Classification B4, Class B, Style 4 per NFPA 72

To connect up to three controllers together and be able to transfer safety information between the controllers, the communication link must be classified as a signaling line circuit per NFPA 72. With the serial board option, Port 2 (plug 10) is a RS-485 serial connection that is ground fault monitored.

To meet the signaling line circuit (Class B Style 4) requirements, the following must be configured for correct operation:

 All controllers must have the optional serial board installed.

- The Termination jumper P28 must be set to Terminate (position 1-2) on all controllers.
- The Ground Fault Monitor jumper P29 must be set to Enabled (position 1-2) on all controllers.
- Connect terminals A (terminal number 60) and B (terminal number 61) between the controllers. The GND (terminal number 62) must not be connected.

See Figure 3-13 for wiring details.

Controller to Controller with Fiber Optic Link, Signal Line Circuit Classification Class B per NFPA 72.

Up to three EQP controllers (single or redundant pair) can be inter-connected via a fiber optic link. This communication link is classified as a signaling line circuit per NFPA 72 to allow safety information to be transferred between controllers.

Table 3-9—Approved Supported Converters for Fiber Optic Link

Manufacturer	Model Number	Description
Moxa (www.moxa.com)	TCF-142-S	RS-485 to Single-mode Fiber Optical Converter

The fiber optic link incorporates a converter to convert from RS-485 to single mode fiber. The approved supported converters are shown in Table 3-9. The link budget for the listed fiber optic converters is 10dB.

The fiber converter can be connected to either of the EQP controller RS-485 communication ports (Port 1 or Port 2). Figure 3-14 illustrates the wiring connection between two EQP controllers in a redundant configuration using Port 1. Note: If Port 2 is preferred, the optional serial board must be purchased.

WARNING

The fiber converters must be mounted inside the same enclosure as the controllers to conform to NFPA 72.

The fiber optic cable used for this approved link must be in conformance with IEC 60793-2:2003 (Class B1.3 for single mode fibers) and International Telecommunication Union recommendation ITU G.652 (Categories A, B, C & D). The maximum distance of a particular optic link given the optical budget is calculated as:

where link loss includes number of end connectors, splices and safety margin.

Example: 10 db link budget

Cable Attenuation: 0.4 db / km

2 connectors: (1 each end) with 0.5 db ea.

Safety margin: 3.0 db max

Max. Distance =
$$\frac{10 - (2 \times 0.5) - 3.0}{0.4}$$
 = 15 km

For more information regarding selection and installation of fiber optic media, please contact Det-Tronics customer service.

Connector P11, Terminals 63, 64 & 65, Port 3—RS-232 Modbus RTU Master/Slave or S3 Configuration Port

Configuration data downloaded into the controller configures the serial interface transmission baud rate, parity check and MODBUS device address for the serial port. Software selectable baud rates are 9600,19200, 38400, 57600, 115200, and 230400. Software selectable parity is None, Odd, and Even. The controller uses 8 data bits with 1 stop bit.

Port Pinout (3-position terminal block)

63 — TXD

64 — RXD

65 — GND




Figure 3-14—Controller to Controller NFPA 72 Approved Fiber Optic Link

Connector P12, Terminals 66, 67 & 68, Port 4—RS-232 Modbus RTU Master/Slave

Configuration data downloaded into the controller configures the serial interface transmission baud rate, parity check and MODBUS device address for the serial port. Software selectable baud rates are 9600,19200, 38400, 57600, 115200, and 230400. Software selectable parity is None, Odd, and Even. The controller uses 8 data bits with 1 stop bit.

Port Pinout (3-position terminal block)

66 — TXD

67 — RXD

68 — GND

Connector P13 — RS-232 High Speed Serial Port

This port is dedicated to inter-controller connection required for redundancy, and is not available for any other use. This port is automatically configured.

CONFIGURATION

Software Defined Addresses

Det-Tronics Safety System Software (S3) is programmed with the addresses that are assigned to the controller when the configuration file is downloaded into the controller. Addresses define and configure the Controller's LON address, Modbus slave address, and the ControlNet option board address.

EQ300X REDUNDANT CONTROLLER INSTALLATION

The redundant controllers must be purchased with the following options for correct installation:


- Serial board
- High-speed serial cable
- LON termination modules (2).

ENCLOSURE REQUIREMENTS

The redundant controllers must be located next to each other in the same enclosure (4 ft. interconnecting cable).

MOUNTING

The controllers are designed for direct panel mounting or DIN rail mounting. See "Specifications" section of this manual for mounting dimensions.



NOTE: LON TERMINATION JUMPERS P25 AND P26 (SEE FIGURE 3-12) MUST BE IN POSITION 2 AND 3 FOR REDUNDANT CONFIGURATION (ON BOTH CONTROLLERS).

Figure 3-15— LON Connection for Redundant EQP Controllers

WIRING

The redundant controllers are wired the same as a simplex controller except for the LON wiring and the dedicated high-speed serial link, which are defined below. Refer to EQ300X Controller Installation for general installation details.

LON WIRING

The LON must be connected to both redundant controllers to ensure correct operation. Two LON Termination Modules are required for the installation as shown in Figure 3-15.

HIGH SPEED SERIAL LINK (HSSL)

The redundant controllers are connected together by a dedicated high-speed serial link. This link is a prefabricated cable that has a custom connector for ease of use. Redundant controllers are automatically addressed with the HSSL cable. One end of the cable is labeled Primary. The primary controller takes address 1, while the secondary controller is address 2. The significance this has for the user is that the primary is the default master when both controllers are powered-up at the same time.

CONFIGURATION

S3 Configuration

The S3 configuration software is used to configure the redundant controllers. A check box on the controller configuration screen must be enabled and downloaded to the controllers.

△IMPORTANT

If the controllers have not been configured for redundancy via the S3 configuration software, redundancy will not function.

Controller Addresses

The LON addresses are pre-determined and cannot be adjusted. Address 1 and 2 have been reserved for a redundant controller configuration.

Modbus

Modbus ports on each controller share the serial settings including baud rate and address. Controllers in standby mode don't respond to or issue Modbus messages. This allows for transparent switching on a multi-drop network. If RS-232 is used, a relay switching mechanism can be used.

ControlNet

The ControlNet interface on each controller will have different addresses. This allows both controllers to reside on the same ControlNet network at the same time. The primary controller uses the configured address while the standby assumes an address 1 higher than the primary controller. Application logic in the attached PLC must be used to determine which controller has the correct output information. Information coming from the PLC should be written to both Premier Controllers.

POWER SUPPLY AND POWER SUPPLY MONITOR INSTALLATION

△WARNING!

ALWAYS follow all safety notes and instructions when installing power supply or batteries!

△WARNING!

Make sure a.c. power is OFF at main a.c. breaker before beginning power supply installation!

MIMPORTANT!

Power supplies require unrestricted air flow for proper cooling.

MOUNTING

Mount the power supply monitor in a Nationally Recognized Test Laboratory (NRTL) labeled enclosure. Refer to the "Specifications" section for mounting dimensions.

WIRING

△ CAUTION!

The power supply should be properly connected to an earth ground! A ground wire MUST be connected to the power supply units's case ground!

NOTE

The Power Supply Monitor uses two of the four DIP switches to select an appropriate fault level for the installation. See Figure 3-16. The unit will fault when the batteries source a current level higher than the threshold for 20 seconds. The fault will clear when the current drops to half the level for 20 seconds. The current level selection is based on the minimum current draw of the attached equipment. The selected value must be less than the actual minimum current draw for the system.

- 1. Verify that the input source is the same voltage and frequency as that marked on the nameplate of the power supply.
- 2. Verify that transformer taps are set for the correct a.c. input. (Input tap setting is located inside the power supply enclosure.)
- 3. Verify that the supply power wire size and fusing are adequate for the current indicated on the power supply nameplate.

NOTE

Consult the power supply manufacturer's instruction manual provided with the support documentation received with the Eagle Quantum System.

NOTE

Required Overload Current is usually equal to 15% of the nominal rating.




Figure 3-16—Power Supply Monitor Terminal and Switch Location




Figure 3-17—J1: Power and LON Wiring Terminal




Figure 3-19— Wiring Connections for a Power Supply Monitor, Power Supply and Backup Batteries

- 4. Connect external wiring to the appropriate points on Power Supply. Refer to Figure 3-16 for terminal block locations and Figures 3-17 and 3-18 for terminal identification. Connect the 24 vdc power wires and the LON network cable to the appropriate points on J1. (Redundant "+", "-" and shield terminals are connected internally.) Do not ground any shield at the monitor / power distribution cabinet. Insulate the shields to prevent shorting to the device housing or to any other conductor.
- Connect a two wire cable between the AC input of the power supply and terminals 1 and 4 on J3, the AC input terminal block on the power supply monitor. See Figure 3-18.
- 6. Connect the "B" terminal on the power supply monitor to the negative (-) side of the backup battery. Connect a correctly sized circuit breaker or disconnect switch in the battery circuit as shown in Figure 3-19. If a circuit breaker is used, it must be rated between 150% and 250% of the total load.
- Connect the "C" terminal on the power supply monitor to the negative (–) side of the power supply.

- 8. Wire the power distribution circuit breakers to the output of the power supply. Circuit breaker ratings must be between 150% and 250% of the full load rating.
- Set the device network address for the power supply monitor.

NOTE

For additional information, refer to the power supply manufacturer's instruction manual provided with the support documentation received with the Eagle Quantum Premier system.

STARTUP

Turn on the power supply and allow the voltage to stabilize at 27 volts before closing the circuit to the battery.

MEASURING BATTERY VOLTAGE AND CHARGING CURRENT

Measure the battery voltage at terminals 3 and 4 of terminal block J2. See Figure 3-20.




Figure 3-20—J2: Current Test Points

To measure the battery charging current, connect a digital voltmeter to terminals 1 and 2 of terminal block J2. The voltmeter will read 1 millivolt (0.001 volt) for each 2 amperes of current.

Current in Amperes = Meter reading in millivolts $\times 2$

Example: A reading of 50 millivolts indicates a charging current of 100 amperes.

ENHANCED DISCRETE INPUT/OUTPUT (EDIO) MODULE INSTALLATION

All electrical connections are made to the field wiring connectors furnished with the module. Refer to Figure 3-21 for identification of module wiring terminals.

Connector P1, Terminals 1 to 6 24 Vdc Power Input

Connect the module power supply to terminals 1 and 2. If additional terminals are required for powering other devices, these devices should be connected to terminals 4 and 5. Shields are to be connected to terminals 3 and 6 — chassis (earth) ground terminals. Terminals are rated for 10 amperes. Use both sets of input terminals in parallel if total output current can exceed 10 amperes.

Connector P2, Terminals 1 to 6 LON/SLC Signaling Circuit Terminals

Be sure to observe polarity when wiring the LON/SLC.

- 1 "A" side of signaling circuit for COM 1
- 2 "B" side of signaling circuit for COM 1
- 4 "A" side of signaling circuit for COM 2
- 5 "B" side of signaling circuit for COM 2
- 3, 6 shield connection

Connector P3, Terminals 1 to 12 Terminals A,B & C Channels 1 to 4 Input / Output Terminals

Refer to individual wiring configurations for terminal descriptions. Only channel 1 is shown in each diagram. The information is typical for channels 2-8.




Figure 3-21—EDIO Module Wiring Terminals

Connector P4, Terminals 13 to 24 Terminals A, B & C

Channels 5 to 8 Input / Output Terminals

Refer to individual wiring configurations for terminal descriptions. Only channel 1 is shown in each diagram. The information is typical for channels 2-8.

Unsupervised Input

Connect external system wiring to the appropriate terminals on the terminal block. See Figure 3-22.

The input to the EDIO consists of one or more normally open or normally closed switches. An EOL resistor is not required.

Make no connection to "+ Supply" terminal.

Supervised Input (IDC) Open Circuit Supervision

Connect external system wiring to the appropriate terminals on the terminal block. For Class B, Style B wiring, see Figure 3-23. For Class A, Style D wiring, see Figure 3-24. Note that two channels are used for one circuit.

The input to the EDIO module consists of one or more normally open switches, with a 10 K ohm, 1/4 watt EOL resistor in parallel across the last switch.

Make no connection to "+ Supply" terminal.

Supervised Input Open and Short Circuit Supervision

Connect external system wiring to the appropriate terminals on the terminal block. For Class B, Style C wiring, see Figure 3-25. For Class A, Style E wiring, see Figure 3-26. Note that two channels are used for one circuit.

The input to the EDIO module consists of normally open switches, with a 10 K ohm, 1/4 watt EOL resistor in parallel across the return channel, and a 3.3 K ohm, 1/4 watt resistor in series with each switch.

NOTE

If using more than one switch, the first active condition (switch closed) must be latched. Any subsequent closed switch will indicate a short circuit fault condition.

Make no connection to "+ Supply" terminal.

Input — Deluge and Pre-Action

The initiating device circuit(s) for use with the deluge and pre-action system configuration must use Class A wiring or be wired within 20 feet and in conduit from the EDIO.




Figure 3-22—Unsupervised Input Configuration




Figure 23—Supervised Input Configuration - Class B, Style B




Figure 3-24—Supervised Input Configuration - Class A, Style D




Figure 3-25—Supervised Input Configuration (Opens and Shorts) – Class B, Style C




Figure 3-26—Supervised Input Configuration (Opens and Shorts) – Class A, Style E

Two-Wire Smoke Detectors


The EDIO supports 2-wire devices from Kidde-Fenwal and Apollo. Figure 3-27 shows the wiring for Apollo detectors connected to EDIO Channel 1 through terminals 1 and 2.

Figure 3-28 shows the typical wiring for Kidde-Fenwal detectors connected to the EDIO through Channel 1 using terminals 1 and 2.

The EDIO supports either brand of detection products, however, mixing brands is not supported on either a single channel or module.

IMPORTANT

No more than 15 devices can be connected per channel.



Unsupervised Output

Connect external system wiring to the appropriate terminals on the terminal block. See Figure 3-29.

No connection should be made to "+ Supply" terminal.




Figure 3-29—Unsupervised Output Configuration

Supervised Output— Notification Supervised for Open & Short Circuits

Connect external system wiring to the appropriate terminals on the terminal block. For Class B, Style Y wiring, refer to Figure 3-30.

For Class A, Style Z wiring, refer to Figure 3-31. Note that two channels are used for one output circuit.

The output of the EDIO module supervises the notification circuit by reversing the polarity of the monitoring circuit. Polarity must be observed when connecting the notification device. It is essential to utilize a notification device approved for fire alarm notification. These devices are polarized and would not require the use of an external diode for the supervision of the circuit. Wire one or more notification devices to the output, with a 10 K ohm, 1/4 watt EOL resistor in parallel across the last device.

No connection should be made to "+ Supply" terminal.

Each output channel is individually activated for response pattern:

- supervisory
- continuous output
- 60 beats per minute
- 120 beats per minute
- temporal
- timed
- trouble.

Supervised Output— Agent Release

Connect external system wiring to the appropriate terminals on the terminal block. For Class B wiring, refer to Figure 3-32.

For Class A wiring, refer to Figure 3-33. Note that two channels are used for one output circuit. Trouble indication is provided for any open wire and the output can still be activated with a single open wire.

Wire one or more releasing devices to the module output.

No connection should be made to "+ Supply" terminal.

The output of the EDIO module supervises the releasing circuit via the coil of the releasing solenoid. It is essential to utilize a releasing device approved for use with this output module. This type of output does not require the use of EOL resistors or diodes to supervise the circuit.




Figure 3-30—Supervised Output Configuration (Notification)— Class B, Style Y




Figure 3-31—Supervised Output Configuration (Notification)— Class A, Style Z




Figure 3-32—Supervised Output Configuration (Agent Release)




Figure 3-33—Supervised Output Configuration (Agent Release)— Class A Wiring

The output can be configured for latching, continuous, supervisory, trouble or timed response.

To ensure adequate operating voltage for the output device, the maximum wiring length from the power source to the output device must not exceed the values shown in Table 3-10 for automatic release applications. (For solenoids, this wire length includes both the wiring from the power supply to the EDIO module and the wiring from the module to the solenoid.)

NOTE

Squibs are not compatible with this output. If squib actuation is required, use EQ2500ARM release module.

Supervised Output for Deluge and Pre-action

To ensure proper operating voltage, the input voltage to the EDIO must be in the range from 21 to 30 vdc and the maximum wiring length must not exceed the values shown in Table 3-11 for deluge and pre-action applications. Per FM Approval requirements, the secondary power must provide capacity for a 90 hour minimum standby operation followed by a minimum of 10 minutes of releasing and alarm operation. The initiating device circuit(s) for use with the deluge and pre-action system configuration must use Class A wiring or be wired in conduit within 20 feet from the EDIO.

Table 3-10—Maximum Wire Length for Releasing Applications

Device	Maximum Wire Length in Feet				
	12 AWG	14 AWG	16 AWG	18 AWG	
890181*	150	100	60		
899175*	150	100	60		
895630*	150	100	60		
897494*	190	120	75		
486500*	1500	1000	600	400	
31-199932-004*	150	100	60		
2 Amp Load	190	120	75		

^{*}Fenwal Solenoid

CONFIGURATION

Setting EDIO Network Address

One unique network address must be assigned to each EDIO module. The address is set by the 8 switch DIP assembly on the EDIO module.

When using the switches located on the EDIO module, the address is binary coded and is the sum of all switches placed in the "closed" position.

Each discrete point of an EDIO module has a tag number and a descriptor for unique identification.

Det-Tronics S³ Safety System Software is used for device configuration. The following shows the minimum software/firmware releases:

Controller Firmware		S3	
Revision	Version	Version	
В	4.28	3.1.0.0	

Table 3-11—Maximum Wiring Length for FM Approved Solenoids for Deluge and Pre-Action Applications

Solenoids			Maximui	m Wire Lengt	h in Feet (Me	eters)
FM Solenoid Group	M Solenoid Group Manufacturer Model		12 AWG	14 AWG	16 AWG	18 AWG
В	ASCO	T8210A107	183 (56)	115 (35)	72 (22)	46 (14)
D	ASCO	8210G207	314 (96)	198 (60)	124 (38)	78 (24)
E	Skinner	73218BN4UNLVNOC111C2	331 (101)	208 (63)	131 (40)	82 (25)
F	Skinner	73212BN4TNLVNOC322C2	130 (40)	82 (25)	51 (16)	32 (10)
G	Skinner	71395SN2ENJ1NOH111C2	331 (101)	208 (63)	131 (40)	82 (25)
Н	Viking	HV-274-0601	180 (55)	110 (34)	70 (21)	45(14)

8 CHANNEL DISCRETE INPUT / OUTPUT (DCIO) MODULE INSTALLATION

The following paragraphs describe how to properly install and configure the 8 Channel DCIO Module.

MOUNTING

The DCIO must be properly installed in a suitable enclosure that is rated for the location. The enclosure must provide space to install and wire the DCIO module and must also provide for ground wire termination. Access into the enclosure is gained by using a special tool to open the enclosure. The enclosure should be rated for the temperature range of the location plus the temperature rise of all equipment installed inside the enclosure. The enclosure must be rated for electrical equipment that is going to be installed.

The DCIO can be panel or DIN rail mounted.

NOTE

It is recommended to maintain a minimum of 4 inches clearance between the module and other equipment to provide adequate room for wiring and ventilation.

WIRING

All electrical connections are made to the field wiring connectors furnished with the module. See Figure 3-34 below for terminal identification.

Power Connector, Terminals 1 to 6 24 Vdc Power Input

Power connections to the DCIO depend upon the total current consumption of all the channels in the device. Each output-configured channel can consume up to 2 Amps. The power-input connection made through the terminal plug is rated to handle up to 10 Amps. If the total current draw is more than 10 Amps, power must be provided into the device using both power inputs. In this case, connect the power supply to terminals 1 and 2, and also to 4 and 5. Otherwise connect the power supply to terminals 1 and 2. Power wire shielding should be connected to terminals 3 and 6.

1 — +

2 — -

3 — Shield*

4 — +

5 — -

6 — Shield*

*Shields on power wires are optional unless required by local codes.

Connect the module power supply to terminals 1 and 2. If additional terminals are required for powering other devices, these devices should be connected to terminals 4 and 5. Shields are to be connected to terminals 3 and 6.

COM Connector, Terminals 1 to 6 LON Terminals

Be sure to observe polarity when wiring the LON.

1 — "A" side of signaling circuit for COM 1

2 — "B" side of signaling circuit for COM 1

4 — "A" side of signaling circuit for COM 2

5 — "B" side of signaling circuit for COM 2

3 & 6 — shield connections.




Figure 3-34—DCIO Module Wiring Terminal Configuration

Channel Connectors, Terminals 1 to 24 Terminals A, B & C Channels 1 to 8 Input / Output Terminals

Refer to individual wiring configurations for terminal descriptions. Only channel 1 is shown in each diagram. The information is typical for channels 2-8.

Unsupervised Input

Connect external system wiring to the appropriate terminals. See Figure 3-35.

Input to the DCIO consists of one or more normally open or normally closed switches.

NOTE

An EOL resistor is not required.

NOTE

No connection should be made to the "+ Supply" terminal.




Figure 3-35—Unsupervised Input Configuration




Figure 3-36—Supervised Input Configuration




Figure 3-38—Supervised Output Configuration (Notification)

NFPA - Class B, Style B Supervised Input (IDC) Open Circuit Supervision

Connect external system wiring to the appropriate terminals on the DCIO terminal block. See Figure 3-36.

The input to the DCIO module consists of one or more normally open switches, with a 10K ohm, 1/4 watt EOL resistor in parallel across the last switch.

NOTE

No connection should be made to the "+ Supply" terminal.

NFPA - Class B, Style C

(Three state – open, switch closure, and short) Supervised Input (IDCSC) Open and Short Circuit Supervision

Connect external wiring to the appropriate terminals on the DCIO terminal block. See Figure 3-37.

The input to the DCIO module consists of a normally open switch, with a 10 K ohm, 1/4 watt EOL resistor in parallel across the switch, and a 3.3 K ohm, 1/4 watt resistor in series with the switch.

NOTE

No connection should be made to the "+ Supply" terminal. For correct operation, only one input switch can be used per channel.




Figure 3-37—Supervised Input Configuration (Opens and Shorts)

NFPA - Class B, Style Y Supervised Output Notification (Horns and Strobes) Supervised Outputs for Open & Short Circuits

Connect external wiring to the appropriate terminals on the DCIO terminal block. See Figure 3-38.

The output of the DCIO module supervises the notification circuit by reversing the polarity of the monitoring circuit.

NOTE

Polarity MUST be observed when connecting the notification device.

It is critical to use a notification device approved for fire alarm notification. These devices are polarized and do not require the use of an external diode for the supervision of the circuit. Wire one or more notification devices to the output, with a 10 K ohm, 1/4 watt EOL resistor in parallel across the last device.

NOTE

No connection should be made to the "+ Supply" terminal.

Each output channel is individually activated for response pattern:

- continuous output
- 60 beats per minute
- 120 beats per minute
- temporal
- supervisory
- timed
- trouble.

Supervised Output for Automatic Release Supervised Output for Open Circuits

Connect external wiring to the appropriate terminals on the DCIO terminal block. See Figure 3-39.

Wire one or more releasing devices to the module output.

NOTE

Make no connection to the "+ Supply" terminal.

The output of the DCIO module supervises the releasing circuit via the coil of the releasing solenoid. It is essential to use a releasing device approved for use with this output module.

NOTE

This type of output does not require the use of EOL resistors or diodes to supervise the circuit.

The output can be configured for latching, continuous or timed response.

To ensure proper operating voltage, the maximum wiring length from the power source to the DCIO module must not exceed the values shown in Table 3-12 for automatic release applications.

NOTE

For solenoids, this wire length includes both the wiring from the power supply to the DCIO module and the wiring from the module to the solenoid.

NOTE

Squibs are not compatible with this output.




Figure 3-39—Supervised Output Configuration (Automatic Release)

Supervised Output for Deluge and Pre-action

Connect external wiring to the appropriate terminals on the DCIO terminal block. See Figure 3-39. Wire one or more releasing devices to the module output.

The output of the DCIO module supervises the releasing circuit via the coil of the releasing solenoid. It is essential to use a releasing device approved for use with this output module.

NOTE

This type of output does not require the use of EOL resistors or diodes to supervise the circuit.

NOTE

For new or retrofit installations, any manufacturer's non-water based agent release valves can be wired into the outputs of the ARM or DCIO modules as long as the devices utilize 24 vdc and do not exceed 2 amperes current draw.

NOTE

For FM system approval listing, pre-action and deluge applications require that only FM approved deluge valves can be wired into the ARM or DCIO modules. Table 3-13 lists the supported solenoid groups. Remember that the valves must utilize 24 vdc and must not exceed 2 amperes current draw.

The output can be configured for latching, continuous or timed response.

Table 3-12—Maximum Wire Length for Automatic Releasing Applications

Device	Maximum Wire Length in Feet			
	12 AWG	14 AWG	16 AWG	18 AWG
890181*	150	100	60	
899175*	150	100	60	
895630*	150	100	60	
897494*	190	120	75	
486500*	1500	1000	600	400
31-199932-004*	150	100	60	
2 Amp Load	190	120	75	

^{*}Fenwal Solenoid

Table 3-13—Maximum Wire Length for FM Approved Solenoids for Deluge and Pre-Action Applications

Solenoids			Maximui	m Wire Lengt	h in Feet (Me	eters)
FM Solenoid Group	FM Solenoid Group Manufacturer Model		12 AWG	14 AWG	16 AWG	18 AWG
В	ASCO	T8210A107	183 (56)	115 (35)	72 (22)	46 (14)
D	ASCO	8210G207	314 (96)	198 (60)	124 (38)	78 (24)
E	Skinner	73218BN4UNLVNOC111C2	331 (101)	208 (63)	131 (40)	82 (25)
F	Skinner	73212BN4TNLVNOC322C2	130 (40)	82 (25)	51 (16)	32 (10)
G	Skinner	71395SN2ENJ1NOH111C2	331 (101)	208 (63)	131 (40)	82 (25)
Н	Viking	HV-274-0601	180 (55)	110 (34)	70 (21)	45(14)

To ensure proper operating voltage, the input voltage to the DCIO must be in the range from 21 to 30 vdc and the maximum wiring length must not exceed the values shown in Table 3-13 for deluge and pre-action applications. Per FM Approval requirements, the secondary power must provide capacity for a 90 hour minimum standby operation followed by a minimum of 10 minutes of releasing and alarm operation. For initiating device circuit(s) for use with the deluge and pre-action system configuration, an Enhanced Discrete Input/Output Module (EDIO) must be used.

Unsupervised Output Ancillary Applications (Unrelated to Fire Detection/Protection)

Connect external wiring to the appropriate terminals on the DCIO terminal block. See Figure 3-40.

NOTE

No connection should be made to the "+ Supply" terminal.

CONFIGURATION

Setting DCIO Network Address

One unique network address must be assigned to each DCIO module. The address is set by the 8 switch DIP assembly on the DCIO module. The address is binary coded and is the sum of all switches placed in the "closed" position.

Each discrete point of a DCIO module has a tag number and a descriptor for unique identification.

Det-Tronics S³ Safety System Software is used for device configuration. The following shows the minimum software/firmware releases:

Controller Firmware		S3
Revision	Version	Version
А	1.03	2.0.2.0

8 CHANNEL RELAY MODULE INSTALLATION

The following paragraphs describe how to properly install and configure the 8 Channel Relay Module.

MOUNTING

The Relay Module must be properly installed in a suitable enclosure that is rated for the location. The enclosure must provide space to install and wire the relay module and must also provide for ground wire termination. Access into the enclosure is gained by using a special tool to open the enclosure. The enclosure should be rated for the temperature range of the location plus the temperature rise of all equipment installed inside the enclosure. The enclosure must be rated for electrical equipment that is going to be installed. The device can be panel or DIN rail mounted.

NOTE

It is recommended to maintain a minimum of 4 inches clearance between the module and other equipment to provide adequate room for wiring and ventilation.

WIRING

All electrical connections are made to the field wiring connectors furnished with the module. See Figure 3-41 for terminal identification.




Figure 3-40—Unsupervised Output Configuration

Power Connector, Terminals 1 to 6 24 Vdc Power Input

1 — +

3 — Shield*

4 — +

5 — -

6 - Shield*

*Shields on power wires are optional unless required by local codes.

Connect the module power supply to terminals 1 and 2. If additional terminals are required for powering other devices, these devices should be connected to terminals 4 and 5. Shields are to be connected to terminals 3 and 6.

COM Connector, Terminals 1 to 6 LON Terminals

Be sure to observe polarity when wiring the LON.

1 — "A" side of signaling circuit for COM 1

2 — "B" side of signaling circuit for COM 1

4 — "A" side of signaling circuit for COM 2

5 — "B" side of signaling circuit for COM 2

3 & 6 — shield connections.

Channel Connectors, Terminals 1 to 24

Unsupervised Output Ancillary Applications (Unrelated to Fire Detection/Protection)

Connect external wiring to the appropriate terminals on the relay module terminal block. See Figure 3-41.

CONFIGURATION


Setting Relay Module Network Address

One unique network address must be assigned to each relay module. The address is set by the 8 switch DIP assembly on the relay module. The address is binary coded and is the sum of all switches placed in the "closed" position.

Each discrete point of a relay module has a tag number and a descriptor for unique identification.

Det-Tronics S³ Safety System Software is used for device configuration. The following shows the minimum software/firmware releases:

Controller Firmware		S3	
Revision	Version	Version	
А	2.01	2.8.0.0	



NOTE: RELAY CONTACTS SHOWN IN REST (DE-ENERGIZED) STATE

Figure 3-41— Relay Module Wiring Terminal Configuration

ANALOG INPUT MODULE INSTALLATION

MOUNTING

The Analog Input Module must be properly installed in a suitable enclosure that is rated for the location. The enclosure must provide space to install and wire the device and must also provide for ground wire termination. Access into the enclosure must be gained by using a special tool to open the enclosure. The enclosure should be rated for the temperature range of the location plus the temperature rise of all equipment installed inside the enclosure. The enclosure must be rated for electrical equipment that is going to be installed.

NOTE

It is recommended to maintain a minimum of 4 inches clearance between the module and other equipment to provide adequate room for wiring and ventilation.

WIRING

All electrical connections are made to the field wiring connectors furnished with the module. (Connectors accept up to 12 AWG wire.) Refer to Figure 3-42 for identification of module wiring terminals.

Power Connector — Terminals 1 to 6 24 Vdc Power Input

1 — +

2 __ _

3 — Shield*

4 — +

5 — -

6 - Shield*

*Shields on power wires are optional unless required by local codes.

Connect the module power supply to terminals 1 and 2. If additional terminals are required for powering other devices, these devices should be connected to terminals 4 and 5. Shields are to be connected to terminals 3 and 6.

COM Connector — Terminals 1 to 6 LON Terminals

Be sure to observe polarity when wiring the LON.

1 — "A" side of signaling circuit for COM 1

2 — "B" side of signaling circuit for COM 1

4 — "A" side of signaling circuit for COM 2

5 — "B" side of signaling circuit for COM 2

3 & 6 — shield connections (shields required).




Figure 3-42—Analog Input Module Wiring Terminal Configuration




Figure 3-43—Two-Wire Transmitter — Non-Isolated 4 to 20 mA Current Output (Sourcing)




Figure 3-44—Two-Wire Transmitter with HART Interface Module — Non-Isolated 4 to 20 mA Current Output (Sourcing)

Channel Connectors — Terminals 1 to 24 4-20 mA Input Devices

Connect external wiring to the appropriate terminals on the analog input module terminal block. See Figure 3-43 for an example of a 2-wire input. See Figure 3-44 for a 2-wire input with HART interface module. See Figure 3-45 for a 3-wire input, where the transmitter must source a 4-20 mA signal. See Figure 3-46 for a 3-wire input with HART interface module.

Only channel 1 is shown in each diagram. The information is typical for channels 2-8.

Analog Input Module Channels used as NFPA 72 Approved 4-20 mA Flame Detector Input

Configure the High Alarm setpoint at 19 mA via the S³ configuration screen, and use the High Alarm to trigger the Fire Alarm in S³ logic. The AlM sends an exception message for the High Alarm so there is no delay in transmitting the Fire Alarm.

Fault indications and other status information must be decoded in logic from the analog process variable. A five second delay should be used to avoid indicating an incorrect status condition while the analog value is changing between two values. See Table 14.

Table 14—Analog Values (in mA) for Fault and Status Indications when the AIM is Used as a 4-20 mA Flame Detector Input

Status	X3301/2	X5200	X9800	X2200
Fault	0 to 3.5	0 to 3.5	0 to 3.5	0 to 3.5
IR Pre-Alarm		7.0 to 9.0		
UV Alarm		11.0 to 12.99		
IR Alarm		13.0 to 14.99		
Pre-Alarm		15.0 to 16.99	15.0 to 16.99	15.0 to 16.99




Figure 3-45—Three-Wire Transmitter — Non-Isolated 4 to 20 mA Current Output (Sourcing)




Figure 3-46—Three-Wire Transmitter with HART Interface Module — Non-Isolated 4 to 20 mA Current Output (Sourcing)

CONFIGURATION

Setting Analog Input Module Network Address

One unique network address must be assigned to each analog input module. The address is set by the 8 switch DIP assembly on the analog input module.

When using the switches located on the analog input module, the address is binary coded and is the sum of all switches placed in the "closed" position.

Each point of an analog input module has a tag number and a descriptor for unique identification.

Det-Tronics S³ Safety System Software is used for device configuration. The following tables show the minimum software/firmware releases:

For Gas Applications

Controlle	r Firmware*	AIM		S3
Rev.	Version	Rev. Version		Version
В	3.06	В	1.02	2.9.1.1

^{*}for part number 007606-002

For Flame Applications

Controlle	r Firmware*	AIM		S3
Rev.	Version	Rev. Version		Version
С	5.52	D	1.07	4.0.0.0

^{*}for part number 008983-001

INTELLIGENT PROTECTION MODULE INSTALLATION

WIRING

All electrical connections are made to the field wiring connectors furnished with the module. Refer to Figure 3-47 for identification of module wiring terminals.

Power Connector, Terminals 1 to 6 24 Vdc Power Input

Connect the module power supply to terminals 1 and 2. If additional terminals are required for powering other devices, these devices should be connected to terminals 4 and 5. Shields are to be connected to terminals 3 and 6 — chassis (earth) ground terminals. Terminals are rated for 10 amperes. Use both sets of input terminals in parallel if total output current can exceed 10 amperes.

LON Connector, Terminals 1 to 6 LON/SLC Signaling Circuit Terminals

Be sure to observe polarity when wiring the LON/SLC.

shield connection — terminals 3 and 6.

1 — "A" side of signaling circuit for COM 1

2 — "B" side of signaling circuit for COM 1

4 — "A" side of signaling circuit for COM 2

5 — "B" side of signaling circuit for COM 2




Figure 3-47—IPM Wiring Terminal Configuration

Channels 1 to 3, Terminals 1 to 9 Channels 1 to 3 Inputs

Refer to individual wiring configurations for terminal descriptions. Only channel 1 is shown in each diagram. The information is typical for channels 1-3.

Unsupervised Input

Connect external system wiring to the appropriate terminals on the terminal block. See Figure 3-48.

The input to the IPM consists of one or more normally open switches. An EOL resistor is not required.

No connection should be made to "+ Supply" terminal.

NOTE

Unsupervised inputs are not recommended for fire alarm applications.

NFPA - Class B, Style B (Two State – Open and Switch Closure)

Supervised Input (IDC) Open Circuit Supervision

Connect external system wiring to the appropriate terminals on the terminal block. See Figure 3-49.

The input to the IPM consists of one or more normally open switches, with a 10 K ohm, 1/4 watt EOL resistor in parallel across the last switch. No connection should be made to "+ Supply" terminal.

NFPA - Class B Style C (Three state – open, switch closure, and short)

Supervised Input (IDCSC) Open and Short Circuit Supervision

Connect external system wiring to the appropriate terminals on the terminal block. See Figure 3-50.

The input to the IPM consists of a normally open switch, with a 10 K ohm, 1/4 watt EOL resistor in parallel across the switch, and a 3.3 K ohm, 1/4 watt resistor in series with the switch.

No connection should be made to "+ Supply" terminal.




Figure 3-48—Unsupervised Input Configuration




Figure 3-49—Supervised Input Configuration




Figure 3-50—Supervised Input Configuration (Opens and Shorts)

Channels 4 and 5, Terminals 10 to 15 ZONE-1 and ZONE-2 Inputs

The IPM supports 2-wire devices from Kidde-Fenwal and Apollo. Figure 3-51 shows the wiring for Apollo detectors connected to IPM Channel 4 through terminals 10 and 11.

Figure 3-52 shows the typical wiring for Kidde-Fenwal detectors connected to the IPM through Channel 5 using terminals 13 and 14.

IPM Channels 4 and 5, labeled "Zone-1" and "Zone-2" on the modules wiring legend, support either brand of detection products however mixing brands is not supported on either a single channel or module.

Notes: 1. Contact devices such as Fenwal heat detectors may be used on ZONE 1 and 2 inputs if NFPA Class B, Style B supervision is selected.

2. The initiating device circuit(s) for use with the deluge and pre-action system configuration must be wired within 20 feet and in conduit from the IPM.

Channel 6, Terminals 16 to 18 Unsupervised Output

Connect external system wiring to the appropriate terminals on the terminal block. See Figure 3-53. No connection should be made to "+ Supply" terminal.






Figure 3-53—CH-6: Unsupervised Output Configuration





Supervised Output Notification Supervised for Open & Short Circuits

Connect external system wiring to the appropriate terminals on the terminal block. See Figure 3-54.

The output of the IPM supervises the notification circuit by reversing the polarity of the monitoring circuit. Polarity must be observed when connecting the notification device. It is essential to utilize a notification device approved for fire alarm notification. These devices are polarized and would not require the use of an external diode for the supervision of the circuit. Wire one or more notification devices to the output, with a 10 K ohm, 1/4 watt EOL resistor in parallel across the last device.

No connection should be made to "+ Supply" terminal. Each output channel is individually activated for response pattern:

- supervisory
- continuous output
- 60 beats per minute
- 120 beats per minute
- temporal
- trouble.

Channels 7 and 8, Terminals 19 to 24 Supervised Output Agent Release

Connect external system wiring to the appropriate terminals on the terminal block. See Figure 3-55.

Wire one or more releasing devices to the module output.

No connection should be made to "+ Supply" terminal.

The output of the IPM supervises the releasing circuit via the coil of the releasing solenoid. It is essential to utilize a releasing device approved for use with this output module. This type of output does not require the use of EOL resistors or diodes to supervise the circuit.

The output can be configured for continuous or timed response.

To ensure adequate operating voltage for the output device, the maximum wiring length from the power source to the output device must not exceed the values shown in Table 3-15 for automatic release applications or Table 3-16 for deluge and pre-action applications.

For solenoids, this wire length includes both the wiring from the power supply to the IPM and the wiring from the module to the solenoid.

NOTE

For FM system approval listing, pre-action and deluge applications require that only FM approved deluge valves can be wired into the IPM module. Remember that the valves must utilize 24 vdc and must not exceed 2 amperes current draw.

NOTE

Squibs are not compatable with this output. If squib actuation is required, use EQ2500ARM.




Figure 3-54—CH-6: Supervised Output Configuration (Notification)




Figure 3-55—CH-7&8: Supervised Output Configuration (Agent Release)

Table 3-15—Maximum Wire Length for Releasing Applications

Device	Maximum Wire Length in Feet				
	12 AWG	14 AWG	16 AWG	18 AWG	
890181*	150	100	60		
899175*	150	100	60		
895630*	150	100	60		
897494*	190	120	75		
486500*	1500	1000	600	400	
31-199932-004*	150	100	60		
2 Amp Load	190	120	75		

^{*}Fenwal Solenoid

CONFIGURATION

Setting Module Network Address

One unique network address must be assigned to each intelligent protection module. The address is set by the 8 switch DIP assembly on the module. The address is binary coded and is the sum of all switches placed in the "closed" position.

Each discrete point of an intelligent protection module has a tag number and a descriptor for identification.

Det-Tronics S³ Safety System Software is used for device configuration. The following shows the minimum software/firmware releases:

Controller Firmware		S3
Revision	Version	Version
В	3.06	2.9.0.1

Table 3-16—Maximum Wiring Length for FM Approved Solenoids for Deluge and Pre-Action Applications

Solenoids		Maximum Wire Length in Feet (Meters)				
FM Solenoid Group	Manufacturer	Model	12 AWG	14 AWG	16 AWG	18 AWG
В	ASCO	T8210A107	183 (56)	115 (35)	72 (22)	46 (14)
D	ASCO	8210G207	314 (96)	198 (60)	124 (38)	78 (24)
E	Skinner	73218BN4UNLVNOC111C2	331 (101)	208 (63)	131 (40)	82 (25)
F	Skinner	73212BN4TNLVNOC322C2	130 (40)	82 (25)	51 (16)	32 (10)
G	Skinner	71395SN2ENJ1NOH111C2	331 (101)	208 (63)	131 (40)	82 (25)
Н	Viking	HV-274-0601	180 (55)	110 (34)	70 (21)	45(14)

GAS DETECTOR LOCATION AND INSTALLATION

Gas detection devices must be properly located to provide maximum protection. Determining the proper number of devices and placement varies depending on the specific requirements of the area of protection.

The following should be considered when locating a gas detection device:

 Gas type. If it is lighter than air (acetylene, hydrogen, methane, etc.), place the sensor above the potential source. Place the sensor close to the floor for gases that are heavier than air (benzene, butane, butylene, propane, hexane, pentane, etc.) or for vapors resulting from flammable liquid spills.

NOTE

Air currents can cause a gas that is heavier than air to rise. Also, if the gas is hotter than ambient air, it could also rise.

- 2. How rapidly will the gas diffuse into the air? Select a location for the sensor as close as possible to the anticipated source of a gas leak.
- Ventilation characteristics. Air movement will cause gas to accumulate more heavily in one area than another. The devices should be placed in areas where the most concentrated accumulation of gas is anticipated.
- 4. Devices should be pointed down to prevent the buildup of moisture or contaminants on the filter.
- Devices must be accessible for testing and calibration.

NOTE

The use of the Sensor Separation Kit will be required in some installations.

ENVIRONMENTS AND SUBSTANCES THAT AFFECT GAS DETECTOR PERFORMANCE

Catalytic sensors should be located where they are safe from potential sources of contamination that can cause a decrease in the sensitivity of the device including:

A. Substances that can clog the pores of the flame arrestor and reduce the gas diffusion rate to the sensor including:

Dirt and oil, corrosive substances such as Cl_2 (Chlorine) or HCl, paint overspray, or residue from cleaning solutions that can clog the flame arrestor.

NOTE

A dust cover should be installed to protect the flame arrester whenever these conditions exist.

B. Substances that cover or tie up the active sites on the catalytic surface of the active sensing element such as volatile metal organics, gases, or vapors of hydrides, and volatile compounds containing phosphorous, boron, silicone, etc.

Examples:

RTV silicone sealants
Silicone oils and greases
Tetraethyl lead
Phosphine
Diborane
Silane
Trimethyl chlorsilane
Hydrogen fluoride
Boron trifluoride

Phosphate esters

C. Materials that remove the catalytic metals from the active element of the sensor. Some substances react with the catalytic metal forming a volatile compound that can erode the metal from the surface of the sensor's active element.

Halogens and compounds containing halogen are materials of this nature and others include:

Examples:

Chlorine

Bromine

lodine

Hydrogen Chloride, Bromide or Iodide

Organic halides:

Trichloroethylene

Dichlorobenzene

Vinyl chloride

Freons

Halon 1301

(Bromotrifluoromethane).

NOTE

Brief exposure to these materials can temporarily increase sensor sensitivity due to the surface of the active element being etched. Prolonged exposure continues this process until the sensitivity of the sensor is degraded, resulting in shortened sensor life.

D. Exposure to high concentrations of combustible gases for extended periods of time can stress the sensing element and seriously affect its performance.

The degree of damage to the sensor is determined by a combination of contaminant type, contaminant concentration in the atmosphere, and the length of time the sensor is exposed.

NOTE

If a sensor has been exposed to a contaminant or a high level of combustible gas, it should be calibrated at the time of exposure. An additional calibration a few days later should be performed to determine whether a significant shift in sensitivity has occurred. If necessary, sensor should be replaced.

NOTE

A combination of accessories such as rain shields and dust covers is not recommended and can result in slow response to a gas leak.

EQ22xxDCU DIGITAL COMMUNICATION UNIT USED WITH DET-TRONICS H2S/O2 SENSORS OR OTHER TWO-WIRE 4 TO 20 MA DEVICES

Determine the best mounting locations for the detectors. Whenever practical, detectors should be placed where they are easily accessible for calibration.

△WARNING!

Do not apply power to the system with the cover removed unless the area has been verified to be free of combustible gases or vapors.

The DCU utilizes the following:

- 1. A terminal wiring board mounted at the bottom of the junction box.
- 2. A communication module mounted above the terminal wiring board using the standoffs provided. See Figure 3-56.

Assembly and Wiring Procedure

Attach the sensor to the DCU enclosure. Do not overtighten. If a sensor separation kit is being used, attach the sensor to the separation kit junction box and wire the device as described in the "Sensor Separation" section.




Figure 3-56—Printed Circuit Boards in Universal DCU

∆CAUTION!

The sensor threads can be coated with an appropriate grease to ease installation. Also lubricate the cover threads. (See "Ordering Information" for part number of recommended lubricant.)

Connect the external wiring to the appropriate terminals on the DCU terminal wiring board. Refer to Figure 3-57 for terminal identification. See Figure 3-58 for an example of a Det-Tronics electrochemical sensor connected to a DCU.

Attach the communication module to the standoffs as shown in Figure 3-56. Connect the ribbon cable from the terminal wiring board to the communication module.

Set the address for the device. Refer to "Setting Device Network Addresses" for complete information regarding the switch setting procedure.

Check the wiring to ensure proper connections, then pour the conduit seals and allow them to dry (if conduit is being used).

NOTE

Before placing the cover back on the enclosure following completion of assembly and wiring, inspect the enclosure O-ring to be sure that it is in good condition and properly installed. Lubricate the O-ring and the threads of the cover with a thin coat of an appropriate grease to ease installation. Refer to the "Ordering Information" section for the part number of the recommended grease (available from Detector Electronics). If the installation uses catalytic type combustible gas sensors, it is imperative that lubricants containing silicone not be used, since they will cause irreversible damage to the sensor. Place the cover on the enclosure. Tighten only until snug. Do not over tighten.

Sensor Separation for DCU with H2S and O2 Sensors

Since the transmitter for the electrochemical sensor is already mounted within the sensor housing, simply mount the entire sensor assembly to the sensor separation kit junction box and wire it to terminals 2 and 4 inside the DCU, the same as a regular (without sensor separation) installation. Connect the shield to the ground terminal in the DCU junction box.

Refer to Table 3-17 for separation distance limitations for H_2S and O_2 sensors.




Figure 3-57—Wiring Configuration for DCU




Figure 3-58—Electrochemical Sensor Connected to DCU

Table 3-17
Maximum Separation Distances — Electrochemical Sensor to DCU

Wire Size	Maximum Wiring Distance			
(AWG)	Feet Meters			
18 16	5700 9000	1750 2800		

T0020A

EQ22xxDCU DIGITAL COMMUNICATION UNIT USED WITH POINTWATCH/DUCTWATCH

Determine the best mounting location for the detector. Whenever practical, detectors should be placed where they are easily accessible for calibration.

MWARNING!

Do not apply power to the system with the cover removed unless the area has been verified to be free of combustible gases and vapors.

The DCU utilizes the following:

- 1. A terminal wiring board mounted at the bottom of the junction box.
- 2. A communication module mounted above the terminal wiring board using the standoffs provided. See Figure 3-56.

Assembly and Wiring Procedure

Attach the PointWatch/DuctWatch to the DCU enclosure. Do not over-tighten. If a sensor separation kit is being used, attach the sensor to the separation kit junction box and wire the device as described in the "Sensor Separation" section.

Refer to the PointWatch instruction manual (form number 95-8440) or the DuctWatch instruction manual (form number 95-8573) for complete installation and application information.

Refer to Figure 3-59 when wiring a PointWatch IR gas detector and a DCU. The wiring code for PointWatch is:

Red = + (24 vdc)
Black = - (common)
White = 4 to 20 ma signal
Yellow = Calibration input
Green = Chassis ground

Set the address for the device. Refer to "Setting Device Network Addresses" for complete information regarding the switch setting procedure.




Figure 3-59—PointWatch/DuctWatch Connected to DCU

Sensor Separation for DCU with PointWatch

Shielded four wire cable is recommended for connecting the detector junction box to the DCU. Cable with a foil shield is recommended. The shield of the cable should be open at the detector junction box and connected to earth ground at the DCU junction box.

NOTE

To ensure proper operation, it is essential to maintain a minimum of 18 vdc (including ripple) at the PointWatch detector.

EQ22xxDCUEX DIGITAL COMMUNICATION UNIT (USED WITH DET-TRONICS COMBUSTIBLE GAS SENSORS)

MOUNTING

Determine the best mounting location for the device. Whenever practical, the device should be placed where it can easily be reached for calibration.

⚠IMPORTANT!

Always orient the junction box with the sensor pointing down.

MWARNING!

Do not apply power to the system with the cover removed unless the area has been verified to be free of combustible gases or vapors.

WIRING

1. Remove the cover from the DCUEX.

△CAUTION!

ALWAYS discharge static from tools and hands by touching the device body before touching the communication module or transmitter board.

- Loosen the screws on the communication module and remove it from the transmitter board standoffs.
- 3. Disconnect the ribbon cable from the communication module.
- Remove the standoffs and detach the transmitter board from the terminal wiring board. Do not disconnect any wiring.
- 5. Connect all external wiring to the terminal wiring board. (See Figure 3-60.)

NOTE

Make sure the ribbon cable is connected to the terminal wiring board.

6. Attach the sensor to the device enclosure. DO NOT overtighten.

NOTE


If a sensor separation kit is being used, attach the sensor to the separation kit junction box. (See Sensor Separation with DCUEX below.)

- 7. Plug the sensor into P2 on the transmitter board.
- 8. Mount the transmitter board to the terminal wiring board and attach with the standoffs.

NOTE

Be sure to note the correct orientation of the transmitter board. If the transmitter board is rotated 180° from proper orientation, the device will not operate correctly — a LON communication fault will result. See Figure 3-61.


- 9. Plug the ribbon cable into the communication module and re-attach it to the transmitter board.
- 10. Set the device network address. (See "Setting Device Network Addresses" in this section.)
- 11. Inspect the junction box O-ring to be sure that it is in good condition. Lubricate the O-ring and the threads of the junction box cover with a thin coat of silicone-free grease (available from Det-Tronics).
- 12. Replace the device cover.




NOTES: 1 Catalytic Combustible Gas Sensor Plugs into Connector Pins on the Middle Board inside the Junction Box.

2 Connections Wired at the Factory.

Figure 3-60—DCU Transmitter Board Connected to Terminal Wiring Board



CORRECT ORIENTATION OF TRANSMITTER BOARD



INCORRECT ORIENTATION OF TRANSMITTER BOARD




Figure 3-61—Printed Circuit Boards in Combustible Gas DCU

Sensor Separation with DCUEX

If the installation requires mounting the sensor in a different location than the DCUEX, observe the following guidelines.

There are two (2) methods that can be used to separate the sensor from the DCUEX:

Preferred Method

- Disassemble the DCUEX and remove the transmitter board. (Refer to "Wiring" for disassembly procedure.) Do not re-assemble at this time.
- 2. Mount the transmitter board inside the sensor separation junction box (remove the existing board).

NOTE

This assembly can be separated from the DCUEX by up to 1000 feet using three conductor 18 AWG shielded cable. (Regardless of separation distance, operating voltage at the transmitter MUST be at least 18 vdc for proper device operation.) (See Figure 3-62.)


- 3. Mount the sensor to the separation junction box. DO NOT overtighten. Plug the sensor into P2 on the transmitter board.
- Use a three conductor 18 AWG shielded cable to connect P1 on the transmitter board to terminals 2, 3 and 4 on the DCU terminal board (See Figure 3-62). Connect the shield to the ground terminal in the DCUEX junction box.
- Connect all external wiring to the terminal wiring board inside the DCU (if not already completed). Re-assemble the DCUEX as described in the "Wiring" section. When completed, it should look similar to the DCU as shown in Figure 3-56.
- 6. Inspect the O-ring on the DCU and separation junction box to be sure that they are in good condition. Lubricate the O-ring and the threads of the junction box cover with a thin coat of silicone-free grease (available from Det-Tronics).
- 7. Replace the cover on the DCU and separation junction box.

Table 3-18—Maximum Separation Distances — Combustible Gas Sensor to DCU (Alternate Method)

Wire Size	Maximum Separation Distance		
VVII e Size	Feet	Meters	
18 AWG (1.0 mm ²)*	40	12	
16 AWG (1.5 mm ²)*	60	18	
14 AWG (2.5 mm ²)*	100	30	
12 AWG (4.0 mm ²)*	150	45	

^{*}Approximate Metric Equivalent.

ELECTROCHEMICAL SENSOR



Alternate Method

If the transmitter board must be mounted separate from the sensor (high temperature applications, etc.), separate the sensor only, leaving the transmitter PC board inside the DCUEX enclosure. When using this installation option, see Table 3-18 for maximum wiring distances.

Mount the sensor directly to the separation kit junction box. Use three conductor shielded cable for the connection between the terminal block in the separation kit junction box and P2 on the DCUEX transmitter board. A plug with screw terminals is provided for connecting the cable to P2 on the transmitter board. Observe the wiring color code. Connect the shield to the ground terminal in the DCUEX junction box.




Figure 3-62—Sensor Separation Kits

EQ25xxARM SERIES AGENT RELEASE MODULE

Mounting

The device should be securely mounted to a vibration free surface. (See "Specifications" in this manual for device dimensions.)

Wiring

To ensure proper operating voltage for the output device, the maximum wiring length from power source to device must not exceed the values shown in Table 3-19 for automatic release applications or Table 3-20 for deluge and pre-action applications.

NOTE

For solenoids, this wire length includes both the wiring from power supply to device, and the wiring from device to solenoid. For squibs, use only the wire length from power supply to module, since the resistance of the wire from module to squib is included when determining the value of the compensating resistor.

See Figure 3-63 for identification of wiring terminals.

Terminals 1 to 4 — Output terminals

Connect a single solenoid between terminals 1 and 4. Connect dual solenoids between terminals 1 and 2, and between terminals 3 and 4.

NOTE

For testing purposes, a load resistor of 1200 to 1500 ohms @ 1 watt can be placed across terminals 1 and 4.

When using an explosive initiator, connect the resistor between terminals 1 and 2 and the initiator between terminals 3 and 4, as shown in Figure 3-63.

△ CAUTION!

DO NOT intermix different types of initiators in release circuit.

Terminals 5 to 10 — LON signaling circuit terminals

NOTE

Be sure to observe polarity when wiring the LON.

5 — "A" side of signaling circuit for COM 2

6— "B" side of signaling circuit for COM 2

7 and 8 — shield connections

9 — "A" side of signaling circuit for COM 1

10 — "B" side of signaling circuit for COM 1

Terminals 11 to 14 — 24 vdc power input

Connect module power supply to terminals 12 and 13.

NOTE

If an auxiliary output supply is used for powering solenoids, it should be connected to terminals 11 and 14.


Table 3-19—Maximum Wiring Length for Automatic Release Applications

Device	Maximum Wire Length in Feet			
	12 AWG	14 AWG	16 AWG	18 AWG
890181*	150	100	60	
899175*	150	100	60	
895630*	150	100	60	
897494*	190	120	75	
486500*	1500	1000	600	400
31-199932-004*	150	100	60	
Squib	190	120	75	
2 Amp Load	190	120	75	

^{*}Fenwal Solenoid


Table 3-20—Maximum Wiring Length for FM Approved Solenoids for Deluge and Pre-Action Applications

Solenoids		Maximum Wire Length in Feet (Meters)				
FM Solenoid Group	Manufacturer	Model	12 AWG	14 AWG	16 AWG	18 AWG
В	ASCO	T8210A107	183 (56)	115 (35)	72 (22)	46 (14)
D	ASCO	8210G207	314 (96)	198 (60)	124 (38)	78 (24)
E	Skinner	73218BN4UNLVNOC111C2	331 (101)	208 (63)	131 (40)	82 (25)
F	Skinner	73212BN4TNLVNOC322C2	130 (40)	82 (25)	51 (16)	32 (10)
G	Skinner	71395SN2ENJ1NOH111C2	331 (101)	208 (63)	131 (40)	82 (25)
Н	Viking	HV-274-0601	180 (55)	110 (34)	70 (21)	45(14)



NOTE:
TERMINALS 12 AND 13 ARE FOR MODULE POWER SUPPLY.
TERMINALS 11 AND 14 ARE FOR AUXILIARY OUTPUT POWER SUPPLY.
JUMPERS JP2 AND JP3 MUST BE REMOVED IF AN AUXILIARY POWER SUPPLY IS USED.

EXPLOSIVE INITIATOR OPTION



- NOTES:
 1. JUMPER JP1 MUST BE REMOVED IF EXPLOSIVE INITIATOR IS USED.
- 2. RESISTOR IS USED TO COMPENSATE FOR 10 OHMS CIRCUIT RESISTANCE.
 RESISTOR MUST BE RATED 1 WATT MINIMUM (WIRE-WOUND RESISTOR PREFERRED).
 WHEN MEASURING THE TOTAL RELEASE CIRCUIT RESISTANCE,
 USE AN OHM METER WITH A CURRENT OUTPUT OF 10 MA MAXIMUM.
- 3. MAXIMUM NUMBER OF EXPLOSIVE INITIATORS PER CIRCUIT IS 12. EACH CIRCUIT MUST NOT EXCEED 10 OHMS INCLUDING CABLE RESISTANCE. B1900

Figure 3-63—Wiring Configuration for Agent Release Module

Supervised Output for Deluge and Pre-action

Connect external wiring to the appropriate terminals on the terminal block. See Figure 3-63. Wire one or more releasing devices to the module output.

The output of the Agent Release Module supervises the releasing circuit via the coil of the releasing solenoid. It is essential to use a releasing device approved for use with this output module.

NOTE

This type of output does not require the use of EOL resistors or diodes to supervise the circuit.

The output can be configured for latching, continuous or timed response.

To ensure proper operating voltage, the input voltage to the release module must be in the range from 21 to 30 vdc and the maximum wiring length must not exceed the values shown in Table 3-20 for deluge and pre-action applications. Per FM Approval requirements, the secondary power must provide capacity for a 90 hour minimum standby operation followed by a minimum of 10 minutes of releasing and alarm operation. The initiating device circuit(s) for use with the deluge and pre-action system configuration must be wired within 20 feet and in conduit from an IDC or DCIO. In addition, power for the device(s) must be per NFPA 72 Class A wiring techniques.

Jumpers

Terminals 13 and 14 are connected by jumper JP2 and terminals 11 and 12 are connected by jumper JP3. These two jumpers (JP2 and JP3) must be cut if an auxiliary output power supply is being used. (See Figure 3-64 for jumper locations.)

When an explosive initiator is being used, jumper JP1 must be cut. If a solenoid is used, the jumper must remain in.

Address Setting

Set the device network address. (See "Setting Device Network Addresses" in this section.)




Figure 3-64—Agent Release Module Wiring Terminals and Jumpers

EQ25xxSAM SERIES SIGNAL AUDIBLE MODULE

Mounting

The device should be securely mounted to a vibration free surface. (See "Specifications" in this manual for device dimensions.)

Wiring

MIMPORTANT!

To ensure adequate operating voltage for the signaling device, the maximum wiring length from the power source to the output device must not exceed the values shown in Table 3-21. (This wire length includes both the wiring from the power supply to the signal audible module and the wiring from the module to the signaling device.)

See Figure 3-65 for identification of wiring terminals.

Table 3-21—Maximum Wiring Length from Nominal 24 VDC Power Source to Signaling Device

Maximum Wire Length in Feet (Meters)					
	12 AWG 14 AWG 16 AW (4 mm ²)* (2.5 mm ²)* (1.5 mm				
One 2 Ampere Load	190 (58)	120 (37)	75 (23)		
Two 2 Ampere Loads	95 (29)	60 (18)	35 (11)		

^{*} Approximate Metric Equivalent.

T0029A

Terminals 1 to 4 — Output terminals

Connect the first output device between terminals 1 and 2, and the second between terminals 3 and 4.

NOTE

Polarity shown in Figure 3-65 is for monitoring condition; polarity is reversed when activated.

Each circuit must have a 10 kohm EOL resistor.

Terminals 5 to 10 — LON signaling circuit terminals

Be sure to observe polarity when wiring the LON.

5 — "A" side of signaling circuit for COM 2

6— "B" side of signaling circuit for COM 2

7 and 8 — shield connections

9 — "A" side of signaling circuit for COM 1

10 — "B" side of signaling circuit for COM 1

Terminals 11 to 14 — 24 vdc power input


Connect the module power supply to terminals 12 and 13. If an auxiliary output supply is used for powering signaling devices, it should be connected to terminals 11 and 14.

Jumpers

Terminals 13 and 14 are connected by jumper JP2 and terminals 11 and 12 are connected by jumper JP1. These two jumpers (JP1 and JP2) must be cut if an auxiliary output power supply is being used. (See Figure 3-66) for jumper locations.

Address Setting

Set device network address. (See "Setting Device Network Addresses" in this section.)



* POLARITY SHOWN IS FOR MONITORING CONDITION, POLARITY IS REVERSED WHEN ACTIVATED.

NOTE:

TERMINALS 12 AND 13 ARE FOR MODULE POWER SUPPLY.
TERMINALS 11 AND 14 ARE FOR AUXILIARY OUTPUT POWER SUPPLY.
JUMPERS JP1 AND JP2 MUST BE REMOVED IF AN AUXILIARY POWER SUPPLY IS USED.

Figure 3-65—Wiring Configuration for Signal Audible Module




Figure 3-66—Signal Audible Module Wiring Terminals and Jumpers

SYSTEM CONFIGURATION

SETTING DEVICE NETWORK ADDRESSES

Overview of Network Addresses

Each device on the LON must be assigned a unique address. Addresses 1 to 4 are reserved for the controller. Valid addresses for field devices are from 5 to 250.

IMPORTANT

If the address is set to zero or an address above 250, the communication module will ignore the switch setting.

Duplicated addresses are not automatically detected. Modules given the same address will use the number given and report to the controller using that address. The status word will show the latest update, which could be from any of the reporting modules using that address.

Setting Field Device Addresses

Selection of the node address for field devices is done by setting rocker switches on an 8 switch "DIP Switch" within each device's housing.


NOTE

Only the first eight of the 12 switches are used for selecting the device address.

The address number is binary encoded with each switch having a specific binary value with switch 1 being the LSB (Least Significant Bit). (See Figure 3-67) The device's LON address is equal to the added value of all closed rocker switches. All "Open" switches are ignored.

NOTE


The address switches in the DCIO module and relay module appear slightly different than those in other devices. Refer to Figure 3-68.



NODE ADDRESS EQUALS THE ADDED VALUE OF ALL CLOSED ROCKER SWITCHES

OPEN = OFF CLOSED = ON

Figure 3-67—Field Device Address Switches for ARM, SAM, DCU and IDC



NODE ADDRESS EQUALS THE ADDED VALUE OF ALL CLOSED ROCKER SWITCHES

OPEN = OFF CLOSED = ON A2190

Figure 3-68—Address Switch for DCIO and Relay Module

Example: for node No. 5, close rocker switches 1 and 3 (binary values 1 + 4); for node No. 25, close rocker switches 1, 4 and 5 (binary values 1 + 8 + 16).


NOTE

The field device sets the LON address only when power is applied to the device. Therefore, it is important to set the switches **before** applying power. If an address is ever changed, system power must be cycled before the new address will take effect.

After setting address switches, record the address number and device type on the "Address Identification Chart" provided with this manual. Post the chart in a convenient location near the Controller for future reference.

TYPICAL APPLICATIONS

Figure 3-69 is a simplified drawing of a typical EQP system. This system includes an EQP Controller, DCIO and various LON field devices.



Section 4 Operation

SYSTEM CONTROLLER

PUSHBUTTONS

The Controller has seven pushbuttons (located on the front panel) for user interface. These pushbuttons allow the operator to interact with the Controller to respond to alarms and system status conditions, access system status reports, and configure Controller time and date settings.

The following paragraphs describe the function of each pushbutton. Refer to Figure 4-1 for Controller pushbutton locations.

Cancel cancels the selected command, and returns the menu to the last option list displayed.

Enter chooses the menu item selected, and advances the menu to the next options list. (See "Controller Menu Options" in this section for additional information.)

NOTE

Pressing Enter while alarms are actively scrolling returns the display to the Main Menu.

Next allows the operator to scroll through options listed within each menu. Each time the NEXT pushbutton is pushed, the current options list indexes up one list item. (See "Controller Menu Options" in this section for additional information)

Previous allows the operator to scroll through options listed within each menu. Each time the PREVIOUS pushbutton is pushed, the current options list indexes down one list item. (See "Controller Menu Options" in this section for additional information)

Reset resets all controller latched outputs that are no longer active.

Acknowledge silences the internal beeper.

Silence turns on the Silence LED and sets Silence status in user logic.




Figure 4-1—EQP Controller Pushbutton Locations

CONTROLLER STATUS INDICATORS

System status is visually displayed on the Controller in two ways — through the use of a Text Display (see Figure 4-2), and through colored LED's (see Table 4-1). The following paragraphs describe these indicators and the function of each.

TEXT DISPLAY

The Controller uses a text based display to show current system status, active Alarms and Faults.

When an alarm or trouble condition occurs, the display scrolls a detailed message of the condition, including tag number, condition (alarm, trouble, supervisory etc.) and time/date. If multiple alarms or trouble conditions exist, the display scrolls through all active status conditions until they go inactive and are reset using the controller pushbutton.

CONTROLLER MENU OPTIONS

The Controller is designed to display system status and device related information. The following paragraphs describe how to move around within the controller's menu structure to access this information and perform minor system settings (see Figure 4-3).

NOTE

During normal operation (no alarms or trouble conditions occurring), the display scrolls current system time and date.

Main Menu displays a list of options to access information types available for display through the Controller. This list also includes access to options used to set system date and time, and diagnostics options.




Figure 4-2—EQP Controller Message Display and System Status Indicator Location

Table 4-1—FOP Control	ler LED System Status Indicators	2

LED	Function	Status
Green	Power	On when power is applied.
Red	Fire Alarm	On (latched) when any fire alarm is active (Fire detected).
Amber	Trouble	On (latched) when a fault is detected in the system. (Indicates "Trouble" relay state.)
Amber	Ack	On when the Acknowledge button is pressed.
Amber	Silence	On when Silence pushbutton is pressed.
Amber	Inhibit	On when any input channel is inhibited.
Amber	Out Inhibit	On when any output is inhibited.
Red	High Gas	On (latched) when any gas detector is at or above the High gas alarm value.
Red	Low Gas	On (latched) when any gas detector is at or above the Low gas alarm value.
Amber	Supervisory	On (latched) when any Supervisory input is active.
Amber	LON Fault	On when a LON fault is detected (open or short).
Amber	Contrl Fault	On when a processor fault occurs.




Figure 4-3—EQP Controller Message Display Menu Outline

Main Menu
>Display Alarms
Display Devices
Device Tagnames

Moving within the Main Menu is done by using the NEXT or PREVIOUS pushbuttons located on the controller's front panel. The menu options will scroll upward (NEXT Pushbutton) or downward (Previous Pushbutton) while the Main Menu name remains stationary. When the desired menu option is selected by the ">" indicator, the ENTER pushbutton is pressed to advance the menu display to the desired information set.

NOTE

Pressing the CANCEL pushbutton from within any sub-menu returns the display to the Main Menu. The display will also return to the Main Menu if left unattended for a period of 20 minutes. If an alarm or trouble condition is present after 20 minutes, the display will change to the existing Alarm or Trouble message.

DISPLAY ALARMS displays a list of existing Alarms and Trouble conditions. Moving within this menu is done by using the NEXT or PREVIOUS pushbuttons.

Alarm Type Off/On
Tag Name
Alarm Description
Time & Date ack

NOTE

Multiple alarm information can be viewed by pressing the NEXT or PREVIOUS pushbuttons. Pressing CANCEL will return the menu to the DISPLAY ALARMS menu.

DISPLAY DEVICES displays device information on all devices on the LON loop. Device tag name, type, and node address are displayed.

Z398-63 U / I Add:63 UV / IR Detect No Fault Pressing the NEXT or PREVIOUS pushbuttons allows cycling through devices. Pressing the CANCEL pushbutton will return the display to the Main Menu.

DEVICE TAG NAMES displays device tag name information for all devices on the LON loop.

Device Tagnames Controller Z398-80 X

Pressing the NEXT or PREVIOUS pushbutton allows cycling through devices. Pressing the CANCEL pushbutton will return the display to the Main Menu.

SET TIME AND DATE provides access to configuration controls for system clock and date settings.

Set Time & Date 11:20:52 Jul 29 / 2002

NOTE

When the Set Time and Date menu opens, the current hour will flash.

To move within this menu, press the ENTER pushbutton until the desired property is flashing. To set the desired property value, press the NEXT Pushbutton to increase or PREVIOUS Pushbutton to decrease the value. When the desired value is displayed, press the ENTER pushbutton. This will advance the menu to the next property and it will flash. When all desired properties have been entered, press the ENTER pushbutton until the message "Press ENTER to Save" is displayed. When the ENTER pushbutton is pressed, the settings are saved and the menu changes back to the MAIN MENU.

SERIAL PORTS displays port information on all available ports.

Serial Ports Configuration Port Serial Port 1 Serial Port 2

Pressing the NEXT or PREVIOUS pushbutton allows cycling through ports. Pressing the CANCEL pushbutton will return the display to the Main Menu.

DIAGNOSTICS displays information for factory field service.

Diagnostics

Lamp Test -Enter-Display: Traditional HW Version: 2

REDUNDANCY INFO displays the current status of all redundancy related faults. It can be used to monitor the health of the master and standby controllers. It can also be used for diagnostic purposes.

Redundancy faults originate from three general areas:

- Self detected internal failures of the master controller
- Inter-controller communications
- A failure in the standby controller.

Any redundancy fault is annunciated by the master controller, and the redundancy fault code of the highest priority fault is displayed. The controller also provides a diagnostic menu for more detailed information on the source of a redundancy problem. All redundancy related faults must be cleared to insure proper redundancy operation.

Fault

Displays the current redundancy fault.

Lst Flt

Displays the last redundancy fault that occurred.

Cntr Mode

Indicates whether the controller is in master or standby mode.

My Config

Indicates whether the controller is the primary or secondary controller.

Redun Mem

Displays how long it takes to transfer the local and global memory between controllers.

HSSL Status

An error is generated when a problem is detected on the high-speed communication link between controllers. This fault is annunciated when the standby controller is offline.

Version Match

To ensure proper redundant operation, the firmware versions of redundant controllers must match. This error is set when a mis-match is detected. Consult the factory for firmware upgrades.

Parser

As the master controller configures a standby controller, configuration information is extracted from non-volatile memory and checked for errors.

Comm Ack

Critical information is exchanged between controllers on the HSSL using acknowledged messages. The master sends data packets that contain an embedded CRC and a transaction number. The standby validates the message by calculating and comparing the CRC values. If the CRC is correct the standby saves the data and returns an acknowledge message with the transaction number. If an acknowledge message with the proper transaction number is not received by the master within the allotted time the message is resent. When all retries are used the acknowledge error is indicted and acknowledged communication is terminated.

Lon Comm

Redundant controllers exchange information across the LON network. This is primarily done to prevent both controllers from becoming the master in the event that the HSSL fails. The fault is annunciated when a controller fails to receive any information from the other controller.

Msg Error

If the standby controller receives a message from the master that has the correct CRC but invalid data an error message is returned. This master will indicate the error with this fault.

Program Flow

Program flow checking ensures that essential functions execute in the correct sequence. If any functions don't execute properly, or execute in the wrong order, the program flow error is set and control is transferred to the standby controller.

LON A/B Inf

Controllers utilize neuron co-processors to interface with the field device network. If an error is detected in the operation of the co-processor, a LON interface fault is annunciated.

User Logic CS

Controllers continually conduct a checksum test of the user logic program to ensure that the data remains unchanged. A user checksum fault is annunciated if the result is incorrect.

App CS

When the controller firmware is generated a checksum of the program is calculated and saved in memory. Each controller is continually conducting a checksum test of the program to ensure that the data remains unchanged. The application checksum fault is annunciated if the result is incorrect.

User Logic

Many checks are conducted while the controller interprets and executes the user program. The user logic error is generated if invalid or out of range data is detected.

Config

This fault is annunciated when a controller has not been configured or the configuration information has been corrupted.

Power 1

Displays the power 1 status on the standby controller.

Power 2

Displays the power 2 status on the standby controller.

Option Bd

Indicates whether there is a fault on the ControlNet option board of the standby controller.

CONTROLLER AUDIBLE ALARM

The Controller features an internal audible alarm for local system status notification (see Table 4-2 and Figure 4-4). When the system is operating in the normal mode (no Alarm or Fault conditions occurring), the alarm is silent (off). If an event (any alarm or trouble condition) occurs, the alarm will remain active until it is acknowledged by pressing the Acknowledge pushbutton or reset by pressing the Reset pushbutton on the Controller front panel.

Table 4-2—EQP Controller Alarm Tone Patterns

Priority	Controller Tone	Tone Pattern
1	Fire Alarm	Temporal
2	Supervisory	Supervisory
3	Trouble	Trouble
4	High Gas	Gas
5	Low Gas	Gas
6	Normal	Off




Figure 4-4—Tone Pattern for Controller Buzzer

NOTE

If multiple alarms are present, "Acknowledging" will silence the audible alarms.

CONTROLNET STATUS INDICATORS (Optional)

The optional ControlNet status indicator LEDs function as follows: (see Table 4-3)

Steady - The indicator is on continuously in the defined state.

Alternating - The two indicators alternate between the two defined states at the same time (applies to both indicators viewed together). The two indicators are always in opposite states, out of phase.

Flashing - The indicator alternates between the two defined states (applies to each indicator viewed independent of the other). If both indicators are flashing, they must flash together, in phase.

SEQUENCE OF EVENTS DURING A CONFIGURATION DATA DOWNLOAD

During a configuration download, the controller receives configuration data that is stored into flash memory. During the download process, the controller halts normal operation and resets a number of controller functions. Items affected and displayed during a configuration data download are listed in the following steps:

- 1. Halt the static logic and user logic programs.
- Ignore field device LON communications. However, the controller continues to generate the LON heartbeat.
- 3. Silence the Controller's audible annunciator.
- 4. Initiate a Trouble condition that is signaled by the amber Trouble LED and relay.
- 5. Clear all Alarm and Fault events.
- 6. De-energize all 8 Controller relays.
- 7. Ignore Modbus communication.

A and B	Cause	Action
Off	No power	None or power up.
Steady red	Faulted unit	Cycle power. If fault persists, contact the factory.
Alternating red/green	Self-test	None
Alternating red/off	Incorrect node configuration	Check network address and other ControlNet configuration parameters.
A or B	Cause	Action
Off	Channel disabled	Program network for redundant media, if required.
Steady green	Normal operation	None
Flashing green/off	Temporary errors	None; unit will self-correct.
	Listen only	Cycle power.
Flashing red/off	Media fault	Check media for broken cables, loose connectors, missing terminators, etc.
	No other nodes present on network	Add other nodes to the network.
Flashing red/green	Incorrect network configuration	Cycle power or reset unit. If fault persists, contact the factory.

- 8. ControlNet communication continues.
- Text display's first line indicates "*** Program Mode ***"
- 10. Text display's third line displays download status.
 - a) "Config Download" indicates the serial transfer into memory from the PC to the Controller.
 - b) "Erasing Flash" indicates that the controller is electronically erasing the contents of the Flash memory.
 - c) "Writing to Flash" indicates that configuration data stored in memory is being written down into Flash memory.
 - d) "Flash Lock" indicates that the controller is locking the configuration data into the Flash memory.

CAUTION

The controller's configuration data will be corrupted if power is removed during a download. Contact the factory if this occurs.

11. Initialize the RS-485 and configuration serial ports with new parameters.

- 12. Initialized the ControlNet option board with new parameters.
- 13. Enable static logic and user logic programs to operate. The first scan program is run first.
- 14. Accept field device LON communications.
- 15. Poll the device type variable from LON field devices.
- 16. Configure LON field devices.
- 17. Clear the Trouble condition.
- 18. Text display shows a normal operation marquee message.
 - a) Text display's first line indicates "Det-Tronics Eagle Quantum Premier".
 - b) Text display's third line displays time (24 hour format) and date (month day/year).

NOTE

Depending on the condition of the LON devices, faults may persist for a number of minutes.

CONTROLLER REDUNDANCY

Pushbuttons

The pushbuttons are active on the master controller and inactive on the standby controller.

Controller Status Indicators

The status indicators are active on the master controller. All LEDs except the power LED are off and the trouble relay is in the no trouble state.

Controller Relay Operation

The controller relays are fully functional on the master controller and the standby controller.

Text Display

The text display on the master controller is fully functional as explained in the previous section. The text display on the standby controller reads **Standby Mode**, Ready.

Controller Menu Options

The menu options are active on the master controller and inactive on the standby controller.

ControlNet Status Indicators

The ControlNet status indicators are active on the master and standby controller. See Table 4-3 for details.

Power-up Sequence

The power-up sequence for a redundant controller pair is as follows:

- 1. Make sure the LON and HSSL are connected correctly.
- 2. Apply power to both controllers.
- 3. Controllers go through their boot-up routine.
- 4. The controller that is connected with the primary end of the HSSL is identified as the primary controller and is assigned address 1.
- The controller that is connected with the secondary end of the HSSL is assigned address 2.

- 6. If there are no faults present, the primary controller defaults to the master controller and the secondary controller defaults to the standby controller.
- 7. The master controller executes user logic and communicates with the connected LON devices.
- 8. The standby controller indicates that it is in standby mode and monitors the master controller.
- 9. The master and standby controller go through a synchronization process.
- 10. The power-up sequence is complete.

Synchronization

When a master controller detects a standby controller on the HSSL, it performs the following synchronization process:

- 1. Compare controller firmware versions. If the firmware versions are not an exact match, the process stops and a fault is generated.
- 2. Standby controller indicates the synchronization steps.
- 3. Compare the user application programs. If there is a mis-match, the master will configure the standby controller via the HSSL.
- 4. Initiate the data synchronization process.
- 5. Transfer the status of device inhibits and device removes.
- 6. Transfer the complete alarm list, including alarm history.
- 7. Transfer the real time clock (RTC) value.
- 8. Copy the local and global memory to the standby controller.
- 9. Synchronization is complete and the standby controller indicates "Ready".

Sequence of Events During a Configuration Download

When downloading a new configuration to the master controller, the following sequence is executed:

 The S3 software must be connected to the master controller.

- 2. Alter the configuration and execute the download command from S3.
- 3. The master controller goes into 'Program' mode and passes mastership to the standby controller.
- 4. The updated configuration file is loaded into the controller.
- 5. The controllers are automatically forced to switch over.
- 6. The master controller puts the standby controller into 'Program' mode and downloads the configuration.
- 7. The controller indicates "Device Download Active" until the LON devices have been successfully updated.
- 8. The configuration download is now complete.

WARNING

The system is inactive and not executing logic/alarm functions during a program download.

Manual Switchover

The user can request a manual switchover from an externally wired switch. The request executes the following sequence:

- 1. Verify that HSSL communication is good and there are no internal faults in the standby controller.
- 2. Verify that the synchronization process is complete.
- 3. The master requests the standby to take control.
- 4. The standby takes control and becomes the master.
- The controller indicates "Device Download Active" until the LON devices have been successfully updated.

Automatic Switchover

An automatic transfer will be initiated if the master controller goes into an error (self detected internal controller failure, program flow error in the controller, user logic checksum error or application checksum error). An automatic switchover executes the following sequence:

- 1. Check that the standby controller is online by verifying that HSSL communication is good and there are no internal faults in the standby controller.
- 2. Verify that the synchronization process is complete.
- 3. The master requests the standby to take control.
- 4. The standby takes control and becomes the master.

Replacing a Faulty Controller

If the master controller fails and the standby controller is healthy, an automatic switchover will occur. To replace the failed controller, perform the following steps:

- 1. Remove power. Disconnect plugs and remove the failed controller.
- 2. Mount the new controller.
- 3. Connect the LON to the new controller.
- 4. Connect the HSSL.
- 5. Connect any other I/O used.
- 6. Apply power to the controller.
- 7. A controller synchronization occurs and the new controller is configured and indicates "Ready" as the standby controller.
- 8. If preferred, perform a manual switchover to return the primary controller to the master status.

ENHANCED DISCRETE I/O MODULE

The EDIO Module (see Figure 4-5) has 18 LED status indicators, two for the device and two for each channel, located on the front panel. Refer to Tables 4-4 and 4-5 for a description of the LED indicators.

POWER-UP SEQUENCE

Set the module address switch prior to applying power.

EDIO module power-up sequence illuminates the LEDs for the device and all of its channels. First the power and fault LEDs are illuminated, indicating that the device is in a power-up mode. Next the LEDs are illuminated in the following sequences:

- Sequentially each channel active red LED is illuminated, starting with channel 1 and continuing through channel 8.
- When the red LED for channel 8 is illuminated, sequentially each channel active red LED is turned off, starting with channel 1 and continuing through channel 8.
- Next, the channel fault amber LEDs are tested in the same manner as the channel active red LEDs.

When all the LEDs have been illuminated, the EDIO module displays the device's LON address by illuminating the channel active red LED. LON dip switches 1 though 8 will be displayed on channels 1 through 8. When a dip switch is set to the ON position, the channel active red LED will be illuminated. The address is displayed for two seconds.

Once the address has been displayed, the device's fault LED will turn off.




Figure 4-5—EDIO Module Status Indicator Location

Table 4-4—EDIO Module - Device Status Indicators

LED	Device Status
Green	On when power is present.
Amber	When On steady indicates device is disabled or must be replaced. Possible Watchdog Timer problem.
	Note
	Blinks one time at power-up.

Table 4-5—EDIO Module - Channel Status Indicators

LED	Channel Status
Red	When On steady indicates the input circuit is closed or the output circuit is active.
Amber	When Blinking indicates a low power condition is present or channel is not properly configured. Steady indicates a channel fault.

8 CHANNEL DCIO MODULE

The DCIO Module (see Figure 4-6) has 18 LED status indicators, two for the device and two for each channel, located on the front panel. Refer to Tables 4-6 and 4-7 for a description of the LED indicators.

POWER-UP SEQUENCE

Set the module address switch prior to applying power.

DCIO module power-up sequence illuminates the LEDs for the device and all of its channels. First the power and fault LEDs are illuminated, indicating that the device is in a power-up mode. Next the LEDs are illuminated in the following sequences:

- Sequentially each channel active red LED is illuminated, starting with channel 1 and continuing through channel 8.
- When the red LED for channel 8 is illuminated, sequentially each channel active red LED is turned off, starting with channel 1 and continuing through channel 8.
- Next, the channel fault amber LEDs are tested in the same manner as the channel active red LEDs.

When all the LEDs have been illuminated, the DCIO module displays the device's LON address by illuminating the channel active red LED. LON dip switches 1 though 8 will be displayed on channels 1 through 8. When a dip switch is set to the ON position, the channel active red LED will be illuminated. The address is displayed for two seconds.

Once the address has been displayed, the device's fault LED will turn off.




Figure 4-6—DCIO Module Status Indicator Location

Table 4-6—DCIO Module - Device Status Indicators

LED	Device Status
Green	On when power is present.
Amber	When On steady indicates device is disabled or must be replaced. Possible Watchdog Timer problem.
	Note
	Blinks one time at power-up.

Table 4-7—DCIO Module - Channel Status Indicators

LED	Channel Status
Red	When On steady indicates the input circuit is closed or the output circuit is active.
Amber	When Blinking indicates a low power condition is present or channel is not properly configured. Steady indicates a channel fault.

8 CHANNEL RELAY MODULE

The Relay Module (see Figure 4-7) has 18 LED status indicators, two for the device and two for each channel, located on the front panel. Refer to Tables 4-8 and 4-9 for a description of the LED indicators.

POWER-UP SEQUENCE

Set the module address switch prior to applying power.

Relay module power-up sequence illuminates the LEDs for the device and all of its channels. First the power and fault LEDs are illuminated, indicating that the device is in a power-up mode. Next the LEDs are illuminated in the following sequences:

- Sequentially each channel active red LED is illuminated, starting with channel 1 and continuing through channel 8.
- When the red LED for channel 8 is illuminated, sequentially each channel active red LED is turned off, starting with channel 1 and continuing through channel 8.
- Next, the channel fault amber LEDs are tested in the same manner as the channel active red LEDs.

When all the LEDs have been illuminated, the relay module displays the device's LON address by illuminating the channel active red LED. LON dip switches 1 through 8 will be displayed on channels 1 through 8. When a dip switch is set to the ON position, the channel active red LED will be illuminated. The address is displayed for two seconds.

Once the address has been displayed, the device's fault LED will turn off.




Figure 4-7—Relay Module Status Indicator Location

Table 4-8—Relay Module - Device Status Indicators

LED	Device Status	
Green	On when power is present.	
Amber	When On steady indicates device is disabled or must be replaced. Possible Watchdog Timer problem.	
	Note	
	Blinks one time at power-up.	

Table 4-9—Relay Module - Channel Status Indicators

LED	Channel Status
Red	When On steady indicates the output circuit is active.
Amber	When Blinking indicates a low power condition is present or channel is not properly configured.

ANALOG INPUT MODULE

The Analog Input Module (see Figure 4-8) has 18 LED status indicators, two for the device and two for each channel, located on the front panel. Refer to Tables 4-10 and 4-11 for a description of the LED indicators.

POWER-UP SEQUENCE

Set the module address switch prior to applying power.

The Analog Input Module power-up sequence illuminates the LEDs for the device and all of its channels. First the power and fault LEDs are illuminated, indicating that the device is in a power-up mode. Next the LEDs are illuminated in the following sequences:

- Sequentially each channel active red LED is illuminated, starting with channel 1 and continuing through channel 8.
- When the red LED for channel 8 is illuminated, sequentially each channel active red LED is turned off, starting with channel 1 and continuing through channel 8.
- Next, the channel fault amber LEDs are tested in the same manner as the channel active red LEDs.

When all the LEDs have been illuminated, the analog input module displays the device's LON address by illuminating the channel active red LED. LON dip switches 1 through 8 will be displayed on channels 1 through 8. When a dip switch is set to the ON position, the channel active red LED will be illuminated. The address is displayed for two seconds.

Once the address has been displayed, the device's fault LED will turn off.




Figure 4-8—Analog Input Module Status Indicator Location

Table 4-10—Analog Input Module - Device Status Indicators

LED	Device Status
Green	On when power is present.
Amber	When On steady indicates device is disabled or must be replaced. Possible Watchdog Timer problem.
	Note
	Blinks one time at power-up.

Table 4-11—Analog Input Module - Channel Status Indicators

LED	Channel Status
Red	When Blinking indicates a low alarm. When On Steady indicates a high alarm.
Amber	When Blinking indicates a low power condition is present or channel is not properly configured. On steady indicates out of range condition.

INTELLIGENT PROTECTION MODULE

The Intelligent Protection Module (see Figure 4-9) has 18 LED status indicators, two for the device and two for each channel, located on the front panel. Refer to Tables 4-12 and 4-13 for a description of the LED indicators.

POWER-UP SEQUENCE

Set the module address switch prior to applying power.

The Intelligent Protection Module power-up sequence illuminates the LEDs for the device and all of its channels. First the power and fault LEDs are illuminated, indicating that the device is in a power-up mode. Next the LEDs are illuminated in the following sequences:

- Sequentially each channel active red LED is illuminated, starting with channel 1 and continuing through channel 8.
- When the red LED for channel 8 is illuminated, sequentially each channel active red LED is turned off, starting with channel 1 and continuing through channel 8.
- Next, the channel fault amber LEDs are tested in the same manner as the channel active red LEDs.

When all the LEDs have been illuminated, the intelligent protection module displays the device's LON address by illuminating the channel active red LED. LON dip switches 1 through 8 will be displayed on channels 1 through 8. When a dip switch is set to the ON position, the channel active red LED will be illuminated. The address is displayed for two seconds.

Once the address has been displayed, the device's fault LED will turn off.

After the power-up sequence, the device will either display an unconfigured state or normal operation state. In the unconfigured state, the channel fault amber LEDs flash ON and OFF at the same rate for all channels.




Figure 4-9—Intelligent Protection Module Status Indicator Location

Table 4-12—Intelligent Protection Module - Device Status Indicators

LED	Device Status		
Green	On when power is present.		
Amber	When On steady indicates device is disabled of must be replaced. Possible Watchdog Time problem.		
Note			
	Blinks one time at power-up.		

Table 4-13—Intelligent Protection Module - Channel Status Indicators

LED	Channel Status
Red	When On steady indicates the input circuit is closed or the output circuit is active.
Amber	When Blinking indicates a low power condition is present or channel is not properly configured. Steady indicates a channel fault.

EMBEDDED LOGIC - PURPOSE

The IPM employs an "Embedded logic" feature that when activated during module configuration can ensure a local level of protection for the hazard during times where communication with the EQP Controller is lost or the EQP Controller is offline for repair or replacement.

EMBEDDED LOGIC – CONTROL TRANSFER SEQUENCE DESCRIPTION

A user configurable selection is provided to choose the operational mode of the IPM. Three modes are provided, two of which utilize the embedded logic feature.

If enabled, the embedded logic is armed at all times but control of the outputs depends on the selected mode.

In the "back-up mode" control of the IPM outputs transfers to the IPM's embedded logic in the event of an IPM diagnosed loss of communications between itself and the EQP Controller.

An IPM diagnosed resumption of normal communications with the Controller will cause control of the IPM outputs to transfer back to the Controller unless a release sequence has been initiated and is not yet complete.

NOTE

Once a release sequence has been initiated within the embedded logic, the sequence will continue until it is complete.

When the embedded logic sequence is complete, a "Manual Reset Required" status condition will be reported by the IPM. User logic within the EQP Controller must be utilized to send a "Reset" command to the IPM that will reset all timers, latches, etc. to their normal state.

If a Detector Electronics S³ Operator Interface Station (OIS) is attached to the EQP Controller, the point display for the IPM can be used to send a reset command.

NOTE

The IPM will not accept a reset command if the "Manual Release" input is in the "alarm" state.

EMBEDDED LOGIC - S3 CONFIGURABLE OPTIONS

The IPM has various configurable options, selected during node configuration in the S³ software package.

Embedded Logic Selection: The IPM has 3 operation modes, Controller Only, Back-up Mode, Embedded Only.

Controller Only: In this mode the I/O of the IPM will be controlled from the EQP Controller only and embedded logic is inactive.

Back-up Mode: (The default selection) the IPM I/O is normally controlled by the EQP Controller but utilizes embedded logic in accordance with the "Control Transfer Sequence Description" to control its I/O under certain circumstances.

Embedded Only: In this mode the IPM continuously operates from its embedded logic. The status of all IPM I/O is available to the EQP Controller but control of the outputs are not; however, controller and S3 reset commands are accepted.

Detection Style - Single or Cross Zoned: A software selection allows either "1 zone release" or "2 zone release" (cross-zoned) operation.

Manual Release Action - Delayed or Not Delayed:

A software selection allows the Manual Release input of the module, channel 2, to be delayed or not delayed. If not delayed, release is immediate. If delayed, the signal will utilize the time delay selected for the release circuits but with a 30-second maximum.

Release Circuit Delay Selection: A time delay is available from when the inputs (channels 2, 4 or 5) go active until the releasing outputs (channels 7 and 8) go active. The bell output (channel 6) is activated immediately when an input becomes active. The time delay selection choices are listed below:

> 0 Second Seconds 10 20 Seconds 30 Seconds 40 Seconds 50 Seconds Seconds

60

NOTE

Manual release is limited to 30 seconds, even if 40, 50 or 60 seconds time delay is selected.

Abort Mode Selection: The IPM abort input, channel 1, is software configurable to use any one of three modes of operation. These three modes operate as follows:

Mode 1: Upon activation, the delay timer will count down to and hold at 10 seconds; upon release, timer will continue to count down to zero. Only this mode complies with UL 864.

Mode 2: Upon activation the delay timer will reset to its initial value and on release will continue counting down to zero.

IRI Mode: Functions similar to "Mode 1" except the abort will only function if activated prior to a second alarm.

Signaling Circuit Configuration - Bell Circuit (SAM), Channel 6: This output channel can be software selected to any standard EQP Signal Audible Module (SAM) configuration. In a crosszoned mode, selections are as follows:

One Zone Mode: The signaling circuit can be configured to any standard SAM selection.

Two Zone Mode: In this mode the user must make two selections. A standard SAM selection for when a single detection circuit is in alarm and another selection for when both detection circuits are in alarm.

EMBEDDED LOGIC - OPERATION

Supervisory Condition: The supervisory input on channel 3 has no embedded logic function and is passed on as information only to the EQP Controller where it is displayed as a supervisory fault.

Alarm Condition - Single Zone Mode: Upon receipt of an alarm from an activated detector on IPM channel 4 or 5 OR activation of the manual station, channel 2:

Signal circuit devices are activated per the software selected signaling circuit configuration described earlier – Bell Circuit Channel 6.

Programmed release time delay activated.

Release output(s) activated.

Operation of Abort: Discharge is aborted ONLY when alarm is from a detector, and abort is activated during programmed release time delay. Abort sequence is dependent on the abort mode selection as described earlier.

Alarm Condition – Two Zone Mode (cross zoned): Upon receipt of an alarm from one activated detector in one zone.

Signal circuit devices are activated per the software selected signaling circuit configuration, two zone mode, one zone in alarm, as described earlier – Bell Circuit Channel 6.

Second Alarm Condition: Upon receipt of an alarm from a second activated detector in the other zone.

Signal circuit devices are activated per the software selected signaling circuit configuration, two zone mode, two zones in alarm, as described earlier – Bell Circuit Channel 6.

Programmed release time delay activated.

Release output(s) activated.

Manual Alarm Condition – Two Zone Mode (cross zoned):

Upon receipt of a manual alarm from Channel 2:

Signal circuit devices are activated per the software selected signaling circuit configuration, two zone mode, two zones in alarm, as described earlier – Bell Circuit Channel 6.

Programmed release time delay activated.

Release output(s) activated.

Module Reset: After completion of the release output(s) timer, if no alarm condition is present on channel 2 (Manual Release) then the module can be reset via soft command on the S3 Module Point Display or if the EQP Controller is offline, by holding the Abort input, Channel 1, active momentarily.

When reset, the IPM will de-energize the two detector circuits, channels 4 and 5, for two seconds to reset the smoke detectors. Any latched outputs will also be reset.

Release Outputs: When commanded to release, the release output(s) will energize for the configured time and then de-energize.

EQ21xxPSM POWER SUPPLY MONITOR

The power supply monitor (see Figure 4-10) has three LEDs used to provide a visual indication of device status:




Figure 4-10—EQ21xxPSM Status Indicator Location

Table 4-14—Power Supply Monitor Status Indicators

LED	Device Status
Green	When On indicates power is supplied to device.
Red	When Flashing indicates an alarm or fault condition is present.
Amber	When on indicates device is disabled. Module must be replaced.

EQ2220GFM GROUND FAULT MONITOR

The ground fault monitor (see Figure 4-11) has three LEDs used to provide a visual indication of device status:




Figure 4-11—Ground Fault Monitor Status Indicator Location

Table 4-15—Ground Fault Monitor Status Indicators

LED	Device Status		
+ GND FLT LED	Indicates Amber in the presence of a "+" ground fault.		
– GND FLT LED	Indicates Amber in the presence of a "-" ground fault.		
POWER LED	Indicates Green when the unit is powered.		

NOTE

The Ground Fault Monitor LED will respond immediately to a ground fault condition. The relay contact requires the condition to exist for 10 seconds before it activates.

EQ22xxIDC SERIES INITIATING DEVICE CIRCUIT (IDC)

The IDC has three LEDs (located at the center of the IDC communication module circuit board) to provide a visual indication of device status.

NOTE

The Initiating Device Circuit Ground Fault Monitor responds to the presence of a ground fault within the power circuitry. It provides a supervised dry contact input and ground fault monitoring circuitry for indicating a power supply trouble condition.

NOTE

A blinking red LED on an IDCSC indicates trouble such as a wiring fault (open or short circuit) or not configured.

Table 4-16—Initiating Device Circuit Status Indicators

LED	Device status		
Green	When On indicates device has power.		
Red	When On indicates an Alarm or Fault condition is present. On steady = One of the inputs is active. Blinking = Fault condition such as an open input circuit or not configured.		
Amber	When On indicates a device is disabled. Module must be replaced.		

EQ22xxDCU AND EQ22xxDCUEX DIGITAL COMMUNICATION UNITS

The DCUs have three LEDs to provide a visual indication of device status. They are visible through the window on the enclosure cover.

NOTE

If the communication module has not been configured, the red LED blinks at a 4 Hz rate.

NOTE

The amber LED is provided for factory diagnostic purposes and is not used in the system. Illumination of the amber LED normally indicates a failure in the communication chip. Replacement of the communication module circuit board is required.

Table 4-17—DCU Status Indicators

Device Status	LED Status
Power-up	Pulsed at a rate of 0.5 Hz
Calibration	Pulsed at a rate of 1 Hz or on steady
Fault	Pulsed at a rate of 4 Hz
Alarm	On steady

EQ25xxARM AGENT RELEASE MODULE

The EQ25xxARM has three LEDs to indicate device status. They are located at the center of the circuit board.

Table 4-18—Agent Release Module Status Indicators

LED	Device Status		
Green	When On indicates device has power.		
Red	When On steady indicates an output is activated.		
	When Blinking at a 4 Hz rate with the LED on 50%, off 50% of the time indicates a local trouble condition such as an open output circuit or low solenoid supply voltage.		
	When Blinking at a 1 Hz rate with the LED on 5%, off 95% of the time indicates an isolate condition.		
	When Blinking at a 1 Hz rate with the LED on 95%, off 5% of the time indicates release and isolate.		
Amber	When On indicates a malfunction in the electronic circuitry. Module replacement is required.		

EQ25xxSAM SIGNAL AUDIBLE MODULE

The EQ25xxSAM has three LEDs to indicate device status. They are located at the center of the circuit board.

Table 4-19—Signal Audible Module Status Indicators

LED	Device Status
Green	When On indicates device has power.
Red	When On steady indicates an Active condition exists. When Blinking indicates a Trouble condition exists.
Amber	When On indicates a malfunction in the electronic circuitry. Module replacement is required.

EQ24xxNE NETWORK EXTENDER

The EQ24xxNE has three LEDs (one green, two amber) for indicating device status.

Table 4-20—Network Extender Status Indicators

LED	Device Status
Green	When On indicates device has power.
	Flashes to indicate messages are being transferred
	over the LON.
Amber	When On indicates a malfunction in the electronic
	circuitry. Module replacement is required.
	Note
	When a network extender has an internal
	fault, the message display will only indicate
	that there is a LON fault condition existing
	somewhere on the LON.

SYSTEM STARTUP

PRE-OPERATION CHECKS

General

Insulate all shields to prevent shorts to device housing or to any other conductor.

Place alarm/release output in "Bypass/Isolate" when servicing devices.

Maintain a log book containing the type and serial numbers of devices as well as the location and date of installation.

Maintain a log of maintenance activities.

Observe normal precautions for handling electrostatic sensitive devices.

LON

Rocker switches for each LON device must be set to the desired address prior to power-up.

Test the loop with no power applied. DC resistance should be equal on A and B.

Check polarity on A and B (no rolls). COM 1 connects to COM 2; COM 2 connects to COM 1. A connects to A and B to B.

Measure voltage. A to chassis ground measures approximately +7.5 vdc. B to ground measures approximately -7.5 vdc.

Measure signal (400 mv P-P min.). (Use oscilloscope if possible).

Check fault tolerance by introducing a short.

Controller

The I/O and LON wiring is correctly installed, observing polarity. All cable shields are properly terminated and insulated.

Power wiring is installed and power source is operational.

Chassis ground stud must be connected to earth ground.

Redundant Controller

The I/O and LON wiring is correctly installed, observing polarity. All cable shields are properly terminated and insulated.

Power wiring is installed and power source is operational.

Chassis ground stud must be connected to earth ground.

The HSSL cable is connected between the two controllers.

EDIO/DCIO Module

Verify correct address setting.

Check signal circuits for correct polarity.

Check for correct installation of EOL resistors.

Relay Module

Verify correct address setting.

Check for correct output connections.

Analog Input Module

Verify correct address setting.

Check for correct input connections.

Check each channel with a loop current input.

Intelligent Protection Module

Verify correct address setting.

Check for correct input/output connections.

Power Supplies and Power Monitors

Verify all earth ground connections as specified in the wiring instructions.

Verify correct ac power to supply.

Check power distribution to ensure that all devices are receiving power.

Check power trouble indicator by introducing an open to the battery.

Ground Fault Monitor

Verify earth ground connections as specified in the wiring instructions.

Check power distribution to ensure that all devices are receiving power.

DCUs

Verify correct address setting.

Check modules for correct orientation.

Check for the presence of contaminants or poisoning agents.

Device should be oriented with the sensor pointing down.

IDCs

Verify correct address setting.

Check for correct installation of EOL resistors.

ARMs

Verify correct address setting.

Check jumpers.

SAMs

Verify correct address setting.

Check signal circuits for correct polarity.

Check for correct installation of EOL resistors.

Check jumpers.

GENERAL START-UP PROCEDURES

- 1. Output loads that are controlled by the system should be secured (remove power from all output devices) to prevent actuation.
- 2. Check all system wiring for proper connection.
- 3. Inspect all devices to verify that they have not been physically damaged in shipment.
- 4. Apply power to the system.

NOTE

To prevent the network modules from going into a fault isolation condition, apply power to the EQP Controller prior to applying power to the network devices.

5. Program the system for the desired operation using Det-Tronics Safety System Software (S³). Download configuration data to all devices.

NOTE

After system configuration has been completed, the entire system should be tested for proper operation to ensure that configuration was performed properly.

- 6. Calibrate the sensors.
- 7. Ensure that all trouble and alarm conditions have been cleared and the EQP Controller is reset, then remove mechanical blocking devices (if used) and restore power to the output loads.

START-UP PROCEDURE FOR CONTROLLER

The Controller is powered-up when the Power Supply is turned on. When the Power Supply has been powered-up, verify power at the Controller by verifying that the Green LED indicator is on. This indicator is located on the front of the Controller.

To verify that the Controller is powered-up and operating properly, ensure that:

- When power is first applied, all LEDs are on. The ACK LED flashes while the memory test is running. When initialization is complete, only the green power LED remains lit.
- The serial link indicators if active continuously flash.
- 3. The Text display runs an initialization routine. When initialization is complete and if all alarms and trouble conditions are cleared, the text display shows the current time and date. If the controller has been unpowered for more than 12 hours, the time and date may have to be set. If an alarm or trouble condition exists, it will be displayed until the condition is corrected and the Reset button is pressed.

If the controller has not been software configured, unconfigured devices will be displayed. Configuration must be done using S3 Safety System Software before proceeding.

- 4. The LEDs on the front panel provide an indication of the system status.
- 5. Ensure configuration was performed properly.
- After any modifications have been made either to the installation or to configuration software, always check the entire system for proper operation in order to ensure that the changes were performed properly.

STARTUP PROCEDURE FOR EDIO MODULE

Configuration

The EDIO Module is an eight-channel device. Each channel is capable of being configured as an input or output, independent of any other channel.

NOTE

The module is configured using Det-Tronics Safety System Software.

Activation Time

Timers are made available for output circuits only. Timers are used primarily to set the timing of output release in a suppression system. Timers provide a pulse timed output for the time period specified in the configuration of the channel. The channel output goes active when commanded by the system logic and remains on until the timer expires.

Static Logic Mode

Each input channel can be configured as a Fire Alarm, Trouble, Low Gas Alarm, High Gas Alarm, Supervisory, or Other type of channel, independent of any other channel configuration. The type selected determines the logic the system uses to configure Indicators, Alarms and Messages.

For example: When an input is selected as Fire type, the Fire LED on the Controller and Audible alarm will automatically actuate when that input channel is active.

EDIO Startup

- 1. The Power-on LED should be illuminated. The Fault LED should blink once on power up, then remain off.
- 2. The input circuits should indicate the proper state of the input device (channel active LED illuminates when the circuit is closed). Check the input power supply and associated wiring. Verify proper voltage per the Troubleshooting matrix.
- 3. The output circuits should indicate the proper state for the programmed device (channel active LED illuminates when the circuit is active). Check the power supply and associated wiring. Verify proper voltage per the Troubleshooting matrix.
- 4. The circuits should not indicate a fault condition (channel fault LED illuminates when the circuit is in fault). Check the end-of-line devices and associated wiring. Verify proper voltage per the Troubleshooting matrix.
- 5. Test the entire system for proper operation to ensure that the configuration was performed properly.

STARTUP PROCEDURE FOR DCIO MODULE

Configuration

The DCIO Module is an eight-channel device. Each channel is capable of being configured as an input or output, independent of any other channel.

NOTE

The module is configured using Det-Tronics Safety System Software.

Activation Time

Timers are made available for output circuits only. Timers are used primarily to set the timing of output release in a suppression system. Timers provide a pulse timed output for the time period specified in the configuration of the channel. The channel output goes active when commanded by the system logic and remains on until the timer expires.

Static Logic Mode

Each input channel can be configured as a Fire Alarm, Trouble, Low Gas Alarm, High Gas Alarm, Supervisory, or Other type of channel, independent of any other channel configuration. The type selected determines the logic the system uses to configure Indicators, Alarms and Messages.

For example: When an input is selected as Fire type, the Fire LED on the Controller and Audible alarm will automatically actuate when that input channel is active.

DCIO Startup

- 1. The Power-on LED should be illuminated. The Fault LED should blink once on power up, then remain off.
- The input circuits should indicate the proper state
 of the input device (channel active LED
 illuminates when the circuit is closed). Check the
 input power supply and associated wiring. Verify
 proper voltage per the Troubleshooting matrix.
- 3. The output circuits should indicate the proper state for the programmed device (channel active LED illuminates when the circuit is active). Check the power supply and associated wiring. Verify proper voltage per the Troubleshooting matrix.
- 4. The circuits should not indicate a fault condition (channel fault LED illuminates when the circuit is in fault). Check the end-of-line devices and associated wiring. Verify proper voltage per the Troubleshooting matrix.
- 5. Test the entire system for proper operation to ensure that the configuration was performed properly.

Relay Module Startup

- 1. The Power-on LED should be illuminated. The Fault LED should blink once on power up, then remain off.
- 2. The output circuits should indicate the proper state for the programmed device (channel active LED illuminates when the circuit is active).
- 3. Test the entire system for proper operation to ensure that the configuration was performed properly.

Analog Input Module Startup

- The Power-on LED should be illuminated. The Fault LED should blink once on power up, then remain off.
- 2. The input circuits should indicate the proper state for the programmed device (channel active LED illuminates when the circuit is active).
- 3. The circuits should not indicate a fault condition (channel fault LED illuminates when the circuit is in fault).
- 4. Test the entire system for proper operation to ensure that the configuration was performed properly.

Intelligent Protection Module Startup

- 1. The Power-on LED should be illuminated. The Fault LED should blink once on power up, then remain off.
- 2. The output circuits should indicate the proper state for the programmed device (channel active LED illuminates when the circuit is active).
- 3. The circuits should not indicate a fault condition (channel fault LED illuminates when the circuit is in fault).
- 4. Test the entire system for proper operation to ensure that the configuration was performed properly.

Section 5 Maintenance

ROUTINE MAINTENANCE

To ensure reliable protection, it is important to check and calibrate the system on a regularly scheduled basis. The frequency of checks is determined by the requirements of the particular installation.

BATTERIES

Batteries **must** be replaced every 48 months, or sooner if required by local codes.

▲IMPORTANT!

Only sealed batteries are to be used.

MANUAL CHECK OF OUTPUT DEVICES

It is important that response devices be checked initially when the system is installed, as well as periodically during an on-going maintenance program.

ACAUTION!

Be sure to secure all output devices that are actuated by the system to prevent unwanted activation of equipment, and remember to place these output devices back into service when the checkout is complete.

O-RING MAINTENANCE

∆WARNING!

The hazardous area must be de-classified prior to removing a junction box cover with power applied.

A rubber O-ring is used to ensure that the junction box cover will seal tightly and provide protection against water entry. The enclosure should be opened periodically, and the O-ring inspected for breaks, cracks and dryness.

To test O-ring: remove it from the enclosure and stretch it slightly. If cracks are visible, replace it. If it feels dry, a thin coating of lubricant should be applied. When re-installing the O-ring, be sure that it is properly seated in the housing groove. It is imperative that this O-ring be properly installed and in

good condition. Failure to properly maintain it can allow water to enter the enclosure and cause premature failure. A coating of lubricant should also be applied to the threads on the cover before reassembling the enclosure. This will both lubricate the cover threads and help prevent moisture from entering the enclosure.

⚠ CAUTION!

The O-rings should be lubricated with a silicone free grease. The use of other lubricants is not recommended, since they can adversely affect the performance of some sensors. Under no circumstances should a lubricant or compound containing silicone be used on systems using catalytic type combustible gas sensors.

GAS SENSOR MAINTENANCE

All gas sensors must be calibrated on a regular basis. Calibration should typically be performed every 90 days for catalytic and electrochemical sensors.

Catalytic sensors have a finite lifespan. If a successful calibration cannot be performed, replace the sensor and recalibrate following the procedure described in the "Calibration" section below. Always compare part numbers to be sure that the correct replacement sensor is being used.

△CAUTION!

Exposure of the sensor to high concentrations of combustible gases for extended periods of time can introduce stress to the sensing element and seriously affect its performance. After exposure, recalibration should immediately be performed, and the sensor should be replaced if necessary.

NOTE

Electrochemical sensors have a finite lifespan. If a successful calibration cannot be performed, inspect the hydrophobic filter. If the filter is plugged, replace it and recalibrate the sensor. If the filter is in good condition, replace the sensor. Recalibrate following the procedure described in the "Calibration" section.

CALIBRATION AND ADJUSTMENTS

To ensure optimum performance, calibration must be performed on a regularly scheduled basis. Since each application is different, the length of time between regularly scheduled recalibrations can vary from one installation to the next. In general, the more frequently a system is checked, the greater the reliability.

▲IMPORTANT!

4 to 20 ma devices not manufactured by Det-Tronics must be pre-calibrated. To ensure adequate protection, calibration must be performed on a regularly scheduled basis.

NOTE


If the calibration procedure is not completed within 12 minutes, the detector will revert back to the previous calibration values. The red LED will blink. The calibration will be logged as aborted.

NOTE

The "Sensor Replacement" calibration procedure must be used for the initial calibration of a new sensor. The "Routine Calibration" procedure can be used for all subsequent calibrations.

NOTE

Some calibration procedures require the operator to activate the reed switch located on a circuit board inside the junction box. See Figure 5-1 for reed switch location. To activate the switch, hold the calibration magnet against the side of the junction box near the switch location approximately one inch above the mounting surface. (Do not open the junction box.) Hold the calibration magnet in place for approximately 4 seconds to initiate the calibration procedure.



* TO ACTIVATE THE MAGNETIC REED SWITCH, HOLD THE CALIBRATION MAGNET AGAINST THE SIDE OF THE ENCLOSURE AT THE LOCATION OF THE REED SWITCH, APPROXIMATELY ONE INCH ABOVE THE MOUNTING SURFACE.

Figure 5-1—DCU Terminal Wiring Board Mounted in Six-Port
Junction Box

CALIBRATION ALGORITHM A FOR MANUAL CALIBRATION OF UNIVERSAL DCU

Normal Calibration

- 1. Activate the reed switch. (The red LED blinks while the reed switch is closed.)
- 2. After the reed switch has been closed for 3 seconds, the calibrate LED blinks, indicating it is ready for the zero input.
- 3. Enter the zero input (4 ma).
- 4. Activate the reed switch. (The red LED blinks while the switch is closed.)
- After the reed switch has been closed for 3 seconds, the communication module records the uncalibrated value in the calibration log and calibrates the zero value. (The calibrate LED stays on steady.)
- 6. Apply the calibration gas.
- 7. The calibrate LED blinks as the input increases.
- 8. Activate the reed switch. (The red LED blinks while the reed switch is closed.)
- 9. The communication module records the uncalibrated value in the calibration log and calibrates the span value after the reed switch is on for 3 seconds.
- 10. The calibrate LED stays on steady.

- 11. Remove the span gas, and return the analog input to normal.
- 12. Activate the reed switch. (The red LED blinks for 3 seconds while the reed switch is closed)
- 13. The calibration is complete. The calibrate LED turns off.

NOTE

If the calibration is not completed within 12 minutes, the previous calibration values are restored and the calibration is logged as aborted. The calibrate LED will flash.

Sensor Replacement

MWARNING!

The hazardous area must be de-classified prior to removing a junction box cover with power applied.

- Open the junction box cover and press the Sensor Replacement Switch.
- 2. The calibrate LED on the communication module will flash, indicating it is ready for the zero input.
- 3. Replace the sensor and apply the zero input (4 ma).
- 4. Activate the reed switch. (The red LED flashes for 3 seconds while the switch is closed.)
- 5. The communication module records the uncalibrated value in position one of the calibration log and calibrates the zero value. (The calibrate LED stays on steady.)
- 6. Apply the calibration gas.
- 7. The calibrate LED flashes when the input increases.
- 8. Activate the reed switch. (The red LED flashes for 3 seconds while the reed switch is closed.)
- 9. The communication module records the uncalibrated value in the first register of the calibration log and calibrates the span value.
- 10. The calibrate LED stays on steady.
- 11. Remove the span gas and return the analog input to normal.
- 12. Activate the reed switch. (The red LED flashes for 3 seconds while the switch is closed.)

13. The calibration is complete. (The calibrate LED turns off.)

NOTE

Pressing the Sensor Replacement Switch aborts calibration and starts over.

NOTE

Resetting the communication module will abort the sensor replacement.

CALIBRATION ALGORITHM C FOR COMBUSTIBLE GAS DCUs AND AUTOMATIC CALIBRATION OF UNIVERSAL DCUs

△CAUTION!

After exposing the H_2S sensor to high concentrations of gas, it should be exposed to fresh air for at least 30 minutes, and recalibrated.

Routine Calibration

- 1. Apply the zero gas.
- 2. Activate the reed switch for at least 4 seconds. (The red LED flashes for 3 seconds while the switch is activated.)
- 3. The calibrate LED on the communication module flashes, indicating it is ready for the zero input.
- 4. Wait until the calibrate LED stays on steady (approximately 4 seconds).

NOTE

The communication module records the uncalibrated value in the calibration log and calibrates the zero value during this time.

- 5. Apply the calibration gas. (The calibrate LED flashes when the sensor detects gas.)
- 6. When the sensor input has been stable for 30 seconds, the communication module records the uncalibrated value in the calibration log, and calibrates the span value.
- 7. The calibrate LED stays on steady.
- 8. Remove the calibration gas.
- 9. The communication module waits until the sensor input drops below 4% full scale.

10. The calibration is complete. (The calibrate LED turns off.)

NOTE

If the calibration procedure is not completed within 12 minutes, calibration will be aborted and the detector will revert back to the previous calibration values. The red LED will flash and the calibration will be logged as aborted.

Sensor Replacement — Combustible Gas (CGS Sensor)

NOTE

When replacing a sensor, compare part numbers to be sure that the correct replacement sensor is being used.

△WARNING!

The hazardous area must be de-classified prior to removing a junction box cover with power applied.

- 1. Remove the cover from the DCU enclosure.
- 2. Press the Sensor Replacement Switch on the communication module for approximately 1 second. (The calibrate LED on the communication module flashes, indicating that it is ready for the zero input.)

NOTE

Pressing the sensor replacement switch prevents the communication module from generating a fault signal when the input drops to zero due to sensor removal. The calibration will **not** be aborted if the calibration procedure is not completed within 12 minutes.

- 3. Move the Calibration Switch to the "calibrate" position.
- 4. Replace the sensor.
- 5. Connect a volt meter to the test points on the transmitter board. Connect the "+" lead to TP1 (red). Connect the "-" lead to TP2 (black).
- 6. Wait at least 5 minutes for the sensor output to stabilize, then adjust R2 for a reading of 0.40 vdc (4 ma) on the meter.

NOTE

Do not make adjustments to R1 when calibrating the sensor.

Move the Calibrate Switch to the "normal" position.

- 8. Activate the reed switch for 4 seconds. (The red LED flashes for 3 seconds while the switch is activated.) The communication module records the uncalibrated value in position one of the calibration log and calibrates the zero value. The calibrate LED goes on steady.
- Move the Calibration Switch to the "calibrate" position.
- 10. Apply the calibration gas and wait for the output to stabilize.
- 11. With 50% LFL calibration gas applied to sensor, adjust R3 for a reading of 1.2 vdc (12 ma) on the volt meter.
- 12. Move the Calibrate Switch to the "normal" position. (The red LED flashes.)
- 13. Activate the reed switch. The red LED flashes for 3 seconds while the switch is activated.
- 14. The communication module records the uncalibrated value in the first register of the calibration log and calibrates the span value. The calibrate LED stays on steady.
- 15. Remove the calibration gas and replace the DCU enclosure cover.
- 16. The communication module waits until the analog value drops below 4% full scale. The calibration is complete. (The calibrate LED turns off.)

NOTE

Pressing the Sensor Replacement Switch aborts the current calibration.

Sensor Replacement — Toxic Gas

NOTE

When replacing a sensor, compare part numbers to be sure the correct replacement sensor is being used.

MWARNING!

The hazardous area must be de-classified prior to removing a junction box cover with power applied.

- 1. Remove the cover from the DCU enclosure.
- Press the Sensor Replacement Switch on the communication module for approximately 1 second. (The calibrate LED flashes, indicating it is ready for the zero input.)

NOTE

Pressing the Sensor Replacement Switch prevents the communication module from generating a fault signal when the input drops to zero due to sensor removal. The calibration will **not** be aborted if the calibration procedure is not completed within 12 minutes.

- 3. Replace the sensor.
- Wait at least 5 minutes for the sensor output to stabilize.
- Activate the reed switch. (The red LED flashes for 3 seconds while the switch is activated.) The communication module records the uncalibrated value in position one of the calibration log and calibrates the zero value. (The calibrate LED stays on steady.)
- 6. Apply the calibration gas. (The calibrate LED flashes when the input increases.)
- 7. Activate the reed switch. (The red LED flashes for 3 seconds while the switch is activated.)
- 8. The communication module records the uncalibrated value in the first register of the calibration log and calibrates the span value. (The calibrate LED stays on steady.)
- Remove the calibration gas and replace the DCU enclosure cover.
- 10. The communication module waits until the analog value drops below 4% full scale. The calibration is complete. (The calibrate LED turns off.)

NOTE

Pressing the Sensor Replacement Switch aborts the calibration and starts over.

CALIBRATION ALGORITHM D FOR UNIVERSAL DCUs WITH O₂ SENSOR

Normal Calibration

- 1. Apply clean air (20.9% oxygen).
- Activate the reed switch for at least 4 seconds. (The red LED flashes for 3 seconds while the switch is closed.)
- 3. The calibrate LED flashes, indicating calibration has begun.

- 4. The communication module waits 3 seconds.
- 5. The communication module records the uncalibrated value in the calibration log and calibrates the span value.
- 6. The calibrate LED stays on steady.
- 7. The communication module waits 3 seconds.
- 8. Calibration is complete. (The calibrate LED turns off.)

Sensor Replacement

Mwarning!

The hazardous area must be de-classified prior to removing a junction box cover with power applied.

- 1. Open the junction box cover and press the Sensor Replacement Switch.
- 2. The calibrate LED on the communication module flashes, indicating it is ready for the zero input.
- 3. Replace the sensor and set the Sensor Switch (located on the sensor cell) to zero.
- 4. Activate the reed switch. (The red LED flashes for 3 seconds while the switch is closed.)
- 5. The communication module records the uncalibrated value in position one of the calibration log and calibrates the zero value. The calibrate LED stays on steady.
- 6. Set the Zero Switch on the sensor to the "normal" position. Apply clean air (20.9% oxygen) to set the sensor analog span value.
- 7. The calibrate LED flashes when the input goes high.
- 8. Activate the reed switch. (The red LED flashes for 3 seconds while the switch is closed.)
- 9. The communication module records the uncalibrated value in the first register of the calibration log and calibrates the span value.
- 10. The calibration is complete. The calibrate LED turns off.

NOTE

Pressing the sensor replacement switch aborts the calibration.

CALIBRATION ALGORITHM G FOR DCUs WITH POINTWATCH OR DUCTWATCH

Routine Calibration

- 1. Apply the zero gas.
- 2. Activate the reed switch for at least 4 seconds. (The red LED flashes for 3 seconds while the switch is activated.)
- 3. The calibrate LED flashes, indicating it is ready for the zero input.
- 4. When a steady zero reading is obtained, the communication module records the uncalibrated value in the calibration log and calibrates the zero value during this time. The LED stays on steady.
- 5. Apply calibration gas. (The calibrate LED flashes when the sensor detects gas.)
- 6. When the sensor input has been stable for 30 seconds, the communication module records the uncalibrated value in the calibration log and calibrates the span value.
- 7. The calibrate LED stays on steady.
- 8. Remove the calibration gas.
- 9. The communication module waits until the sensor input drops below 4% full scale.
- 10. The calibration is complete. (The calibrate LED turns off.)

NOTE

Calibration is aborted if not complete within 12 minutes. If not completed, the detector will revert back to the previous calibration values. The red LED will flash and the calibration will be logged as aborted.

Sensor Replacement

MWARNING!

The hazardous area must be de-classified prior to removing a junction box cover with power applied.

 Remove power from the DCU and PointWatch/DuctWatch unit. Replace the PointWatch unit. Apply power. Press the Sensor Replacement Switch on the communication module for approxImately 1 second.

NOTE

Allow at least 10 minutes for the sensor to warm up.

NOTE

Pressing the Sensor Replacement Switch prevents the communication module from generating a fault signal when the input drops to zero.

NOTE

The calibration will not be aborted if the calibration procedure is not completed within 12 minutes.

- 2. Apply zero gas.
- 3. The calibrate LED flashes, indicating that it is ready for the zero input.
- 4. Continue from step 4 of the PointWatch/DuctWatch routine calibration procedure described above.

DEVICE CALIBRATION LOGS AND RECORDS

The DCU keeps a calibration log in non-volatile memory that can be used by the operator to evaluate the remaining life of some sensors. This log includes the zero, span, date and time for each successful calibration. An aborted calibration is indicated by zeros in the zero and span values. The calibration log is cleared when the sensor replacement switch is pressed and the calibration is successfully completed.

The initial calibration is logged in position one, where it remains for the life of the sensor. If more than 8 calibrations are performed without the sensor replacement switch being pressed, the newest calibration data will replace the second oldest so that the initial calibration data can be saved. The old calibration data will be lost. This feature enables sensor sensitivity trending to aid in maintenance or troubleshooting.

The analog value for the sensor is represented in raw analog-to-digital counts 0 to 4095, where 0 represents 0 ma and 4095 represents 24 ma.

TROUBLESHOOTING

Tables 5-1 and 5-2 are provided to assist in locating the source of a system problem.

Table 5-1—System Controller Troubleshooting Guide

Symptom	Possible Cause	Corrective Action	
Controller Power LED/ Text Display OFF.	No Power to Input.	 Measure input voltage (18 to 32 VDC). Check that P1 is fully inserted. If voltage is present and P1 is fully inserted, replace controller. 	
LON Fault – LED lit.	LON wiring is shorted or open.	 Check that P7 is fully inserted. Using the EQ Safety System Software, determine the location of open or short via LON Diagnostics screen. Use a multimeter to determine wiring fault. 	
Trouble Relay is Active.	Any monitored device in the system including ground fault in fault condition.	 Using the front panel display/controls, view all points in alarm/fault and identify faulted device. Repair or replace faulted device as necessary. 	
Digital inputs are not responding.	 Bad input switch. Faulty input channel. Faulty wiring. Configuration error. 	 Check that P2 and P3 are fully inserted. Using a voltmeter, measure input terminals with contact closed to the input (measures 0 vdc when input contact is closed, measures approximately 23 vdc with circuit open and 24 vdc input at the controller). If input does not respond to a contact closure, replace module (verify response with EQ Safety System Software/textual display). Verify configuration. 	
Relay outputs are not responding to an output command.	Bad relay channel.Faulty output wiring.User logic.	 Check that P4 and P5 are fully inserted. When output should be energized, measure contact resistance using an ohm meter. Verify that wiring from output is not open. Using EQ Safety System Software, verify that logic is trying to operate the channel. 	
Serial links are not responding.	 Faulty wiring. Incorrect serial link configuration. Text display shows "Invalid Configuration" 	 Check that P8 and P9 are fully inserted. Verify that communication LEDs are flashing. Verify that serial link configuration matches the host device. Verify that wiring is not open or shorted. 	
Front panel pushbuttons are not working.	- Power OFF. - Controller is faulted.	Verify that power is present and P1 is fully inserted.Cycle power to controller.	
Text display indicates a RTC Fault.	Power loss for more than 12 hours.	- Using the Safety System Software, execute "Set RTC", which downloads the current time into the Controller's real time clock. Alternatively, use the "Set Time and Date" menu in the Controller.	

Table 5-2—Troubleshooting Guide - DCIO Module

I/O Type	Normal (Off)	Normal (On)	Open (Off)	Open (On)	Short (Off)	Short (On)
Unsupervised Input	-15.4	0	-15.4	-15.4	0	0
Supervised Input (EOL Resistor)	-14.4	0	-15.4	-15.4	0	0
Supervised Input (EOL/Inline Resistors)	-15.4	–15	-15.4	-15.4	0	0
Unsupervised Output	-15.4	23.9	-15.4	23.9	0	0
Supervised Output (Agent Release)	0 to 2.1 Note 2	23.9	-15.4	23.9	0	0
Supervised Output (Notification)	-14.4	23.9	-15.4	23.9	0	0

Notes:

- 1. All measurements are in Volts and are measured in reference to the common terminal and 24.0 Vdc is the module's input.
- 2. Value is dependent on the resistance of the solenoid attached.

REPLACEMENT PARTS

Eagle Quantum Premier devices are not designed to be repaired in the field. If a problem should develop, first carefully check for proper wiring, programming and calibration. If it is determined that the problem is caused by an electronic defect, the device must be returned to the factory for repair.

NOTE

When replacing a device, be sure that all rocker switches on the replacement are set the same as the original device. Consult the settings documented during system installation and setup to determine proper settings for the new device. Remove power before removing a device or plugging in a replacement unit. When a device is replaced, configuration is done automatically.

DEVICE REPAIR AND RETURN

Prior to returning devices or components, contact the nearest local Detector Electronics office so that a Service Order number can be assigned. A written statement describing the malfunction must accompany the returned device or component to expedite finding the cause of the failure.

Pack the unit or component properly. Use sufficient packing material in addition to an antistatic bag or aluminum-backed cardboard as protection from electrostatic discharge.

Return all equipment transportation prepaid to the factory in Minneapolis.

ORDERING INFORMATION

When ordering, please specify:

POWER SUPPLIES

Part Number	Description
006979-001	EQ21xxPSM Power Supply Monitor
000604-013	EQ2110PS Power Supply (10 A / 60 Hz)
000604-014	EQ2130PS Power Supply (30 A / 60 Hz)
000604-015	EQ2175PS Power Supply (75 A / 60 Hz)
000604-034	EQ2111PS Power Supply (10 A / 50 Hz)
000604-035	EQ2131PS Power Supply (30 A / 50 Hz)
000604-036	EQ2176PS Power Supply (75 A / 50 Hz)
007941-001	EQ2220GFM Ground Fault Monitor

LON DEVICES

Part Number	Description					
006608-xxx	EQ22xxIDC Initiating Device Circuit					
006943-xxx	EQ22xxIDCGF Ground Fault Monitor					
007257-xxx	EQ22xxIDCSC Initiating Device					
	Circuit Short Circuit					
006607-xxx	EQ22xxDCU Digital Communication					
	Unit (specify gas)					
006733-xxx	EQ25xxARM Agent Release Module					
006738-xxx	EQ25xxSAM Signal Audible Module					
006941-xxx	EQ24xxNE Network Extender					
008056-001	HART Interface Module					
008982-001	LON Termination Module					

Refer to the OS number matrix on the following page for the following devices:

EQ300X EQP Controller
EQ3700DCIO DCIO Module
EQ3710AIM Analog Input Module
EQ3720RM Relay Module
EQ3730EDIO Enhanced Discrete Input/Output Module
EQ3740IPM Intelligent Protection Module

Controller Matrix

MODEL	DESCF	DESCRIPTION				
EQ3001	Eagle 0	Eagle Quantum Premier Controller				
	TYPE	MOUN	TING O	PTION		
	D	Din Ra	il			
	Р	Panel				
	TYPE	сом в	COM Board 1			
		N	None			
		С	Control	Net		
			TYPE	СОМ В	loard 2	
			N	None		
	S Serial					
				TYPE	APPROVAL AGENCY	
W FM/CSA/C					FM/CSA/CENELEC*/CE	

Redundancy

Part No.	Description
008981-001	Controller to Controller High-Speed Serial Link Cable (4 ft)
008982-001	LON Termination Module

Controller Communication Cables

		Length			
Part No.	Description	15 ft. (4.57 m)	30 ft (9.14 m)	50 ft. (15.24 m)	
007633-001	Controller RS-232 Cable (DB9 Female PC Connection)	Х			
007633-002	Controller RS-232 Cable (DB9 Female PC Connection)		Х		
007633-003	Controller RS-232 Cable (DB9 Female PC Connection)			Х	

DCIO Module Matrix

MODE	L	DESCRIPTION				
EQ370	00	8 Channe	el Direct Co	urrent Input/Output (DCIO) Module		
		TYPE	TYPE MOUNTING OPTION			
		D	Din Rail			
		Р	Panel			
			TYPE	APPROVAL AGENCY		
			A FM & CSA			
			W FM/CSA/CENELEC*/CE			

Analog Input Module Matrix

MODEL	DESCRIPTION					
EQ3710	8 Channel Analog Input Module					
	TYPE	MOUNTING OPTION				
	D	Din Rail				
	Р	Panel	Panel			
		TYPE	APPROVAL AGENCY			
	W FM/CSA/CENELEC*/CE					

Relay Module Matrix

MODEL	DESCRIPTION					
EQ3720	8 Channe	el Relay M	odule			
	TYPE	TYPE MOUNTING OPTION				
	D	Din Rail	Din Rail			
	Р	Panel				
		TYPE	APPROVAL AGENCY			
		A FM & CSA				
	W FM/CSA/CENELEC*/CE					

Enhanced Discrete Input/Output Module Matrix

MODEL	DESCRIPTION				
EQ3730	Enhanced Discrete Input/Output Module				
	TYPE	MOUNTI	MOUNTING OPTION		
	D	Din Rail			
	Р	Panel			
		TYPE	APPROVAL AGENCY		
		W	FM/CSA/CENELEC*/CE		

Intelligent Protection Module Matrix

MODEL	DESCRIPTION				
EQ3740	Intelligent Protection Module				
	TYPE	TYPE MOUNTING OPTION			
	D	Din Rail			
	Р	Panel			
		TYPE APPROVAL AGENCY			
		W FM/CSA/CENELEC*/CE			

 $^{^*}$ Component certification

COMBUSTIBLE GAS SENSORS

Table 5-3—Combustible Gas Sensors

OS Number	Part Number	Replaces	Threads	Wire Length
CGSS1A6C2R1X 006824-001		225006-004 225957-002 226530-003 226531-003 226931-005 226931-006 226999-011 226999-012	3/4 inch 6 inch	
CGSS1A3C2R1X	006824-005	225006-003 226530-005 226531-004 226931-007 226931-008	3/4 inch	30 inch
CGSS1C6C2R1X	006824-003	226999-008 226999-020 226999-014 226999-021	20 mm	6 inch
CGSS1C3C2R1X	006824-007	226999-015	20 mm	30 inch

H ₂ S	SENSOR
------------------	---------------

Part Number	Des	<u>scri</u>	pti	on

004539-009 Explosion-Proof H₂S Sensor Housing 005434-001 Electrochemical H₂S Sensing

Element Assembly

NOTE

Other toxic gas sensors are available. Consult the factory for types and availability.

GAS SENSOR ACCESSORIES

G/10 02/100/11/100200/11/20		
Part Number	<u>Description</u>	
102868-001	Silicone Free Grease	
102740-001	Calibration Magnet	
226365-113	Sensor Separation Kit for Catalytic	
	Sensors	
226365-104	Sensor Separation Kit for	
	Electrochemical Sensors	
006414-001	Sensor Separation Kit for PointWatch	
226349-001	Sensor Rain Shield	
225312-001	Sensor Dust Cover (Stainless Steel)	
226190-001	Sensor Dust Cover (Porex)	
226354-001	Splash Guard	

NOTE

Other accessories are available.

CALIBRATION KITS FOR CATALYTIC COMBUSTIBLE GAS SENSORS

Part Number	<u>Gas</u>
225130-001	Methane (50% LFL)
225130-002	Ethane (50% LFL)
225130-003	Ethylene (50% LFL)
225130-004	Propane (50% LFL)
225130-005	Hydrogen (50% LFL)
225130-006	Methane (20% LFL)
225130-007	Methane (25% LFL)
225130-008	Methane (35% LFL)

REPLACEMENT CYLINDERS

Part Number	<u>Gas</u>
226166-001	Methane (50% LFL)
226166-002	Ethane (50% LFL)
226166-003	Ethylene (50% LFL)
226166-004	Propane (50% LFL)
226166-005	Hydrogen (50% LFL)
226166-006	Air (0% LFL)
226166-007	Methane (20% LFL)
226166-008	Methane (25% LFL)
226166-009	Methane (35% LFL)

REPLACEMENT PARTS FOR CALIBRATION KIT

HEI EAGEMENT I ATTIOT OT GALIBITATION KIT	
Part Number	Description
162552-001	Regulator
101678-007	3 foot hose
004976-001	Standard calibration cup
225777-001	Calibration cup for sensor separation

H₂S CALIBRATION KIT

227115-001	H ₂ S Calibration Kit (for electro-
	chemical sensors only) includes
	regulator, hose, calibration cup, and
	two cylinders of calibration gas.

REPLACEMENT PARTS — H2S

1121 2710 2111 2111 1711110 1120		
Part Number	Description	
005434-001	Electrochemical Sensing Element	
	Assembly for H ₂ S Sensor	
004532-002	Hydrophobic Filter for H ₂ S Sensor	
107427-034	O-ring (for Hydrophobic Filter)	
107427-004	O-ring (for Sensor Housing)	
227117-001	Gas Bottle for 227115-001 Calibration	
	Kit - 50 ppm	

For additional information or for assistance in ordering, please contact:

Detector Electronics Corporation 6901 West 110th Street

Minneapolis, Minnesota 55438 USA Operator: (952) 941-5665 or (800) 765-FIRE

Customer Service: (952) 946-6491

Fax: (952) 829-8750

Web site: www.detronics.com E-mail: detronics@detronics.com

Section 6 Specifications

EQ300X CONTROLLER

INPUT VOLTAGE—

24 vdc nominal, 18 to 30 vdc. 10% overvoltage will not cause damage to the equipment.

INPUT POWER—

9 watts nominal, 12 watts maximum.

LON COMMUNICATION—

Digital communication, transformer isolated (78.5 kbps).

RS-485 COMMUNICATION—

MODBUS Master/Slave capability.

Digital communication, transformer isolated (up to 115 kbps).

RS-232 COMMUNICATION—

S3 configuration only.

Digital communication, optically isolated.

CONTROLNET—

Digital communication, transformer isolated (5 Mbps).

SERIAL INTERFACE BOARD-

RS-485 Communication: MODBUS master/slave capability, ground fault monitored.

Digital communication, transformer isolated (up to 230 kbps).

RS-232 Communication: MODBUS master/slave or S3 configuration capability.

Digital communication, isolated (up to 230 kbps).

RS-232 Communication: MODBUS master/slave capability.

Digital communication, isolated (up to 230 kbps).

High Speed Serial Link (HSSL): Port used only for redundant controller to controller communication.

UNSUPERVISED OUTPUTS-

Dry Contact Rating: 1 ampere at 30 vdc maximum. SPDT normally open/normally closed contact, Configurable for normally energized or de-energized (de-energized is the default mode).

UNSUPERVISED INPUTS-

Two State input (on/off).

User selectable normally open or normally closed contact (N.O. is the default).

TROUBLE OUTPUT-

SPDT normally open/normally closed contact, Non-Configurable, normally energized only.

TEMPERATURE RANGE—

Operating: -40°F to +185°F (-40°C to +85°C). Storage: -40°F to +185°F (-40°C to +85°C). Excluding communication port optional modules.

HUMIDITY RANGE—

5 to 95% RH, non-condensing.

VIBRATION—

FM 3260, FM 6310/6320.

DIMENSIONS—

See Figure 6-1.

SHIPPING WEIGHT—

2 pounds (0.9 kilograms).

CERTIFICATION—

FM / CSA: Class I, Div. 2, Groups A, B, C, D (T4).

Class I, Zone 2, Group IIC (T4).

Performance verified.

Refer to Appendix A for FM Approval details. Refer to Appendix B for CSA Certification details.

CENELEC/CE: ATEX/EMC Directive Compliant.

Performance verified per EN 61779-4.


(€ 0539 **(a)** II 3 G EEx nC IIC T4


DEMKO 02 ATEX 133867U T4 (Tamb = -40° C to $+85^{\circ}$ C).

Refer to Appendix C for CE Mark details.

Special conditions for safe use:

The device shall be installed in an enclosure that complies with all relevant requirements of EN 50021: 1999, and provides a degree of ingress protection of at least IP54. The device may only be installed, connected or removed when the area is known to be non-hazardous.





DIN RAIL MOUNTING DIMENSIONS




Figure 6-1—Dimensions of EQP Controller in Inches (Centimeters)

LON TERMINATION MODULE

TEMPERATURE RANGE—

Operating: $-40^{\circ}\text{F to } +185^{\circ}\text{F } (-40^{\circ}\text{C to } +85^{\circ}\text{C}).$ Storage: $--67^{\circ}\text{F to } +185^{\circ}\text{F } (-55^{\circ}\text{C to } +85^{\circ}\text{C}).$

HUMIDITY RANGE—

5 to 95% RH, non-condensing.

DIMENSIONS—

See Figure 6-2.

SHIPPING WEIGHT-

0.5 pounds (0.2 kilograms)

CERTIFICATION—

FM / CSA: Class I, Div. 2, Groups A, B, C, D (T4).

Class I, Zone 2, Group IIC (T4).

CENELEC/CE: ATEX/EMC Directive Compliant.

DEMKO 04 ATEX 138345U T4 (Tamb = -40° C to $+85^{\circ}$ C).

Special Conditions for Safe Use:

The LON Termination Module shall be installed in an enclosure that complies with all relevant requirements of EN50021:1999 and provides a degree of ingress protection of at least IP54.

The LON Termination Module may only be installed, connected, or removed when the area is known to be non-hazardous.




Figure 6-2—Dimensions of LON Termination Module and HART Interface Module in Inches (Centimeters)

EQ3730EDIO ENHANCED DISCRETE INPUT/OUTPUT MODULE

POWER REQUIREMENTS—

3 watts nominal, 7 watts maximum.

INPUT VOLTAGE—

24 Vdc nominal, 18 to 30 Vdc. 10% overvoltage will not cause damage to the equipment.

21 to 30 Vdc for Pre-action / Deluge applications.

Note: For deluge and pre-action applications, input voltage to the device must be 21 Vdc minimum to ensure proper operation of the connected output device.

SLC OUTPUT-

Digital communication, transformer isolated (78.5 kbps).

TEMPERATURE RANGE—

Operating: -40° F to $+185^{\circ}$ F (-40° C to $+85^{\circ}$ C). Storage: -67° F to $+185^{\circ}$ F (-55° C to $+85^{\circ}$ C).

HUMIDITY RANGE—

0 to 95% RH, non-condensing.

VIBRATION-

FM 3260-2000 (clause 4.9).

DIMENSIONS—

Refer to Figure 6-3.

SHIPPING WEIGHT-

1 pound (0.45 kilograms).

CERTIFICATION—

FM / CSA: Class I, Div. 2, Groups A, B, C, D (T4).

Class I, Zone 2, Group IIC (T4).

CENELEC: ATEX

DEMKO 05 ATEX 138864U T4 (Tamb = -40° C to $+85^{\circ}$ C).

Special conditions for safe use:

The device shall be installed in an enclosure that complies with all relevant requirements of EN 50021: 1999, and provides a degree of ingress protection of at least IP54. The device may only be installed, connected or removed when the area is known to be non-hazardous.

CE: 89/336/EEC

EMC Directive Compliant.




Figure 6-3—Dimensions of the EDIO / DCIO / Relay Module / AIM / IPM in Inches (Centimeters)

INPUT / INITIATING DEVICE CIRCUITS

UNSUPERVISED INPUT-

Two state input (on/off). Normally open contact.

SUPERVISED INPUT (Open Circuit)—

For Class A, Style D and Class B, Style B wiring. Two state input (active/trouble):

- End of Line Resistor 10 K ohms nominal
- Open Circuit > 45 K ohms
- Active Circuit < 5 K ohms.

SUPERVISED INPUT (Open and Short Circuit)—

For Class A, Style E and Class B, Style C wiring. Three State input (active/short/open):

- End of Line Resistor 10 K ohms nominal
- In Line Resistor 3.3 K ohms nominal
- Open Circuit > 45 K ohms
- Short Circuit < 250 ohms
- Active Circuit 2.5 K ohms to 5 K ohms.

INPUT. TYPES—

Configurable for static logic applications:

- Fire Alarm
- Supervisory
- Trouble
- High Gas Alarm
- Low Gas Alarm
- Other.

For Class A wiring on inputs, configure adjacent channels for Class A wiring and connect both channels to single contact device(s).

INPUT CIRCUITS - TWO WIRE SMOKE/HEAT TYPE-

Supervised Input, Class B, Style B or Style C:

Up to 15 two wire detectors per circuit.

Maximum line resistance 50 ohms.

5K ohm EOL.

Open circuit fault impedance 22k ohms.

OUTPUT / NOTIFICATION / RELEASING OR UNSUPERVISED DEVICE CIRCUITS

UNSUPERVISED OUTPUT RATING (Per Channel)—

2 amperes at 30 Vdc maximum.

Automatic short circuit protection provided.

Instantaneous short circuit current < 15 amperes.

Note: Voltage available at outputs is dependent on input voltage (Vout ≈ Vin - 1 Vdc).

OUTPUT STYLE—

Form "A" normally off.

RESPONSE TIME—

Output actuates in <0.15 second after acknowledging an alarm command message.

SUPERVISED OUTPUT RATING—SIGNALING TYPE. STYLE "Y"

MAXIMUM OUTPUT CURRENT (Per Channel)—

2 amperes at 30 Vdc maximum.

Automatic short circuit protection provided.

Instantaneous short circuit current < 15 amperes.

SUPERVISORY CURRENT (Per Channel)—

Reverse current monitored at 1.5 mA, \pm 0.5 mA.

RESPONSE TIME—

Output actuates in <0.15 second after acknowledging an alarm command message.

EOL RESISTORS—

10 K ohms ±2 K ohms. Each circuit must have an EOL resistor.

SIGNALING OUTPUT, TYPES—

Configurable for device applications:

- Continuous
- 60 beats per minute
- 120 beats per minute
- Temporal Pattern.

Note: All eight channels are synchronized when programmed as a signaling output.

SUPERVISED OUTPUT RATING— Releasing Type

MAXIMUM OUTPUT CURRENT (Per Channel)—

2 amperes at 30 Vdc maximum.

Automatic short circuit protection provided. Instantaneous short circuit current < 15 amperes.

SUPERVISORY CURRENT (Per Channel)—

Monitored at 1.3 mA ±0.2 mA.

RESPONSE TIME—

Output actuates in <0.15 second after acknowledging an alarm command message.

RELEASING OUTPUT, TYPES-

Configurable for device applications:

- Continuous
- Timed.

For Class A wiring on outputs, configure adjacent channels for Class A wiring and connect both channels to single output device(s).

EQ3700 DIRECT CURRENT IO (DCIO) MODULE

POWER REQUIREMENTS—

3 watts nominal, 7 watts maximum.

INPUT VOLTAGE—

24 vdc nominal, 18 to 30 vdc. 10% overvoltage will not cause damage to the equipment.

21 to 30 vdc for Pre-action / Deluge application.

NOTE: For deluge and pre-action applications, input voltage to the device must be 21 vdc minimum to ensure proper operation of the connected output device.

OUTPUT VOLTAGE—

(Input voltage - 0.5 vdc) @ 2 amperes.

LON COMMUNICATION—

Digital communication, transformer isolated (78.5 kbps).

TEMPERATURE RANGE—

Operating: $-40^{\circ}\text{F to } +185^{\circ}\text{F } (-40^{\circ}\text{C to } +85^{\circ}\text{C}).$ Storage: $-67^{\circ}\text{F to } +185^{\circ}\text{F } (-55^{\circ}\text{C to } +85^{\circ}\text{C}).$

HUMIDITY RANGE—

5 to 95% RH, non-condensing.

DIMENSIONS—

Refer to Figure 6-3.

SHIPPING WEIGHT-

1 pound (0.45 kilograms).

CERTIFICATION—

FM / CSA: Class I, Div. 2, Groups A, B, C, D (T4).

Class I, Zone 2, Group IIC (T4).

Refer to Appendix A for FM Approval details.

Refer to Appendix B for CSA Approval details.

CENELEC/CE: ATEX/EMC Directive Compliant.

(€ 0539 **(⊕** II 3 G EEx nC IIC T4

DEMKO 02 ATEX 133864U T4 (Tamb = -40° C to $+85^{\circ}$ C).

Refer to Appendix C for CE Mark details.

Special conditions for safe use:

The device shall be installed in an enclosure that complies with all relevant requirements of EN 50021: 1999, and provides a degree of ingress protection of at least IP54. The device may only be installed, connected or removed when the area is known to be non-hazardous.

INPUT / INITIATING DEVICE CIRCUITS

UNSUPERVISED INPUT-

Two state input (on/off). Normally open contact.

SUPERVISED INPUT, CLASS B STYLE B-

Two state input (active/trouble):

- End of Line Resistor 10 K ohms nominal
- Open Circuit > 45 K ohms
- Active Circuit < 5 K ohms.

SUPERVISED INPUT, CLASS B STYLE C-

Three State input (active/short/open):

- End of Line Resistor 10 K ohms nominal
- In Line Resistor 3.3 K ohms nominal
- Open Circuit > 45 K ohms
- Short Circuit < 1.4 K ohms
- Active Circuit 2.5 K ohms to 5 K ohms.

INPUT. TYPES—

Configurable for fixed logic applications:

- Fire Alarm
- Supervisory
- Trouble
- High Gas Alarm
- Low Gas Alarm
- Other.

OUTPUT / NOTIFICATION / RELEASING CIRCUITS

UNSUPERVISED OUTPUT RATING-

Short circuit protected: 2 amperes at 30 Vdc maximum.

SUPERVISED OUTPUT RATING—SIGNALING TYPE, CLASS B, STYLE "Y".

MAXIMUM OUTPUT CURRENT—

2 amperes maximum, 15 Amp inrush. Automatic short circuit protection provided.

SUPERVISORY CURRENT—

Reverse current monitored at 3.0 mA, ± 2.0mA.

RESPONSE TIME—

Output actuates in <0.15 second after acknowledging an alarm command message.

EOL RESISTORS—

10 K ohms ±2 K ohms.

SIGNALING OUTPUT, TYPES-

Configurable for device applications:

- Continuous
- 60 beats per second
- 120 beats per second
- Temporal Pattern.

NOTE

All eight channels are synchronized when programmed as a signaling output.

SUPERVISED OUTPUT RATING— RELEASING TYPE

MAXIMUM OUTPUT CURRENT—

2 amperes maximum, 15 Amp inrush. Automatic short circuit protection provided.

SUPERVISORY CURRENT—

Monitored at 3.0 mA ±2.0 mA.

RESPONSE TIME—

Output actuates in <0.15 second after acknowledging an alarm command message.

RELEASING OUTPUT, TYPES-

Configurable for device applications:

- Continuous
- Timed.

EQ3720 RELAY MODULE

POWER REQUIREMENTS—

3 watts nominal, 4 watts maximum.

INPUT VOLTAGE—

24 vdc nominal, 18 to 30 vdc. 10% overvoltage will not cause damage to the equipment.

RELAY CONTACTS—

30 VDC, 2 amps resistive.

125 VAC, 0.5 amp resistive (FM and CSA only).

LON COMMUNICATION—

Digital communication, transformer isolated (78.5 kbps).

TEMPERATURE RANGE—

Operating: $-40^{\circ}\text{F to } +185^{\circ}\text{F } (-40^{\circ}\text{C to } +85^{\circ}\text{C}).$ Storage: $-67^{\circ}\text{F to } +185^{\circ}\text{F } (-55^{\circ}\text{C to } +85^{\circ}\text{C}).$

HUMIDITY RANGE—

5 to 95% RH, non-condensing.

DIMENSIONS—

Refer to Figure 6-3.

SHIPPING WEIGHT-

1 pound (0.45 kilograms).

CERTIFICATION—

FM / CSA: Class I, Div. 2, Groups A, B, C, D (T4).

Class I, Zone 2, Group IIC (T4).

Refer to Appendix A for FM Approval details. Refer to Appendix B for CSA Approval details.

CENELEC/CE: ATEX/EMC Directive Compliant.

DEMKO 03 ATEX 135246U T4 (Tamb = -40° C to $+85^{\circ}$ C).

 $V_{in} = 24 \text{ vdc } \pm 10\%$.

Refer to Appendix C for CE Mark details.

Special conditions for safe use:

The device shall be installed in an enclosure that complies with all relevant requirements of EN 50021: 1999, and provides a degree of ingress protection of at least IP54. The device may only be installed, connected or removed when the area is known to be non-hazardous.

RESPONSE TIME—

Actuates in <0.15 second after acknowledging an alarm command message.

EQ3710AIM ANALOG INPUT MODULE

POWER REQUIREMENTS—

Module power consumption: 6 watts.

When supplying power to three-wire transmitters:

Maximum current at power input: 7.4 amperes.

Output current: 900 mA per channel maximum.

INPUT/OUTPUT VOLTAGE—

24 vdc nominal, 18 to 30 vdc. 10% overvoltage will not cause damage to the equipment.

TEMPERATURE RANGE—

Operating: -40° F to $+185^{\circ}$ F (-40° C to $+85^{\circ}$ C). Storage: -67° F to $+185^{\circ}$ F (-55° C to $+85^{\circ}$ C).

HUMIDITY RANGE—

0 to 95% RH, non-condensing.

CHANNEL ACCURACY—

Zero: $\pm 0.3\%$ full scale from -40° C to $+85^{\circ}$ C. Span: $\pm 0.5\%$ full scale from -40° C to $+85^{\circ}$ C.

RESPONSE TIME—

1 to 100 LON devices: < 2 seconds 101 to 200 LON devices: < 3 seconds 201 to 246 LON devices: < 4 seconds.

LON COMMUNICATION—

Digital communication, transformer isolated (78.5 kbps).

DIMENSIONS—

Refer to Figure 6-3.

SHIPPING WEIGHT-

1 pound (0.45 kilograms).

CERTIFICATION—

FM / CSA: Class I, Div. 2, Groups A, B, C, D (T4).

Class I, Zone 2, Group IIC (T4).

CENELEC/CE: ATEX/EMC Directive Compliant.

DEMKO 03 ATEX 136207U T4 (Tamb = -40°C to +85°C).

Special conditions for safe use:

The device shall be installed in an enclosure that complies with all relevant requirements of EN 50021: 1999, and provides a degree of ingress protection of at least IP54. The device may only be installed, connected or removed when the area is known to be non-hazardous.

HART INTERFACE MODULE (HIM)

INPUT VOLTAGE—

24 vdc nominal, 18 to 30 vdc. 10% overvoltage will not cause damage to the equipment.

INPUT POWER—

1.0 watt maximum.

INPUT/OUTPUT CURRENT—

Operating: 4 -20 mA. Maximum: 0-30 mA.

TEMPERATURE RANGE—

Operating: -40°F to +185°F (-40°C to +85°C). Storage: --67°F to +185°F (-55°C to +85°C).

HUMIDITY RANGE—

5 to 95% RH, non-condensing.

DIMENSIONS—

See Figure 6-2.

SHIPPING WEIGHT—

0.5 pounds (0.2 kilograms)

CERTIFICATION—

FM / CSA: Class I, Div. 2, Groups A, B, C, D (T4).

Class I, Zone 2, Group IIC (T4).

CENELEC/CE: ATEX/EMC Directive Compliant.

DEMKO 04 ATEX 136507U T4 (Tamb = -40° C to $+85^{\circ}$ C).

Special Conditions for Safe Use:

The HIM shall be installed in an enclosure that complies with all relevant requirements of EN50021:1999 and provides a degree of ingress protection of at least IP54.

The HIM may only be installed, connected, or removed when the area is known to be non-hazardous.

EQ3740IPM INTELLIGENT PROTECTION MODULE

POWER REQUIREMENTS—

3 watts nominal, 7 watts maximum.

INPUT VOLTAGE—

24 vdc nominal, 18 to 30 vdc. 10% overvoltage will not cause damage to the equipment.

LON COMMUNICATIONS—

Digital communication, transformer isolated (78.5 kbps).

TEMPERATURE RANGE—

Operating: $-40^{\circ}\text{F to } +185^{\circ}\text{F } (-40^{\circ}\text{C to } +85^{\circ}\text{C}).$ Storage: $-67^{\circ}\text{F to } +185^{\circ}\text{F } (-55^{\circ}\text{C to } +85^{\circ}\text{C}).$

HUMIDITY RANGE—

0 to 95% RH, non-condensing.

DIMENSIONS—

Refer to Figure 6-3.

SHIPPING WEIGHT-

1 pound (0.45 kilograms).

CERTIFICATION—

FM / CSA: Class I, Div. 2, Groups A, B, C, D (T4).

Class I, Zone 2, Group IIC (T4).

Special conditions for safe use:

Electronic assembly must be installed in a suitable NRTL labled NEMA rated enclosure.

CENELEC/CE: ATEX/EMC Directive Compliant.

(€ 0539 ⁽²⁾ II 3 G EEx nC IIC T4

DEMKO 03 ATEX 136206U T4 (Tamb = -40° C to $+85^{\circ}$ C).

Special conditions for safe use:

The device shall be installed in an enclosure that complies with all relevant requirements of EN 50021: 1999, and provides a degree of ingress protection of at least IP54. The device may only be installed, connected or removed when the area is known to be non-hazardous.

INPUT / INITIATING DEVICE CIRCUITS - CONTACT MONITOR TYPE - CHANNEL 1 - 3

NOTE

An input must be active for at least 750 milliseconds in order to be recognized.

UNSUPERVISED INPUT—

Two state input (on/off). Normally open contact. No EOL resistor required.

SUPERVISED INPUT, CLASS B STYLE B-

Two state input (active/trouble):
End of Line Resistor 10 K ohms ±20%
Open Circuit > 45 K ohms
Active Circuit < 5 K ohms.

SUPERVISED INPUT, CLASS B STYLE C-

Three State input (active/short/open): End of Line Resistor 10 K ohms ±20% In Line Resistor 3.3 K ohms ±20% Open Circuit > 45 K ohms Short Circuit < 1.4 K ohms Active Circuit 2.5 K ohms to 5 K ohms.

INPUT CIRCUITS - TWO WIRE SMOKE/HEAT TYPE - CHANNEL 4 AND 5

SUPERVISED INPUT, CLASS B STYLE B or CLASS B STYLE C:

Up to 15 two wire detectors per circuit.

Maximum line resistance 50 ohms

Style B, 5K ohm EOL

Open circuit fault impedance 22K ohms

OUTPUT / NOTIFICATION / RELEASING OR UNSUPERVISED DEVICE CIRCUITS - CHANNEL 6-8

UNSUPERVISED OUTPUT RATING-

Rating: 2 amperes at 30 Vdc maximum.

Note: Voltage available at outputs is dependent on input voltage (Vout \approx Vin - 1 Vdc).

OUTPUT STYLE—

Form "A" normally off.

RESPONSE TIME—

Output actuates in <0.15 second after acknowledging an alarm command message.

No EOL resistor required.

SUPERVISED OUTPUT RATING—SIGNALING TYPE. STYLE "Y" - CHANNEL 6

MAXIMUM OUTPUT CURRENT—

2 amperes at 30 Vdc maximum, 15 Amp inrush. Automatic short circuit protection provided.

SUPERVISORY CURRENT—

Reverse current monitored at 1.5 mA, ± 0.5 mA. End of Line Resistor 10 K ohms ±20%.

RESPONSE TIME—

Output actuates in <0.15 second after acknowledging an alarm command message.

SIGNALING OUTPUT, TYPES-

Configurable for device applications:

STANDARD "SAM" SELECTIONS-

Continuous

60 beats per minute 120 beats per minute Temporal Pattern.

Trouble Supervisory

SUPERVISED OUTPUT RATING— RELEASING TYPE - CHANNEL 7 AND 8

MAXIMUM OUTPUT CURRENT—

2 amperes at 30 Vdc maximum, 15 Amp inrush. Automatic short circuit protection provided.

SUPERVISORY CURRENT—

Monitored at 1.3 mA ±0.2 mA. No EOL resistor required.

RESPONSE TIME—

Output actuates in <0.15 second after acknowledging an alarm command message.

RELEASING OUTPUT. TYPES—

Configurable for device applications:

- Continuous
- Timed.

EQ21XXPS POWER SUPPLIES

INPUT VOLTAGE—

Selectable for 120, 208 or 240 vac input power, $\pm 10\%$.

INPUT CURRENT—

60 Hz Models:

EQ2110PS: 4 amps at 120 VAC

EQ2130PS: 11 / 6 / 6 amps at 120 / 208 / 240 VAC EQ2175PS: 24 / 15 / 12 amps at 120 / 208 / 240 VAC.

50 Hz Models:

EQ2111PS: 4 amps at 120 VAC EQ2131PS: 6 amps at 240 VAC EQ2176PS: 12 amps at 240 VAC.

OUTPUT CURRENT—

EQ2110PS / EQ2111PS: 10 amperes at 24 VDC EQ2130PS / EQ2131PS: 30 amperes at 24 VDC EQ2175PS / EQ2176PS: 75 amperes at 24 VDC.

POWER CONSUMPTION—

EQ2110PS / EQ2111PS: 46 Watts EQ2130PS / EQ2131PS: 140 Watts EQ2175PS / EQ2176PS: 349 Watts.

TEMPERATURE RANGE—

Operating: $+32^{\circ}F$ to $+122^{\circ}F$ (0°C to $+50^{\circ}C$) Storage: $-40^{\circ}F$ to $+185^{\circ}F$ ($-40^{\circ}C$ to $+85^{\circ}C$).

HUMIDITY RANGE—

5 to 95% RH, non-condensing.

DIMENSIONS—

in Inches (Centimeters)

•	Width	Height	Depth
EQ211xPS:	19 (48.3)	7 (17.8)	15 (38.1)
EQ213xPS:	19 (48.3)	14 (35.6)	15 (38.1)
EQ217xPS:	19 (48.3)	14 (35.6)	15 (38.1)

NOTE

Power supplies are designed for mounting in a standard 19 inch rack. Optional mounting hardware is available for floor or wall mount applications.

CERTIFICATION—

FM / CSA: Ordinary locations.

EQ21xxPSM POWER SUPPLY MONITOR

INPUT VOLTAGE—

24 vdc nominal, 18 to 30 Vdc.

POWER CONSUMPTION—

2.0 watts maximum.

MEASUREMENT RANGE—

AC Voltage: 240 vac maximum. DC Battery Charging Current: 75 amperes maximum.

OUTPUT-

Digital communication, transformer isolated (78.5 k bps).

TEMPERATURE RANGE—

Operating: $+32^{\circ}F$ to $+122^{\circ}F$ (0°C to $+50^{\circ}C$) Storage: $-67^{\circ}F$ to $+185^{\circ}F$ ($-55^{\circ}C$ to $+85^{\circ}C$).

HUMIDITY RANGE—

5 to 95% RH, non-condensing.

DIMENSIONS—

See Figure 6-4.

CERTIFICATION—

FM / CSA: Ordinary locations.




Figure 6-4—Dimensions of Power Supply Monitor in Inches (Centimeters)

EQ22xxIDC/IDCGF INITIATING DEVICE CIRCUIT

INPUT VOLTAGE—

24 vdc nominal, 18 to 30 vdc. 10% overvoltage will not cause damage to the equipment.

INPUT POWER—

4.0 watts maximum.

INPUTS-

Two supervised non-incendive digital inputs (sealed or unsealed switch or relay contacts). 10 kohm EOL resistors are required.

OUTPUTS—

Digital communication, transformer isolated (78.5 kbps).

TEMPERATURE RANGE—

Operating: $-40^{\circ}\text{F to } +167^{\circ}\text{F } (-40^{\circ}\text{C to } +75^{\circ}\text{C}).$ Storage: $-67^{\circ}\text{F to } +185^{\circ}\text{F } (-55^{\circ}\text{C to } +85^{\circ}\text{C}).$

HUMIDITY RANGE—

5 to 95% RH, non-condensing.

VIBRATION-

FM 3260.

DIMENSIONS—

See Figure 6-5.




Figure 6-5—Dimensions of Tall Cover Junction Box in Inches (Centimeters)

CERTIFICATION—

FM / CSA: Class I, Div. 1, Groups B, C, D.

Class I, Zone 1, Group IIC. Class II/III, Div. 1, Groups E, F, G. Class I, Div. 2, Groups A, B, C, D (T4A).

Class I, Zone 2, Group IIC (T4). Class II/III, Div. 2, Groups F & G (T4A).

NEMA/Type 4X.

Refer to Appendix A for FM Approval details. Refer to Appendix B for CSA Approval details.

CENELEC/CE: ATEX/EMC Directive Compliant.

(€ 0539 **()** II 2 G EEx d IIC T4-T6

DEMKO 02 ATEX 131321X T6 (Tamb = -55° C to $+50^{\circ}$ C). T5 (Tamb = -55° C to $+65^{\circ}$ C). T4 (Tamb = -55° C to $+75^{\circ}$ C).

IP66.

Special Conditions for Safe Use (X):

The device has an ambient temperature rating for performance of -40°C to +75°C.

Refer to Appendix C for CE Mark details.

EQ2220GFM GROUND FAULT MONITOR

INPUT VOLTAGE—

24 vdc nominal, 18 to 30 vdc. 10% overvoltage will not cause damage to the equipment.

INPUT POWER—

1.0 watt maximum.

OUTPUT-

Form C NO/NC relay contact rated 1 ampere (resistive) at 30 Vdc maximum.

TEMPERATURE RANGE—

Operating: $-40^{\circ}\text{F to } +185^{\circ}\text{F } (-40^{\circ}\text{C to } +85^{\circ}\text{C}).$ Storage: $--67^{\circ}\text{F to } +185^{\circ}\text{F } (-55^{\circ}\text{C to } +85^{\circ}\text{C}).$

HUMIDITY RANGE—

5 to 95% RH, non-condensing.

DIMENSIONS—

See Figure 6-6.

SHIPPING WEIGHT—

0.5 pounds (0.2 kilograms)

CERTIFICATION—

FM / CSA: Class I, Div. 2, Groups A, B, C, D (T4).

Class I, Zone 2, Group IIC (T4).

CENELEC/CE: ATEX/EMC Directive Compliant.

DEMKO 03 ATEX 136222U T4 (Tamb = -40° C to $+85^{\circ}$ C).

Special Conditions for Safe Use:

The EQ2220GFM shall be installed in an enclosure that complies with all relevant requirements of EN50021:1999 and provides a degree of ingress protection of at least IP54.

The EQ2220GFM may only be installed, connected, or removed when the area is known to be non-hazardous.




Figure 6-6—Dimensions of Ground Fault Monitor in Inches (Centimeters)

EQ22xxDCU AND EQ22xxDCUEX DIGITAL COMMUNICATION UNIT

INPUT VOLTAGE—

24 vdc nominal, 18 to 30 vdc. 10% overvoltage will not cause damage to the equipment.

POWER CONSUMPTION—

DCU with toxic gas sensor/transmitter: 95 ma maximum.

DCU with transmitter and combustible gas sensor: 180 ma maximum during normal operation, 500 ma during startup.

INPUTS-

4 to 20 ma analog signal. Non-intrusive calibration.

OUTPUTS—

Digital communication, transformer isolated (78.5 kbps).

TEMPERATURE RANGE—

Operating: $-40^{\circ}\text{F to } +167^{\circ}\text{F } (-40^{\circ}\text{C to } +75^{\circ}\text{C}).$ Storage: $-67^{\circ}\text{F to } +185^{\circ}\text{F } (-55^{\circ}\text{C to } +85^{\circ}\text{C}).$

HUMIDITY RANGE—

5 to 95% RH, non-condensing.

VIBRATION—

FM 6310/6320.

DIMENSIONS—

See Figure 6-5.

CERTIFICATION—

FM / CSA: Class I, Div. 1, Groups B, C, D.

Class I, Zone 1, Group IIC.

Class I, Div. 2, Groups A, B, C, D (T4A).

Class I, Zone 2, Group IIC (T4).

Class II/III, Div. 1 & 2 (for use with Model STB).

NEMA/Type 4X (for use with Model STB).

Refer to Appendix A for FM Approval details.

Refer to Appendix B for CSA Approval details.

CENELEC/CE: ATEX/EMC Directive Compliant.

(€ 0539 ऒ II 2 G

EEx d IIC T4-T6

DEMKO 02 ATEX 131321X

T6 (Tamb = -55°C to +50°C).

T5 (Tamb = -55° C to $+65^{\circ}$ C).

T4 (Tamb = -55° C to $+75^{\circ}$ C).

IP66.

Special Conditions for Safe Use (X):

The device has an ambient temperature rating for performance of -40°C to +75°C.

Refer to Appendix C for CE Mark details.

EQ25xxARM AGENT RELEASE MODULE

RELEASE OUTPUT RATING-

2 amperes at 30 vdc maximum.

SUPERVISORY CURRENT—

2.0 ma, ±1.0 ma each circuit.

INPUT VOLTAGE—

24 vdc nominal, 18 to 30 vdc. 10% overvoltage will not cause damage to the equipment.

NOTE: For deluge and pre-action applications, input voltage to the device must be 21 vdc minimum to ensure proper operation of the connected output device.

INPUT CURRENT—

Standby: 75 ma maximum at 24 vdc. Alarm: 120 ma maximum at 24 vdc.

STATUS OUTPUTS-

Digital communication, transformer isolated (78.5 kbps).

TEMPERATURE RANGE—

Operating: $-40^{\circ}\text{F to } +167^{\circ}\text{F } (-40^{\circ}\text{C to } +75^{\circ}\text{C}).$ Storage: $-67^{\circ}\text{F to } +185^{\circ}\text{F } (-55^{\circ}\text{C to } +85^{\circ}\text{C}).$

HUMIDITY RANGE—

5 to 95% RH, non-condensing.

VIBRATION—

Meets MIL SPEC 810C, method 514.2, curve AW.

DIMENSIONS—

See Figure 6-5.

CERTIFICATION—

FM / CSA: Class I, Div. 1, Groups B, C, D.

Class I, Zone 1, Group IIC.

Class II/III, Div. 1, Groups E, F, G.

Class I, Div. 2, Groups A, B, C, D (T4A).

Class I, Zone 2, Group IIC (T4).

Class II/III, Div. 2, Groups F & G (T4A).

NEMA/Type 4X.

Refer to Appendix A for FM Approval details. Refer to Appendix B for CSA Approval details.

CENELEC/CE: ATEX/EMC Directive Compliant.

EEx d IIC T4-T6

DEMKO 02 ATEX 131321X

T6 (Tamb = -55° C to $+50^{\circ}$ C).

T5 (Tamb = -55° C to $+65^{\circ}$ C).

T4 (Tamb = -55° C to $+75^{\circ}$ C).

IP66.

Special Conditions for Safe Use (X):

The device has an ambient temperature rating for performance of -40°C to +75°C.

Refer to Appendix C for CE Mark details.

EQ25xxSAM SIGNAL AUDIBLE MODULE

OUTPUT RATING—

2 amperes at 30 vdc maximum.

RESPONSE TIME—

Output relay actuates in <0.1 second after acknowledging an alarm command message.

SUPERVISORY CURRENT—

3.0 ma ± 2.0ma, each circuit.

EOL RESISTORS —

10 kohm \pm 2 kohm. Each circuit must have an EOL resistor.

INPUT VOLTAGE—

24 vdc nominal, 18 to 30 vdc. 10% overvoltage will not cause damage to the equipment.

INPUT CURRENT (Excluding Output Current)—

Standby: 60 ma maximum at 24 vdc.
Alarm: 120 ma maximum at 24 vdc.

STATUS OUTPUT-

Digital communication, transformer isolated (78.5 kbps).

TEMPERATURE RANGE—

Operating: $-40^{\circ}\text{F to } +167^{\circ}\text{F } (-40^{\circ}\text{C to } +75^{\circ}\text{C}).$ Storage: $-67^{\circ}\text{F to } +185^{\circ}\text{F } (-55^{\circ}\text{C to } +85^{\circ}\text{C}).$

HUMIDITY RANGE—

5 to 95% RH, non-condensing.

VIBRATION—

Meets MIL SPEC 810C, method 514.2, curve AW.

DIMENSIONS—

See Figure 6-5.

CERTIFICATION—

FM / CSA: Class I, Div. 1, Groups B, C, D.

Class I, Zone 1, Group IIC. Class II/III, Div. 1, Groups E, F, G. Class I, Div. 2, Groups A, B, C, D (T4A). Class I, Zone 2, Group IIC (T4).

Class II/III, Div. 2, Groups F & G (T4A).

NEMA/Type 4X.

Refer to Appendix A for FM Approval details. Refer to Appendix B for CSA Approval details.

CENELEC/CE: ATEX/EMC Directive Compliant.

DEMKO 02 ATEX 131321X T6 (Tamb = -55° C to $+50^{\circ}$ C). T5 (Tamb = -55° C to $+65^{\circ}$ C). T4 (Tamb = -55° C to $+75^{\circ}$ C).

IP66.

Special Conditions for Safe Use (X):

The device has an ambient temperature rating for performance of -40°C to +75°C.

Refer to Appendix C for CE Mark details.

EQ24xxNE NETWORK EXTENDER

INPUT VOLTAGE—

24 vdc nominal, 18 to 30 vdc. 10% overvoltage will not cause damage to the equipment.

POWER CONSUMPTION—

2.2 watts nominal at 24 vdc, 2.7 watts maximum.

INPUTS/OUTPUTS-

Digital, transformer isolated (78.5k Baud).

TEMPERATURE RANGE—

Operating: $-40^{\circ}\text{F to } +167^{\circ}\text{F } (-40^{\circ}\text{C to } +75^{\circ}\text{C})$ Storage: $-67^{\circ}\text{F to } +185^{\circ}\text{F } (-55^{\circ}\text{C to } +85^{\circ}\text{C})$.

HUMIDITY—

5 to 95% RH at 70°C.

DIMENSIONS—

See Figure 6-7.


CERTIFICATION—

FM / CSA: Class I, Div. 1, Groups B, C, D.

Class I, Zone 1, Group IIC. Class II/III, Div. 1, Groups E, F, G. Class I, Div. 2, Groups A, B, C, D (T4A). Class I, Zone 2, Group IIC (T4).

Class II/III, Div. 2, Groups F & G (T4A).

NEMA/Type 4X.






Figure 6-7—Dimensions of Short Cover Junction Box in Inches (Centimeters)

Refer to Appendix A for FM Approval details. Refer to Appendix B for CSA Approval details.

CENELEC/CE: ATEX/EMC Directive Compliant.

C€ 0539 II 2 G EEx d IIC T4-T6

DEMKO 02 ATEX 131321X

T6 (Tamb = -55° C to $+50^{\circ}$ C).

T5 (Tamb = -55° C to $+65^{\circ}$ C). T4 (Tamb = -55° C to $+75^{\circ}$ C).

IP66.

Special Conditions for Safe Use (X):

The device has an ambient temperature rating for performance of -40°C to +75°C.

Refer to Appendix C for CE Mark details.

COMBUSTIBLE GAS SENSOR

Refer to the Combustible Gas Sensor Specification Data sheet, form 90-1041, for specifications.

ELECTROCHEMICAL SENSORS

Refer to the Electrochemical Gas Sensor Specification Data sheet, form 90-1079, for specifications. Electrochemical sensors available from Det-Tronics include Hydrogen Sulfide, Oxygen, Carbon Monoxide, Chlorine, Sulfur Dioxide, and Nitrogen Dioxide.

EQ21XXPS POWER SUPPLY

The EQ21xxPS Rectifier / Power Supply has many inherent advantages such as voltage regulation, high efficiency, high power factor and short circuit protection.

These chargers provide separate adjustable voltages for floating or equalizing lead or nickel-cadmium cells. An equalize switch is located on the front panel of the charger for manual activation or a multi-mode electronic timer can be used for automatic activation.

Steady state output voltage remains within +/- 1/2% of the setting from no load to full load and for AC input voltages within +/- 10% of the nominal input voltage. The power supply is internally filtered to be no greater than 32dBrn ("C" message weighting) and 30 millivolts RMS for all conditions on input voltage and output load with or without batteries connected. This allows the A36D to be used as a battery eliminator.

APPENDIX A

FM APPROVAL DESCRIPTION

HAZARDOUS LOCATIONS

- Refer to Figure A-1 for System Classification details.
- EQxxxxEM versions rated nonincendive for Class I, Div. 2, Groups A, B, C, D (T4A).

FIRE DETECTION & RELEASING

- National Fire Alarm Code performance verified per ANSI/NFPA 72-2002. Refer to Table A-1 for supervision characteristics.
- Refer to the Model X3301, X5200, X2200 and X9800 manuals (see Table 2-4) for further FM flame performance details. Additional 2 second response time applied for system communication.
- Models EQ3700 Series and EQ22xxARM Series are Approved as agent releasing circuits and are Approved for use with the following automatic deluge and pre-action solenoids:

FM Solenoid Group	Manufacturer	Model
В	ASCO	T8210A107
D	ASCO	8210G207
E	Skinner	73218BN4UNLVNOC111C2
F	Skinner	73212BN4TNLVNOC322C2
G	Skinner	71395SN2ENJ1NOH111C2
н	Viking	HV-274-0601

GAS DETECTION

• Combustible Gas Performance verified for 0 to 100% LFL methane-in-air atmospheres per FM 6310/6320. Accuracy: ±3% LFL from 0 to 50% LFL, ±5% LFL from 51% to 100% LFL. For the Model PIRECL, refer to the PIRECL manual (form number 95-8526) for further FM gas performance details.

NOTE: Detector Electronics combustible gas detection K factors are not FM verified.

H₂S Toxic Gas Performance verified 0 to 20, 50 or 100 ppm per FM requirements. Accuracy: ±2 ppm from 0 to 20 ppm, ±10% of concentration from 21 to 100 ppm. Models C7064E4012 and C7064E5012 Hydrogen Sulfide (H2S) Sensors Explosion-proof for Class I, Div. 1, Groups C and D Hazardous (Classified) Locations per FM 3615. Model C7064E5014 Hydrogen Sulfide (H2S) Sensors Explosion-proof for Class I, Div. 1, Groups B, C and D Hazardous (Classified) Locations per FM 3615. Operating temperature limits are -40°C to +40°C.

NOTE: Sensor cross sensitivity has not been verified by FM.

- Calibration of the above listed sensors has been FM verified using the respective EQ22xxDCU, EQ22xxDCUEX, and PIRECL with the Det-Tronics 225130-001 (50% LFL methane) and/or 227115-001 H2S Calibration Kits.
- The EQ22xxDCU Series can be used with any FM Approved 4-20 ma device.

NOTE

FM Approval of the 4-20 ma input does not include or imply approval of the gas detection apparatus such as sensors, transmitters, or devices connected to the system. In order to maintain FM Approval of the system, all 4-20 ma gas detection instruments connected to the input must also be FM Approved.

NOTE


FM Approval allows the presence and operation of serial communications software in the Controller (MODBUS, Allen Bradley protocols, etc.); however, the communications functions are not included in the Approval.

Table A-1—Circuit Classifications

Signaling Path	NFPA 72 Supervision
Local Operating Network (LON)	Signaling Line Circuit (SLC): Class A, Style 7
Power Distribution Module, Input Power	Supervised. Loss of power per ANSI/NFPA 72, Cl. 1-5.8.7.
Power Distribution Module, Controller Power Output	Supervised. Loss of power per ANSI/NFPA 72, Cl. 1-5.8.7.
Power Distribution Module, Field Device Power Output	Supervised. Single open or ground-fault per ANSI/NFPA 72, Cl. 1-5.8.
Power Distribution Module, Local Field Device Power Output	Unsupervised per ANSI/NFPA 72, Cl. 1-5.8, Exception #7 & #8.
Power Supply Monitor, Input Power	Supervised. Loss of power per ANSI/NFPA 72, Cl. 1-5.8.7.
Power Supply Monitor, Output Power	Supervised (via Controller for opens). Single open or ground-fault per ANSI/NFPA 72, Cl. 1-5.8.
Power Supply Monitor, Charger	Supervised. Loss of charger per NFPA Cl. 1-5.2.9.5.
Power Supply Monitor, Battery	Supervised. Loss of battery per NFPA Cl. 1-5.8.7.
Controller, Digital Input	Unsupervised per ANSI/NFPA 72, Cl. 1-5.8, Exception #7 & #8.
Controller, Relay Output	Unsupervised per ANSI/NFPA 72, Cl. 1-5.8, Exception #7 & #8.
Controller, Trouble Relay Output	Unsupervised per ANSI/NFPA 72, Cl. 1-5.8, Exception #7 & #8.
Relay Module, Output	Unsupervised, for connection with ancillary equipment only.
Enhanced Discrete I/O, Input (software configurable)	Unsupervised per ANSI/NFPA 72, Cl. 1-5.8, Exception #7 & #8.
	Initiating Device Circuit (IDC): Class A, Style D
	Initiating Device Circuit (IDC): Class A, Style E
	Initiating Device Circuit (IDC): Class B, Style B
	Initiating Device Circuit (IDCSC): Class B, Style C
Enhanced Discrete I/O, Output (software configurable)	Unsupervised per ANSI/NFPA 72, Cl. 1-5.8, Exception #7 & #8.
	Notification Appliance Circuit (NAC): Class A, Style Z
	Notification Appliance Circuit (NAC): Class B, Style Y
	Supervised Solenoids (Class A or Class B): Single open or ground-fault per ANSI/NFPA 72, Cl. 1-5.8. Group B: ASCO T8210A107 Group D: ASCO 8210G207 Group E: Skinner 73218BN4UNLVNOC111C2 Group F: Skinner 73212BN4TNLVNOC322C2 Group G: Skinner 71395SN2ENJ1NOH111C2 Group H: Viking HV-274-060-7

Table A-1—Circuit Classifications-Continued

Signaling Path	NFPA 72 Supervision
Direct Current I/O, Input (software configurable)	Unsupervised per ANSI/NFPA 72, Cl. 1-5.8, Exception #7 & #8.
	Initiating Device Circuit (IDC): Class B, Style B
	Initiating Device Circuit (IDCSC): Class B, Style C
Direct Current I/O, Output (software configurable)	Unsupervised per ANSI/NFPA 72, Cl. 1-5.8, Exception #7 & #8.
	Notification Appliance Circuit (NAC): Class B, Style Y
	Supervised Solenoids: Single open or ground-fault per ANSI/NFPA 72, Cl. 1-5.8. Group B: ASCO T8210A107 Group D: ASCO 8210G207 Group E: Skinner 73218BN4UNLVNOC111C2 Group F: Skinner 73212BN4TNLVNOC322C2 Group G: Skinner 71395SN2ENJ1NOH111C2 Group H: Viking HV-274-060-7
Analog Input Module	Initiating Device Circuit (IDC): Class B, Style B
IDC Input	Initiating Device Circuit (IDC): Class B, Style B
IDCGF Input (Channel 2 only)	Unsupervised per ANSI/NFPA 72, Cl. 1-5.8, Exception #7 & #8.
SAM Output	Notification Appliance Circuit (NAC): Class B, Style Y
ARM Output	Supervised Solenoids: Single open or ground-fault per ANSI/NFPA 72, Cl. 1-5.8. Group B: ASCO T8210A107 Group D: ASCO 8210G207 Group E: Skinner 73218BN4UNLVNOC111C2 Group F: Skinner 73212BN4TNLVNOC322C2 Group G: Skinner 71395SN2ENJ1NOH111C2 Group H: Viking HV-274-060-7



APPENDIX B

CSA INTERNATIONAL CERTIFICATION DESCRIPTION

HAZARDOUS LOCATIONS

- Refer to Figure B-1 for System Classification details.
- EQxxxxEM versions rated Class I, Div. 2, Groups A, B, C, D (T4A).

GAS DETECTION

• Combustible Gas Performance verified for 0 to 100% LFL methane-in-air atmospheres per CSA C22.2 No. 152. Accuracy: ±3% LFL from 0 to 50% LFL, ±5% LFL from 51% to 100% LFL. For the Model PIRECL, refer to the PIRECL manual (form number 95-8526) for further CSA gas performance details.

NOTE: Detector Electronics combustible gas detection K factors are not CSA verified.

- Calibration of the devices has been CSA verified using the respective EQ22xxDCU, EQ22xxDCUEX and PIRECL Series with the Det-Tronics 225130-001 (50% LFL methane) and 227115-001 H2S Calibration Kits.
- The EQ22xxDCU Series can be used with any CSA Certified 4-20 ma device.

NOTE

CSA Certification of the 4-20 ma input does not include or imply approval of the gas detection apparatus such as sensors, transmitters, or devices connected to the system. In order to maintain CSA Certification of the system, all 4-20 ma gas detection instruments connected to the input must also be CSA Certified.

NOTE

CSA Certification allows the presence and operation of serial communications software in the Controller (MODBUS, Allen Bradley protocols, etc.); however, the communications functions are not included in the Certification.

Figure B-1 (Drawing 007546-001)

APPENDIX C

CE MARK

EMC DIRECTIVE

The Eagle Quantum Premier Fire and Gas Detection/Releasing System was tested and found to be compliant with EN50081-2, EN50082-2, EN50130-4, and EN50270. The following considerations must be given for installation of the Eagle Quantum Premier system.

- For shielded cable installed in conduit, attach the wire shields to the "shield" connections on the terminal blocks, or to the earth ground on the case.
- For installations without conduit, use double shielded cable. Terminate the outer shield to the earth ground on the case. Terminate the inner shield to the "shield" connection on the terminal blocks.

ATEX DIRECTIVE

The Eagle Quantum Premier Fire and Gas Detection / Releasing System was tested and certified to hazardous location and combustible gas performance standards. Refer to Figure C-1 for system classification details.

Figure C-1 (Drawing 007547-001)

APPENDIX D

							R	ocker Sv	vitch Table								
Node Address	1	2	3 3	ocker 4	Swite 5	ch 6	7	8	Node Address	1	2	3 3	locker 4	Swite 5	ch 6	7	8
1 2 3 4 5 6 7 8 9	X O X O X O X	0 X X 0 0 X X 0 0	0 0 0 X X X X 0 0	0 0 0 0 0 0 0 0 X X	0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0	0000000000	71 72 73 74 75 76 77 78 79	X 0 X 0 X 0 X 0	X O O X X O O X	X O O O X X X X	O	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0	× × × × × × × ×	000000000000000000000000000000000000000
11 12 13 14 15 16 17 18 19 20	X O X O X O X	X O O X X O O X	O X X X X O O O X	X X X X X O O O O	0 0 0 0 0 X X X X	0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0	81 82 83 84 85 86 87 88 89	X O X O X O X O	O X X O O X X O O X	O O O X X X X O O O	0 0 0 0 0 0 0 0 0 0 X X	X X X X X X X X	0 0 0 0 0 0 0	× × × × × × × ×	0 0 0 0 0 0 0 0
21 22 23 24 25 26 27 28 29 30	X O X O X O X	O X X O O X X O O X	X X X O O O O X X	O O X X X X X X	× × × × × × × ×	0 0 0 0 0 0 0 0 0	0 0 0 0 0 0	00000000000	91 92 93 94 95 96 97 98 99	X O X O X O X O	X O O X X O O X X	O X X X X O O O X	X X X X O O O O	X X X X O O O	0 0 0 0 0 X X X X	× × × × × × × ×	0 0 0 0 0 0 0 0
31 32 33 34 35 36 37 38 39 40	X O X O X O X	X O O X X O O X X	X O O O X X X X	X 0 0 0 0 0 0 0	X 0 0 0 0 0 0	O	000000000	000000000	101 102 103 104 105 106 107 108 109	X 0 X 0 X 0 X 0 X	O X X O O X X O O X	X X X O O O O X X X	O O X X X X X X	0 0 0 0 0 0 0 0 0	X X X X X X X X	× × × × × × × ×	0 0 0 0 0 0 0 0
41 42 43 44 45 46 47 48 49 50	X O X O X O X	O X X O O X X O O X	O O O X X X X O O O	X X X X X X O O	0 0 0 0 0 0 0 0 0 0 X X	X X X X X X X X	0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0	111 112 113 114 115 116 117 118 119	X O X O X O X	X O O X X O O X	X O O O X X X X	X 0 0 0 0 0 0 0 0 0 0 0	O	X X X X X X X X	X X X X X X X X	0 0 0 0 0 0 0 0
51 52 53 54 55 56 57 58 59 60	X O X O X O X	X O O X X O O X	O X X X X O O O X	0 0 0 0 0 0 X X X X	× × × × × × × ×	X X X X X X X X	0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0	121 122 123 124 125 126 127 128 129 130	X 0 X 0 X 0 X 0	O	0 0 0 X X X X 0 0	X X X X X X O O	X X X X X X O O	X X X X X X O O	X X X X X X O O	0 0 0 0 0 0 X X
61 62 63 64 65 66 67 68 69 70	X O X O X O X	0 X X 0 0 X X 0 0	X X X O O O O X X X	X X X 0 0 0 0 0	X X X 0 0 0 0 0	X X X O O O O O	O O X X X X X X	0000000000	131 132 133 134 135 136 137 138 139	X O X O X O X O	X O O X X O O X X	O X X X X O O O X	0 0 0 0 0 X X X X	0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0	X X X X X X X X X

Rocker	Switch	Table
		No

		ode Rocker Switch						R	ocker Switcl									
4	Node Address	1	2	3 3	ocker 4	Swite 5	ch 6	7	8	Node Address	1	2	3 3	ocker 4	Swite 5	ch 6	7	8
	141 142 143 144 145 146 147 148 149 150	X O X O X O X	O	X X X O O O O X X	X X X O O O O O	O O O X X X X X X X X X X X X X X X X X	0 0 0 0 0 0	0 0 0 0 0 0	X X X X X X X X	211 212 213 214 215 216 217 218 219 220	X O X O X O X	X O O X X X O O X	O X X X X O O O X X	O O O O X X X X X X X	× × × × × × × ×	0 0 0 0 0 0	X X X X X X X X	X X X X X X X X
	151 152 153 154 155 156 157 158 159	X O X O X O X	X O O X X O O X X	X O O O O X X X X	O	X X X X X X X X	0 0 0 0 0 0	0 0 0 0 0 0 0 0 0	X X X X X X X	221 222 223 224 225 226 227 228 229 230	X O X O X O X	O X X O O X X O O X	X X X O O O O X X X	X X X O O O O O	X X X O O O O O	O O X X X X X X	X X X X X X X X	X X X X X X X X
	161 162 163 164 165 166 167 168 169	X O X O X O X	O X X O O X X O O X	0 0 0 X X X X 0 0	0 0 0 0 0 0 0 0 X X	0 0 0 0 0 0 0 0 0	× × × × × × × ×	0000000000	X X X X X X X	231 232 233 234 235 236 237 238 239 240	X O X O X O X	X O O X X O O X X	X 0 0 0 0 X X X X	O	0 0 0 0 0 0 0 0 0 0 0 0 0	× × × × × × × ×	× × × × × × × ×	X X X X X X X
	171 172 173 174 175 176 177 178 179 180	X O X O X O X	X O O X X O O X X	O	X X X X O O O O	O O O O X X X X	× × × × × × ×	000000000	X X X X X X X X	241 242 243 244 245 246 247 248 249 250	X O X O X O X	O X X O O X X X O O X	0 0 0 X X X X 0 0	0 0 0 0 0 0 0 0 X X	× × × × × × × ×	× × × × × × × ×	× × × × × × × ×	X X X X X X X
	181 182 183 184 185 186 187 188 189 190	X O X O X O X	O X X O O X X O O X	X X X O O O O X X	O O X X X X X X	X X X X X X X X	X X X X X X X X	0 0 0 0 0 0 0 0	X X X X X X X X					OPEN CLOSEI)			
	191 192 193 194 195 196 197 198 199 200	X O X O X O X	X O O X X O O X X	X O O O X X X X	X 0 0 0 0 0 0 0	X 0 0 0 0 0 0	X 0 0 0 0 0 0 0 0 0	O	X X X X X X X X									
	201 202 203 204 205 206 207 208 209 210	X O X O X O X O	O X X O O X X X O O X	O O O X X X X O O O	X X X X X X O O	O O O O X X X	0 0 0 0 0 0 0 0 0	X X X X X X X X	X X X X X X X X									
4.1									D-3								95	-853

