



95-8527

Protect•IR[®] Multispectrum IR Flame Detector X3301



Table of Contents

DESCRIPTION	1
Outputs	1
LED	2
Optical Integrity (oi)	2
Communication	3
Data Logging	3
Integral Wiring Compartment	3
GENERAL APPLICATION INFORMATION	3
Response Characteristics	3
Important Application Considerations	3
IMPORTANT SAFETY NOTES	4
INSTALLATION	4
Detector Positioning	4
Detector Orientation	5
Protection Against Moisture Damage	5
Wiring Procedure	5
Setting Device Network Addresses (EQP Model Only)1	2
STARTUP PROCEDURE	3
Fire Alarm Test	3

TROUBLESHOOTING
MAINTENANCE 14 Cleaning Procedure 14 oi Plate Removal and Replacement 14 Periodic Checkout Procedure 15 Clock Battery 15
FEATURES15
SPECIFICATIONS
REPLACEMENT PARTS
DEVICE REPAIR AND RETURN
ORDERING INFORMATION
APPENDIX A – FM APPROVAL AND PERFORMANCE REPORT20
APPENDIX B – CSA APPROVAL
APPENDIX C – ATEX / CE APPROVAL
APPENDIX D – IECEx APPROVAL
APPENDIX E – VdS APPROVAL
APPENDIX F – OFFSHORE APPROVALS
APPENDIX G – ADDITIONAL APPROVALS
APPENDIX H – APPROVED ACCESSORIES37



INSTRUCTIONS



Protect•IR[®] Multispectrum IR Flame Detector X3301

IMPORTANT

Be sure to read and understand the entire instruction manual before installing or operating the flame detection system. Any deviation from the recommendations in this manual may impair system performance and compromise safety.

ATTENTION

The X3301 includes the Automatic Optical Integrity (o_i°) feature — a calibrated performance test that is automatically performed once per minute to verify complete detector operation capabilities. No testing with an external test lamp is required.

DESCRIPTION

The X3301 Protect•IR[®] is a multispectrum infrared (IR) flame detector. It provides unsurpassed detection of fires from light to heavy hydrocarbon fuels combined with the highest degree of false alarm rejection. The detector has Division and Zone explosion-proof ratings and is suitable for use in indoor and outdoor applications.

The X3301 contains three IR sensors with their associated signal processing circuitry. The standard output configuration includes fire, fault and auxiliary relays. Output options include:

- 0 to 20 mA output (in addition to the three relays)
- Pulse output for compatibility with existing controller based systems (with fire and fault relays)
- Eagle Quantum Premier[®] (EQP) compatible model (no analog or relay outputs).
- HART communication.



A tricolor LED on the detector faceplate indicates normal condition and notifies personnel of fire alarm or fault conditions.

Microprocessor controlled heated optics increase resistance to moisture and ice.

The X3301 housing is available in copper-free aluminum or stainless steel, with NEMA 4X and IP66 rating.

OUTPUTS

Relays

The standard detector is furnished with fire, fault and auxiliary relays. All three relays are rated 5 amperes at 30 Vdc.

The Fire Alarm relay has redundant terminals and normally open / normally closed contacts, normally de-energized operation, and latching or non-latching operation.

The Fault relay has redundant terminals and normally open contacts, normally energized operation, and latching or non-latching operation.

X3301 technology advancements are covered under the following U.S. Patents: 5,995,008, 5,804,825 and 5,850,182.

The Auxiliary relay has normally open / normally closed contacts, and is configurable for energized or de-energized operation, and latching or non-latching operation.

0 to 20 mA Output

A 0 to 20 mA output is available as an option (in addition to the three relays). This option provides a 0 to 20 mA dc current output for transmitting detector status information to other devices. The circuit can be wired in either an isolated or non-isolated configuration and can drive a maximum loop resistance of 500 ohms from 18 to 19.9 Vdc and 600 ohms from 20 to 30 Vdc. Table 1 indicates the detector status conditions represented by the various current levels. The output is calibrated at the factory, with no need for field calibration. A model with relays and 0-20 mA with HART is also available. Refer to Addendum number 95-8577 for complete details.

NOTE

The output of the 0 to 20 mA current loop is not monitored by the fault detection circuitry of the X3301. Therefore, an open circuit on the loop will not cause the fault relay to change state or the detector status LED to indicate a fault. The status of the LED always follows the status of the relays.

An alarm condition will normally over-ride a fault condition, unless the nature of the fault condition impairs the ability of the detector to generate or maintain an alarm output, i.e. loss of operating power.

Table	1—	Detector	Status	Conditions	Indicated	hv	Current	l evel
Table		Delector	Otatus	Contaitions	mulcalcu	bу	ounoni	LCVCI

Current Level (±0.3 mA)	Detector Status
0 mA	Power Fault
1 mA	General Fault
2 mA	oi Fault
3 mA	Hi Background IR
4 mA	Normal Operation
20 mA	Fire Alarm

LON/SLC Output

The EQP model is designed for use exclusively with Detector Electronics Corporation's (Det-Tronics[®]) Eagle Quantum Premier system. The detector communicates with the system controller over a digital communication network or LON/SLC (Local Operating Network / Signaling Line Circuit). The LON/SLC is a fault tolerant, two wire digital communication network arranged in a loop configuration. Analog and relay outputs are not available on this model.

LED

A tricolor LED on the detector faceplate indicates normal condition and notifies personnel of fire alarm or fault conditions. Table 2 indicates the condition of the LED for each status.

OPTICAL INTEGRITY (Oi)

Automatic oi

The X3301 includes the Automatic Optical Integrity (**oi**) feature — a calibrated performance test that is automatically performed once per minute to verify complete detector operation capabilities. No testing with an external test lamp is required. The detector automatically performs the same test that a maintenance person with a test lamp would perform — once every minute, 60 times per hour. However, a successful automatic **oi** test does not produce an alarm condition.

The Protect•IR signals a fault condition when less than half of the detection range remains. This is indicated by the Fault relay and is evident by the yellow color of the LED on the face of the detector. See the "Troubleshooting" section for further information.

Magnetic oi / Manual oi

The detector also incorporates both magnetic **oi** and manual **oi** features that provide the same calibrated test as the automatic **oi**, and in addition actuates the Alarm relay to verify output operation for preventive maintenance requirements. These features can be performed at any time and eliminate the need for testing with a non-calibrated external test lamp.

CAUTION

These tests require disabling of all extinguishing devices to avoid release resulting from a successful test.

Detector Status	LED Indicator
Power On/Normal Operation (no fault or fire alarm)	Green
Fault	Yellow
Fire (Alarm)	Red
Low Sensitivity	One Yellow Flash During Power-up
Medium Sensitivity	Two Yellow Flashes During Power-up
Very High Sensitivity	Four Yellow Flashes During Power-up

Table 2-Detector Status Indicator

The magnetic **o**_i test is performed by placing a magnet by the marked location (mag **o**_i) on the outside of the detector. The manual **o**_i test is accomplished by connecting the **o**_i lead (terminal 22) to power supply minus via an external switch. The magnet or switch must be held in place for a minimum of 6 seconds to complete the test. Either of these test methods activates the calibrated IR emitters. If the resulting signal meets the test criteria, indicating that greater than half of the detection range remains, the Alarm relay changes state, the indicating LED changes to red, and the 0-20 mA current output goes to 20 mA. This condition remains until the magnet is removed or the switch is released, regardless of whether the relays are set for latching or non-latching operation.

If less than half of the detection range remains, no alarm is produced and a fault is generated. The fault indication can be reset by momentarily applying the magnet or manual **oi** switch.

NOTE

Refer to Appendix A for FM verification of Det-Tronics' Optical Integrity **o**_i function.

COMMUNICATION

The X3301 is furnished with an RS-485 interface for communicating status and other information with external devices. The RS-485 supports MODBUS protocol, with the detector configured as a slave device.

NOTE

The EQP model uses LON/SLC communication. RS-485 communication is not available on the EQP model.

DATA LOGGING

Data logging capability is also provided. Status conditions such as normal, power down, general and **oi** faults, pre-alarm, fire alarm, time and temperature are recorded. Each event is time and date stamped, along with the temperature and input voltage. Event data is stored in non-volatile memory when the event becomes active, and again when the status changes. Data is accessible using the RS-485 port or the EQP controller.

INTEGRAL WIRING COMPARTMENT

All external wiring to the device is connected within the integral junction box. The screw terminals accept wiring from 14 to 24 AWG. The detector is furnished with four conduit entries, with either 3/4 inch NPT or 25 mm threads.

GENERAL APPLICATION INFORMATION

RESPONSE CHARACTERISTICS

Response is dependent on distance, type of fuel, temperature of the fuel, and time required for the fire to come to equilibrium. As with all fire tests, results must be interpreted according to an individual application. See Appendix A for fire test results.

IMPORTANT APPLICATION CONSIDERATIONS

In applying any type of sensing device as a fire detector, it is important to know of any conditions that can prevent the device from responding to fire, and also to know what other sources besides fire can cause the device to respond.

Welding

Arc welding should not be performed within 40 feet of the very high sensitivity detector, 10 feet of the medium sensitivity detector, or 5 feet of the low sensitivity detector. It is recommended that the system be bypassed during welding operations in situations where the possibility of a false alarm cannot be tolerated. Gas welding mandates system bypass, since the gas torch is an actual fire. Arc welding rods can contain organic binder materials in the flux that burn during the welding operation and are detectable by the X3301. Welding rods with clay binders do not burn and will not be detected by the X3301. However, system bypass is always recommended, since the material being welded may be contaminated with organic substances (paint, oil, etc.) that will burn and possibly trigger the X3301.

Artificial Lighting

The X3301 should not be located within 3 feet of artificial lights. Excess heating of the detector could occur due to heat radiating from the lights.

EMI/RFI Interference

The X3301 is resistant to interference by EMI and RFI, and is EMC Directive compliant. It will not respond to a 5 watt walkie-talkie at distances greater than 1 foot. Do not operate a walkie-talkie within 1 foot of the X3301.

Non-Carbon Fires

The X3301 is a multiple spectrum IR device with detection limited to carbonaceous fuels. It should not be used to detect fires from fuels that do not contain carbon, such as hydrogen, sulfur and burning metals.

IMPORTANT SAFETY NOTES

AWARNING

Do not open the detector assembly in a hazardous area when power is applied. The detector contains limited serviceable components and should never be opened. Doing so could disturb critical optical alignment and calibration parameters, possibly causing serious damage. This type of damage could be undetected and could result in failure to see a fire and/or false alarm.

CAUTION

The wiring procedures in this manual are intended to ensure proper functioning of the device under normal conditions. However, because of the many variations in wiring codes and regulations, total compliance to these ordinances cannot be guaranteed. Be certain that all wiring complies with the NEC as well as all local ordinances. If in doubt, consult the authority having jurisdiction before wiring the system. Installation must be done by a properly trained person.

CAUTION

To prevent unwanted actuation or alarm, extinguishing devices must be disabled prior to performing system tests or maintenance.

CAUTION

The multispectrum IR flame detectors are to be installed in places where the risk of mechanical damages is low.

ATTENTION

Remove the protective cap from the front of the detector before activating the system.

ATTENTION

Observe precautions for handling electrostatic sensitive devices.

INSTALLATION

NOTE

The recommended lubricant for threads and O-rings is a silicone free grease (part number 005003-001) available from Detector Electronics. Under no circumstances should a lubricant containing silicone be used.

DETECTOR POSITIONING

Detectors should be positioned to provide the best unobstructed view of the area to be protected. The following factors should also be taken into consideration:

- Identify all high risk fire ignition sources.
- Be sure that enough detectors are used to adequately cover the hazardous area.
- Be sure that the unit is easily accessible for cleaning and other periodic servicing.
- Locate and position the detector so that the fire hazard(s) are within both the field of view and detection range of the device. Refer to Appendix A for specific information.
- The detector should be aimed downward at least 10 to 20 degrees to allow lens openings to drain. See Figure 1. The detector should be positioned so that its field of view does not cover areas outside the hazardous area. This will minimize the possibility of false alarms caused by activities outside the area requiring protection.
- For best performance, the detector should be mounted on a rigid surface in a low vibration area.
- Dense fog, rain or ice can absorb IR radiation and reduce the sensitivity of the detector.



NOTE: DETECTOR MUST ALWAYS BE AIMED DOWNWARD AT LEAST 10 TO 20 DEGREES.

Figure 1—Detector Orientation Relative to Horizon

- Although IR detectors are less affected by smoke than other detectors, the X3301 should not be placed where rising combustion products can obscure its vision. If smoke is expected before fire, smoke or other alternative detectors should be used in conjunction with the X3301. For indoor applications, if dense smoke is expected to accumulate at the onset of a fire, mount the detector on a side wall at least a few feet (approximately 1 meter) down from the ceiling.
- If possible, fire tests should be conducted to verify correct detector positioning and coverage.
- For ATEX installations, the X3301 detector housing must be electrically connected to earth ground.



Figure 2—Front View of the X3301

DETECTOR ORIENTATION

Refer to Figure 2 and ensure that the **oi** plate will be oriented as shown when the X3301 is mounted and sighted. This will ensure proper operation of the **oi** system and will also minimize the accumulation of moisture and contaminants between the **oi** plate and the viewing windows.

IMPORTANT

The **oi** plate **must** be securely tightened to ensure proper operation of the **oi** system (40 oz./inches recommended).

PROTECTION AGAINST MOISTURE DAMAGE

It is important to take proper precautions during installation to ensure that moisture will not come in contact with the electrical connections or components of the system. The integrity of the system regarding moisture protection must be maintained for proper operation and is the responsibility of the installer.

If conduit is used, we recommend installing drains, according to local codes, at water collection points to automatically drain accumulated moisture.

It is also recommended to install at least one breather, according to local codes, at upper locations to provide ventilation and allow water vapor to escape.

Conduit raceways should be inclined so that water will flow to low points for drainage and will not collect inside enclosures or on conduit seals. If this is not possible, install conduit drains above the seals to prevent the collection of water or install a drain loop below the detector with a conduit drain at the lowest point of the loop.

Conduit seals are not required for compliance with explosion-proof installation requirements, but are highly recommended to prevent water ingress in outdoor applications. Units with M25 thread must use an IP66 washer to prevent water ingress.

WIRING PROCEDURE

Wire Size and Type

The system should be wired according to local codes. The wire size selected should be based on the number of detectors connected, the supply voltage and the cable length. Typically 14 AWG (2.08 mm²) or 16 AWG (1.31 mm²) shielded cable is recommended. Wires should be stripped 3/8 inch (9 mm). A minimum input voltage of 18 Vdc must be present at the X3301.

NOTE

Refer to "Power Consumption" in the "Specifications" section of this manual.

The use of shielded cable is required to protect against interference caused by EMI and RFI. When using cables with shields, terminate the shields as shown in Figures 7 through 12, and Figure 14. Consult the factory if not using shielded cable.

In applications where the wiring cable is installed in conduit, the conduit must not be used for wiring to other electrical equipment.

If disconnection of power is required, separate disconnect capability must be provided.

CAUTION

Installation of the detector and wiring should be performed only by qualified personnel.

Detector Mounting

Install the swivel mounting bracket assembly on the wall. The installation surface should be free of vibration and suitable to receive 1/4 inch (M6) screws with a length of at least 1 inch (25 mm), and have sufficient capacity to hold the detector and bracket weight. Refer to Figure 3 for dimensions.

Relay and 0-20 mA Output Models

Follow the instructions below to install the X3301.

- 1. Make field connections following local ordinances and guidelines in this manual.
 - Figure 4 shows the wiring terminal strip located inside the detector's integral junction box.
 - Figure 5 shows the wiring terminal identification for the X3301 detector.
 - Figure 6 shows an EOL resistor installed within the integral wiring compartment of the detector (refer to "EOL Resistors" for details).
 - Figures 7 and 8 provide examples of typical installations with a X3301 wired to a fire alarm panel.
 - If the detector is equipped with a 0 to 20 mA output, refer to Figures 9 through 12.
- 2. Check all field wiring to be sure that the proper connections have been made.

IMPORTANT

Do not test any wiring connected to the detector with a meg-ohmmeter. Disconnect wiring at the detector before checking system wiring for continuity.

3. Make the final sighting adjustments and ensure that the mounting bracket hardware is tight.

EOL Resistors (Not Used with EQP Model)

To ensure that the insulating material of the wiring terminal block will not be affected by the heat generated by EOL resistors, observe the following guidelines when installing the resistors.

1. Required EOL resistor power rating must be 5 watts minimum.

NOTE

EOL resistors must be ceramic, wirewound type, rated 5 watts minimum, with actual power dissipation not to exceed 2.5 watts. This applies to ATEX/IEC installations only.

- 2. Resistor leads should be cut to a length of approximately 1 1/2 inches (40 mm).
- 3. Bend the leads and install the EOL resistor as shown in Figure 6.
- 4. Maintain a 3/8 inch (10 mm) minimum gap between the resistor body and the terminal block or any other neighboring parts.

NOTE

The EOL resistor can only be used within the flameproof terminal compartment. Unused apertures shall be closed with suitable blanking elements.





Figure 3—Q9033 Mounting Bracket Dimensions in Inches (cm) (See Figure 1 for Correct Detector Orientation.)



Figure 4—X3301 Terminal Block

9	4-20 mA +	19	4-20 mA – SPARE	29
8	4-20 mA + REF	18	4-20 mA – REF SPARE	28
7	COM FIRE	17	COM FIRE COM AUX	27
6	N.O. FIRE	16	N.O. FIRE N.O. AUX	26
5	N.C. FIRE	15	N.C. FIRE N.C. AUX	25
4	COM FAULT	14	COM FAULT RS-485 A	24
3	N.O. FAULT	13	N.O. FAULT RS-485 B	23
2	24 VDC +	12	24 VDC + MAN O_i	22
1	24 VDC –	11	24 VDC – 24 VDC –	21





Figure 6—EOL Resistor Installation (For Ex d Wiring only)



- 1 IN NORMAL OPERATION WITH NO FAULTS OCCURRING, THE FAULT RELAY COIL IS ENERGIZED AND THE NORMALLY OPEN (N.O.) AND COMMON (COM) CONTACTS ARE CLOSED.
- 2 ALARM RELAY IS NORMALLY DE-ENERGIZED WITH NO ALARM CONDITION PRESENT.
- 3 INDIVIDUAL MANUAL σ_i TEST SWITCHES CAN BE INSTALLED REMOTELY OR A DETECTOR SELECTOR AND ACTIVATION SWITCH CAN BE INSTALLED AT THE FIRE PANEL. TEST SWITCHES ARE NOT SUPPLIED.
- 4 REFER TO SPECIFICATIONS SECTION FOR EOL RESISTOR VALUES. REFER TO EOL RESISTORS SECTION FOR INSTALLATION DETAILS.

Figure 7—Ex d Wiring Option



- 1 IN NORMAL OPERATION WITH NO FAULTS OCCURRING, THE FAULT RELAY COIL IS ENERGIZED AND THE NORMALLY OPEN (N.O.) AND COMMON (COM) CONTACTS ARE CLOSED.
- 2 ALARM RELAY IS NORMALLY DE-ENERGIZED WITH NO ALARM CONDITION PRESENT.
- 3 INDIVIDUAL MANUAL oI TEST SWITCHES CAN BE INSTALLED REMOTELY OR A DETECTOR SELECTOR AND ACTIVATION SWITCH CAN BE INSTALLED AT THE FIRE PANEL. TEST SWITCHES ARE NOT SUPPLIED.
- 4 EOL RESISTOR SUPPLIED BY PANEL.

Figure 8—Ex d e Wiring Option



Figure 9—X3301 Detector Wired for Non-Isolated 0 to 20 mA Current Output (Sourcing)



Figure 10—X3301 Detector Wired for Non-Isolated 0 to 20 mA Current Output (Sinking)





Figure 12—X3301 Detector Wired for Isolated 0 to 20 mA Current Output (Sinking)

NOTES: 1. INDIVIDUAL MANUAL oj TEST SWITCHES CAN BE INSTALLED REMOTELY OR A DETECTOR SELECTOR AND ACTIVATION SWITCH CAN BE INSTALLED AT THE FIRE PANEL. TEST SWITCHES ARE NOT SUPPLIED.

EQP Model

- 1. Connect external wires to the appropriate terminals inside the device junction box. (See Figure 13 for terminal identification.)
- 2. Connect the shield of the power cable to "earth ground" at the power source.
- 3. Connect shields for the LON cable as indicated. See Figure 14.

NOTE

DO NOT ground any shields at the detector housing.

4. Set the device network address. (See "Setting Device Network Addresses" section of this manual for switch setting procedure.)

- 5. Check all field wiring to be sure that the proper connections have been made.
- 6. Replace the device cover.
- 7. Make the final sighting adjustments and ensure that the mounting bracket hardware is tight.

NOTE

Refer to the Eagle Quantum Premier system manual 95-8533 for information regarding power and network communication cable requirements.









Figure 15—Location of Address Switches

SETTING DEVICE NETWORK ADDRESSES (EQP Model Only)

Overview of Network Addresses

Each device on the LON must be assigned a unique address. Addresses 1 to 4 are reserved for the controller. Valid addresses for field devices are from 5 to 250.

IMPORTANT

If the address is set to zero or an address above 250, the switch setting will be ignored.

Duplicated addresses are not automatically detected. Modules given the same address will use the number given and report to the controller using that address. The status word will show the latest update, which could be from any of the reporting modules using that address.

Setting Field Device Addresses

Selection of the node address is done by setting rocker switches on an 8 switch "DIP Switch Assembly" within the detector's housing. Refer to Figure 15 for switch location.

WARNING

The network address switches are located within the detector housing. Disassembly of the detector head that contains powered electrical circuits is required to gain access to the network address switches. For hazardous areas, the area must be de-classified before attempting disassembly of the device. Always observe precautions for handling electrostatic sensitive devices. The address number is binary encoded with each switch having a specific binary value with switch 1 being the LSB (Least Significant Bit). (See Figure 16) The device's LON address is equal to the added value of all closed rocker switches. All "Open" switches are ignored.

Example: for node No. 5, close rocker switches 1 and 3 (binary values 1 + 4); for node No. 25, close rocker switches 1, 4 and 5 (binary values 1 + 8 + 16).

NOTE

The field device sets the LON address only when power is applied to the device. Therefore, it is important to set the switches **before** applying power. If an address is ever changed, system power must be cycled before the new address will take effect.

After setting address switches, record the address number and device type.



Figure 16—Address Switches for X3301

STARTUP PROCEDURE

When installation of the equipment is complete, perform the "Fire Alarm Test" below.

FIRE ALARM TEST

- 1. Disable any extinguishing equipment that is connected to the system.
- 2. Apply input power to the system.
- Initiate an oi test. (See "Magnetic oi / Manual oi" under Optical Integrity in the Description section of this manual.)
- 4. Repeat this test for all detectors in the system. If a unit fails the test, refer to the "Troubleshooting" section.
- 5. Verify that all detectors in the system are properly aimed at the area to be protected. (The Det-Tronics Q1201C Laser Aimer is recommended for this purpose.)
- 6. Enable extinguishing equipment when the test is complete.

TROUBLESHOOTING

WARNING

The sensor module ("front" half of the detector) contains no user serviceable components and should never be opened. The terminal compartment is the only part of the enclosure that should be opened by the user in the field.

- 1. Disable any extinguishing equipment that is connected to the unit.
- Inspect the viewing windows for contamination and clean as necessary. The detector is relatively insensitive to airborne contaminants, however, thick deposits of ice, dirt, or oil will reduce sensitivity. (Refer to the "Maintenance" section for complete information regarding cleaning of the detector viewing windows.)

Current Level (±0.3 mA)	Status	Action
0 mA	Power Fault	Check system wiring.
1 mA	General Fault	Cycle power.1
2 mA	oi Fault	Clean windows. ²
3 mA	Hi Background IR	Remove IR source or aim detector away from IR source.
4 mA	Normal Operation	
20 mA	Fire Alarm	

¹If fault continues, return device to factory for repair. ²See "Maintenance" section for cleaning procedure.

- 3. Check input power to the unit.
- If the fire system has a logging function, check the fire panel log for output status information. See Table 3 for information regarding 0 to 20 mA output.
- 5. Turn off the input power to the detector and check all wiring for continuity. **Important: Disconnect wiring at the detector before checking system wiring for continuity.**
- 6. If all wiring checks out and cleaning of the oi plate/ window did not correct the fault condition, check for high levels of background IR radiation by covering the detector with the factory supplied cover or aluminum foil. If the fault condition clears within 6 minutes or less, extreme background IR is present. Re-adjust the view of the detector away from the IR source or relocate the detector.

If none of these actions corrects the problem, return the detector to the factory for repair.

NOTE

It is highly recommended that a complete spare be kept on hand for field replacement to ensure continuous protection.

MAINTENANCE

IMPORTANT

Periodic flamepath inspections are not recommended, since the product is not intended to be serviced and provides proper ingress protection to eliminate potential deterioration of the flamepaths.

WARNING

The sensor module ("front" half of the detector) contains no user serviceable components and should never be opened. The terminal compartment is the only part of the enclosure that should be opened by the user in the field.

NOTE

Refer to the X3301 Safety Manual 95-8582 for specific requirements and recommendations applicable to the proper installation, operation, and maintenance of all SIL-Certified X3301 flame detectors.

To maintain maximum sensitivity and false alarm resistance, the viewing windows of the X3301 must be kept relatively clean. Refer to the following procedure for cleaning instructions.

CLEANING PROCEDURE

CAUTION

Disable any extinguishing equipment that is connected to the unit to prevent unwanted actuation.

To clean the windows and **oi** plate, use Det-Tronics window cleaner (part number 001680-001) and a soft cloth, cotton swab or tissue and refer to the following procedure:

1. Disable any extinguishing equipment that is connected to the unit.

- Since the X3301 is less affected by contamination than other detectors, removal of the oi plate is needed only under extreme conditions. In addition, it is not necessary to achieve perfect cleanliness, because IR is not significantly absorbed by slight films of oil and/or salt. If a fault condition is still indicated after cleaning, remove and clean the oi plate using the oi Plate Removal and Replacement procedure.
- In all environments, clean all three viewing windows and reflector surfaces thoroughly. Use a cotton swab and Det-Tronics window cleaning solution. Use Isopropyl alcohol for contaminations that the Det-Tronics window cleaning solution can not remove.



Figure 17-0i Plate Removal

IMPORTANT

When used in extreme environments, the reflective surface of the detector **o**_i plate may eventually deteriorate, resulting in reoccurring **o**_i faults and the need for **o**_i plate replacement.

OI PLATE REMOVAL AND REPLACEMENT

1. Disable any extinguishing equipment that is connected to the unit.

- Loosen the two captive screws, then grasp the oi plate by the visor and remove it from the detector. See Figure 17.
- 3. Install the new (or cleaned) oi plate.

NOTE

When installing the stainless steel plate, ensure that the gasket is present and correctly seated to prevent moisture or contaminants from penetrating behind the plate. To ensure even seating, tighten both screws equally.

4. Re-calibrate the detector's **oi** system. Refer to the Inspector Monitor manual, 95-8581, for instructions regarding **oi** plate replacement and **oi** system recalibration.

CAUTION

Do not replace the **o**_{*i*} reflector plate without also recalibrating the **o**_{*i*} system.

Recalibration of the **oi** system requires the use of the Inspector Connector Cable and Inspector Monitor Software. These two items are included in the **oi** replacement kit, or they can be purchased separately. See Ordering Information for details. Refer to the Inspector Monitor manual, 95-8581, for instructions regarding **oi** plate replacement and **oi** system recalibration.

X3301 Reflector Plates

X3301 models are supplied with either a black or a stainless steel reflector plate. These plates are **not** interchangeable. Order the replacement that matches the reflector plate on your X3301 detector.

PERIODIC CHECKOUT PROCEDURE

A checkout of the system using the manual or magnetic oi feature should be performed on a regularly scheduled basis to ensure that the system is operating properly. To test the system, perform the "Fire Alarm Test" as described in the "Startup Procedure" section of this manual.

CLOCK BATTERY

(Not used with EQP Model)

The real time clock has a backup battery that will operate the clock with no external power for nominally 10 years. It is recommended that the battery be replaced every 7 years. Return the device to the factory for battery replacement.

NOTE

If the backup battery is depleted, there is no effect on the operation of the flame detector, but the time stamping of the data log may be affected.

FEATURES

- Long detection range to carbonaceous fires.
- Unequaled false alarm rejection.
- Responds to a fire in the presence of modulated blackbody radiation (i.e. heaters, ovens, turbines) without false alarm.
- Microprocessor controlled heated optics for increased resistance to moisture and ice.
- Automatic, manual or magnetic optical integrity (oi) testing.
- Easily replaceable oi plate.
- Fire, fault and auxiliary relays standard.
- 0 to 20 mA isolated output (optional).
- Eagle Quantum Premier LON/SLC output (optional).
- A tricolor LED on the detector faceplate indicates normal condition and notifies personnel of fire alarm or fault conditions.
- Operates under adverse weather conditions and in dirty environments.
- Mounting swivel allows easy sighting.
- Integral wiring compartment for ease of installation.
- Explosion-proof/flame-proof detector housing. Meets FM, CSA, ATEX Directive and CE certification requirements.
- Class A wiring per NFPA-72.
- Meets NFPA-33 response requirement for under 0.5 second (available when model selected).
- 5 year warranty.
- RFI and EMC Directive compliant.

ASSOCIATED MANUALS

List of X3301 related manuals:

TITLE	FORM NUMBER
Pulse	95-8528
EQP	95-8533
SIL 2 (Safety)	95-8582
HART Addendum	95-8577
Automotive Addendum	95-8534
Hangar	95-8548

SPECIFICATIONS

OPERATING VOLTAGE-

24 Vdc nominal (18 Vdc minimum, 30 Vdc maximum). Maximum ripple is 2 volts peak-to-peak.

POWER CONSUMPTION—

Without heater: 4 watts at 24 Vdc nominal;

5.2 watts at 24 Vdc in alarm.

4.5 watts at 30 Vdc nominal;

6.5 watts at 30 Vdc in alarm.

Heater only: 8 watts maximum.

Total power: 17 watts at 30 Vdc with EOL resistor installed and heater on maximum.

EOL resistor must be ceramic, wirewound type, rated 5 watts minimum, with actual power dissipation not to exceed 2.5 watts.

For HART model, refer to Addendum number 95-8577.

POWER UP TIME-

Fault indication clears after 0.5 second; device is ready to indicate an alarm condition after 30 seconds.

OUTPUT RELAYS-

Fire Alarm relay, Form C, 5 amperes at 30 Vdc: The Fire Alarm relay has redundant terminals and normally open / normally closed contacts, normally de-energized operation, and latching or nonlatching operation.

Fault relay, Form A, 5 amperes at 30 Vdc:

The Fault relay has redundant terminals and normally open contacts, normally energized operation, and latching or non-latching operation.

Auxiliary relay, Form C, 5 amperes at 30 Vdc:

The auxiliary relay has normally open/normally closed contacts, normally energized or de-energized operation, and latching or non-latching operation.

CURRENT OUTPUT (OPTIONAL)-

0 to 20 milliampere (\pm 0.3 mA) dc current, with a maximum loop resistance of 500 ohms from 18 to 19.9 Vdc and 600 ohms from 20 to 30 Vdc.

LON OUTPUT—

Digital communication, transformer isolated (78.5 kbps).

TEMPERATURE RANGE—

Operating: -40° F to $+167^{\circ}$ F (-40° C to $+75^{\circ}$ C). Storage: -67° F to $+185^{\circ}$ F (-55° C to $+85^{\circ}$ C). Hazardous location ratings from -55° C to $+125^{\circ}$ C.

HUMIDITY RANGE-

0 to 95% relative humidity, can withstand 100% condensing humidity for short periods of time.

CONE OF VISION-

The detector has a 90° cone of vision (horizontal) with the highest sensitivity lying along the central axis. Unlike conventional detectors, the X3301 provides full coverage at a minimum of 70% of the maximum detection distance.

Perfect cone of vision for methane fire detection — 100 feet on and off axis on "very high" setting.

Refer to Appendix A for FM Approved cone of vision data.

RESPONSE TIME—

Typical response times are under 10 seconds. Models are available that can respond to automotive paint gun fires in under 0.5 seconds. See Appendix A and "Automotive Addendum" (95-8534) for actual response times.

DIMENSIONS-

See Figure 18.



Figure 18—X3301 Dimensions in Inches (cm)

ENCLOSURE MATERIAL

Copper-free aluminum (painted) or 316 stainless steel.

VIBRATION-

Conformance per FM 3260: 2000, MIL-STD 810C (Curve AW), DNV Note 2.4 (Class B).

WIRING-

Field wiring screw terminals are UL/CSA rated for up to 14 AWG wire, and are DIN/VDE rated for 2.5 mm^2 wire. Screw terminal required torque range is 3.5-4.4 in.-lbs. (0.4-0.5 N·m).

14 AWG (2.08 mm²) or 16 AWG (1.31 mm²) shielded cable is recommended.

Important: 18 Vdc minimum must be available at the detector. For ambient temperatures below –10°C and above +60°C use field wiring suitable for both minimum and maximum ambient temperature.

THREAD SIZE—

Conduit connection: Four entries, 3/4 inch NPT or M25. Conduit seal not required.

SHIPPING WEIGHT (Approximate)-

Aluminum:6 pounds (2.75 kilograms).Stainless Steel:10 pounds (4.5 kilograms).Swivel Mount (AL):6 pounds (2.75 kilograms).Swivel Mount (SS):14 pounds (6.4 kilograms).

WARRANTY PERIOD— **5 years.**

CERTIFICATION-



For complete approval details, refer to the appropriate Appendix:

Appendix A - FM Appendix B - CSA Appendix C - ATEX/CE Appendix D - IECEx Appendix E - VdS Appendix F - Offshore Appendix G - Additional approvals.

17

REPLACEMENT PARTS

The detector is not designed to be repaired in the field. If a problem should develop, refer to the Troubleshooting section. If it is determined that the problem is caused by an electronic defect, the device must be returned to the factory for repair.

DEVICE REPAIR AND RETURN

Prior to returning devices, contact the nearest local Detector Electronics office so that a Return Material Identification (RMI) number can be assigned. A written statement describing the malfunction must accompany the returned device or component to assist and expedite finding the root cause of the failure.

Pack the unit properly. Always use sufficient packing material. Where applicable, use an antistatic bag as protection from electrostatic discharge.

NOTE

Det-Tronics reserves the right to apply a service charge for repairing returned product damaged as a result of improper packaging.

Return all equipment transportation prepaid to the factory in Minneapolis.

NOTE

It is highly recommended that a complete spare be kept on hand for field replacement to ensure continuous protection.

ORDERING INFORMATION

When ordering, please specify: X3301 IR Flame Detector Refer to the X3301 Model Matrix for details

Q9033 mount is required: Q9033A for aluminum detectors only. Q9033B for aluminum and stainless steel detectors.

X-SERIES FLAME DETECTOR ACCESSORIES

Part Number	Description				
000511-029	Converter RS485 to RS232				
103881-001	Converter RS485 to USB				
007819-001	W6300B1002 Serial Inspector Connector (Inspector Monitor software included)				
007819-002	W6300B1003 USB Inspector Connector (Inspector Monitor software included)				
009207-001	Flame Inspector Monitor CD				
103922-001	Model 475 HART Communicator				
102740-002	Magnet				
008082-001	Magnet and Adapter for Extension Pole				
007739-001	Magnet and Extension Pole				
009208-001	oi Replacement kit for X3301 (5 Black reflector plates) with Inspector Connector and Monitor				
010831-001	oi Replacement kit for X3301 (5 Stainless Steel reflector plates) with Inspector Connector and Monitor				
009208-003	oi Replacement kit for X3302 (5 Black reflector plates) with Inspector Connector and Monitor				
010831-002	oi Replacement kit for X3302 (5 Stainless Steel reflector plates) with Inspector Connector and Monitor				
009208-002	oi Replacement kit for X52/X22/X98 (5 reflector plates) with Inspector Connector and Monitor				
007307-001	Replacement oi reflector plate for X3301 with Black plate (requires inspector connector to calibrate)				
010830-001	Replacement oi reflector plate for X3301 with Stainless Steel plate (requires inspector connector to calibrate)				
007307-003	Replacement of reflector plate for X3302 with Black plate (requires inspector connector to calibrate)				
010830-002	Replacement oi reflector plate for X3302 with Stainless Steel plate (requires inspector connector to calibrate)				
007307-002	Replacement oi reflector plate for X52/X22/X98 (requires inspector connector to calibrate)				
007240-001	Q1116A1001, Air Shield (AL)				
007818-001	Q1118A1001 Aluminum Air Shield/Flange Mount (AL)				
007818-002	Q1118S1001 Stainless Steel Air Snield/Flange Mount (SS)				
0109177-001	QT120A1001 Flance Mount Accomply for V2201 & V2202				
010837-001	O1198A1001 Dual Air Shield/Elange Mount (X9800 only)/(AL)				
006097-001					
102871-001	Laser Battery 3V Lithium (laser)				
007255-001	Q1201C1001 X-Series Laser Holder (AL/Plastic)				
007338-001	Q2000A1001 X-Series Weather Shield (AL)				
007338-010	Q2033A10R X3301/X3302 FOV Limiter 10° (AL)				
007338-020	Q2033A20R X3301/X3302 FOV Limiter 20° (AL)				
007338-030	Q2033A30R X3301/X3302 FOV Limiter 30° (AL)				
007912-010	Spare Restrictor Plate 10° (AL)				
007912-020	Spare Restrictor Plate 20° (AL)				
007912-030	Spare Restrictor Plate 30° (AL)				
007290-001	Q9033B Stainless Steel Swivel Mount Assembly is for aluminum and stainless steel detectors				
007290-002	Q9033A Aluminum Swivel Mount Assembly is for aluminum detectors only				
011385-001	Q9033 Collar Attachment				
101197-001	Stop Plug, 3/4 NPT, AL				
101197-004	Stop Plug, 3/4 NPT, SS				
103517-001	Stop Plug, AL, IP66, Ex d e, M25				
101197-003	Stop Plug, SS, IP66, Ex d e, M25				
010816-001	Stop Plug, 20PK, 3/4NPT, AL				
	Stop Plug, 20PK, 3/4NPT, SS				
	Stop Plug, 20PK, M25, AL				
	Stop Plug, 20PK, M25, SS				
103303-001					
103400-001					
	1 oz grease for detectors (pop silicon)				
001680-001	Window cleaner (6 pack)				

X3301 MODEL MATRIX

MODEL	DESCRIPTION							
X3301	Multispec	Multispectrum IR Flame Detector						
	TYPE	MATERIA	MATERIAL					
	Α	Aluminum)					
	S	Stainless	Stainless Steel (316)					
		TYPE	TYPE THREAD TYPE					
		4M	4 PORT, N	METRIC M2	25			
		4N	4 PORT, 3	3/4" NPT				
			TYPE OUTPUTS					
	11 Relay							
			13 Relay and 4-20 mA					
			14 Eagle Quantum Premier (EQP)			mier (EQP)		
			15 Relay and Pulse					
			16	Addressa	ble Module	e Only (Third Party Type)*		
			21	Relay-Aut	omotive			
			22	EQP Auto	motive			
			23	HART, Re	lay and 4-2	20 mA		
				TYPE	APPROV	ALS		
				Α	FM/CSA			
				Т	SIL/FM/C	SA/ATEX/CE/IECEx		
			W FM/CSA/ULC**/ATEX/CE/IECEx					
					TYPE	CLASSIFICATION		
				1 Division/Zone Ex d e				
					2	Division/Zone Ex d		

*The Addressable Module Only (Type 16) is not FM approved. **ULC approval applies to output types 11, 13, 15, 21, and 23.

APPENDIX A

FM APPROVAL AND PERFORMANCE REPORT

THE FOLLOWING ITEMS, FUNCTIONS AND OPTIONS DESCRIBE THE FM APPROVAL:

- Explosion-proof for Class I, Div. 1, Groups B, C and D (T4A) Hazardous (Classified) Locations per FM 3615.
- Dust-ignition proof for Class II/III, Div. 1, Groups E, F and G (T4A) Hazardous (Classified) Locations per FM 3615.
- Nonincendive for Class I, Div. 2, Groups A, B, C and D (T3C) Hazardous (Classified) Locations per FM 3611.
- Nonincendive for Class II, Div. 2, Groups F and G (T3C) Hazardous (Classified) Locations per FM 3611.
- Enclosure rating NEMA/Type 4X per NEMA 250.
- Ambient Temperature Limits: -40°F to +167°F (-40°C to +75°C).
- Automatic Fire Alarm Signaling Performance verified per FM 3260 (2000).

The following performance criteria were verified:

AUTOMATIC OPTICAL INTEGRITY TEST:

The detector generated an optical fault in the presence of contamination on any single or combination of lens surfaces resulting in a loss of approximately 50% of its detection range, verifying that the detector performs a calibrated Automatic Optical Integrity (**oi**) test for each sensor. Upon removal of the contamination, the detector fault was cleared and the detector was verified to detect a fire.

MANUAL OPTICAL INTEGRITY TEST:

The Manual / Magnetic **oi** performs the same calibrated test as the Automatic **oi**, and additionally actuates the alarm relay to verify output operation. If there is a 50% loss of its detection range, an alarm signal is not generated.

The Optical Integrity test procedure, as described in the "Magnetic **oi** / Manual **oi**" section of this instruction manual, is the approved external optical test method for this detector to verify end-to-end detector function. This test replaces the function and need of a traditional external test lamp.

RESPONSE CHARACTERISTICS

Very High Sensitivity

Fuel	Size	Distance feet (m)	Average Response Time (seconds)***
n-Heptane	1 x 1 foot	210 (64)*	11
n-Heptane**	1 x 1 foot	210 (64)*	6
n-Heptane	1 x 1 foot	100 (30.5)	3
n-Heptane	6 in. x 6 in.	80 (24.4)	3
Isopropanol	6 in. x 6 in.	70 (21.3)	4
Diesel**	1 x 1 foot	150 (45.7)*	14
Ethanol	1 x 1 foot	210 (64)	11
Methanol	6 in. x 6 in.	40 (12.2)	3
Methanol	1 x 1 foot	150 (45.7)*	18
Methanol**	1 x 1 foot	150 (45.7)*	7
Methane	30 inch plume	100 (30.5)	3
JP-5**	1 x 1 foot	150 (45.7)*	2
JP-5**	2 x 2 feet	210 (64)*	4
JP-5**	2 x 2 feet	100 (30.5)	2
Office Paper 0.5 lb.	19" x 19" x 8"	100 (30.5)	4
Corrugated Panel	18" x 36"	100 (30.5)	8

* Outdoor test condition.

** Pre-burn from ignition.

*** Add 2 seconds for EQP Model.

Medium Sensitivity

Fuel	Size	Distance feet (m)	Average Response Time (seconds)***
n-Heptane	1 x 1 foot	100 (30.5)	12
n-Heptane	1 x 1 foot	50 (15.2)	2
Diesel**	1 x 1 foot	70 (21.3)	4
Ethanol	1 x 1 foot	85 (25.9)	13
Methanol	1 x 1 foot	70 (21.3)	10
Methane	30 inch plume	65 (19.8)	3
Methane	30 inch plume	55 (16.8)	2
JP-5**	2 x 2 feet	100 (30.5)	3
Office Paper 0.5 lb.	19" x 19" x 8"	50 (15.2)	6
Corrugated Panel	18" x 36"	50 (15.2)	2

** Pre-burn from ignition.*** Add 2 seconds for EQP Model.

Low Sensitivity

Fuel	Size	Distance feet (m)	Average Response Time (seconds)***
n-Heptane	1 x 1 foot	50 (15.2)	10
Methanol	1 x 1 foot	20 (6.1)	10
Methane	32 inch plume	15 (4.6)	9

*** Add 2 seconds for EQP Model.

RESPONSE CHARACTERISTICS IN THE PRESENCE OF FALSE ALARM SOURCES

Very High Sensitivity

False Alarm Source	Distance feet (m)	Fire Source	Distance feet (m)	Average Response Time (seconds)***
Sunlight, direct, modulated, reflected	—	6-inch propane	6 (1.8)	< 10
Vibration	N/A	3-inch propane	10.5 (3.2)	< 10
Radio frequency interference	1 (0.3)	3-inch propane	12 (3.7)	< 10
Arc welding, #7014	40 (12.2)	1 x 1 foot n-Heptane	40 (12.2)	4
6 kw heater, modulated	80 (24.4)	1 x 1 foot n-Heptane	80 (24.4)	2
6 kw heater, unmodulated	10 (3)	1 x 1 foot n-Heptane	80 (24.4)	3
250 w vapor lamp, modulated	3 (0.9)	1 x 1 foot n-Heptane	80 (24.4)	2
300 w incandescent lamp, modulated	3 (0.9)	1 x 1 foot n-Heptane	80 (24.4)	7
500 w shielded quartz halogen lamp, modulated	8 (2.4)	1 x 1 foot n-Heptane	80 (24.4)	2
500 w unshielded quartz halogen lamp, modulated	8 (2.4)	1 x 1 foot n-Heptane	80 (24.4)	3
1500 w electric radiant heater, modulated	10 (3)	1 x 1 foot n-Heptane	80 (24.4)	5
Two 34 w fluorescent lamps, modulated	3 (0.9)	1 x 1 foot n-Heptane	80 (24.4)	3

*** Add 2 seconds for EQP Model.

Medium Sensitivity

False Alarm Source	Distance feet (m)	Fire Source	Distance feet (m)	Average Response Time (seconds)***
Sunlight, direct, modulated, reflected	—	6-inch propane	6 (1.8)	< 4
Vibration*	N/A	N/A	N/A	N/A
Radio frequency interference	1 (0.3)	6-inch propane	6 (1.8)	< 1
Arc welding, #7014	10 (3)	1 x 1 foot n-Heptane	40 (12.2)	4
6 kw heater, modulated	60 (18.3)	1 x 1 foot n-Heptane	60 (18.3)	2
6 kw heater, unmodulated	10 (3)	1 x 1 foot n-Heptane	60 (18.3)	2
250 w vapor lamp, modulated	3 (0.9)	1 x 1 foot n-Heptane	60 (18.3)	1
300 w incandescent lamp, modulated	3 (0.9)	1 x 1 foot n-Heptane	60 (18.3)	1
500 w shielded quartz halogen lamp, modulated	8 (2.4)	1 x 1 foot n-Heptane	60 (18.3)	1
500 w unshielded quartz halogen lamp, modulated	8 (2.4)	1 x 1 foot n-Heptane	60 (18.3)	1
1500 w electric radiant heater, modulated	10 (3)	1 x 1 foot n-Heptane	60 (18.3)	6
Two 34 w fluorescent lamps, modulated	3 (0.9)	1 x 1 foot n-Heptane	60 (18.3)	2

Fire was verified with very high sensitivity only.
 *** Add 2 seconds for EQP Model.

FM Approval and Performance Report – Continued

Low Sensitivity

False Alarm Source	Distance feet (m)	Fire Source	Distance feet (m)	Average Response Time (seconds)***
Sunlight, direct, unmodulated, reflected*	_	1 x 1 foot n-Heptane	35 (10.7)	< 13
Sunlight, direct, modulated, reflected*	—	1 x 1 foot n-Heptane	15 (4.6)	< 14
Arc welding, steady, #7014	5 (1.5)	1 x 1 foot n-Heptane	50 (15.2)	11
Arc welding, modulated, #7014	5 (1.5)	1 x 1 foot n-Heptane	30 (9.1)	10
70 w sodium vapor, modulated	3 (0.9)	1 x 1 foot n-Heptane	50 (15.2)	16
250 w vapor lamp, modulated	3 (0.9)	1 x 1 foot n-Heptane	50 (15.2)	18
300 w incandescent lamp, modulated	3 (0.9)	1 x 1 foot n-Heptane	50 (15.2)	18
500 w shielded quartz halogen lamp, unmodulated	3 (0.9)	1 x 1 foot n-Heptane	50 (15.2)	12
500 w shielded quartz halogen lamp, modulated	10 (3)	1 x 1 foot n-Heptane	50 (15.2)	11
1500 w electric radiant heater, unmodulated	3 (0.9)	1 x 1 foot n-Heptane	50 (15.2)	12
1500 w electric radiant heater, modulated	10 (3)	1 x 1 foot n-Heptane	30 (9.1)	11
Two 34 w fluorescent lamps, modulated	3 (0.9)	1 x 1 foot n-Heptane	50 (15.2)	14

* Outdoor test conditions. *** Add 2 seconds for EQP Model.

FALSE ALARM IMMUNITY

Very High Sensitivity

False Alarm Source	Distance feet (m)	Modulated Response	Unmodulated Response
Sunlight, direct, reflected	_	No alarm	No alarm
Vibration	N/A	No alarm	N/A
Radio frequency interference	1 (0.3)	No alarm (keyed)	No alarm (steady)
Arc welding	40 (12.2)	No alarm	No alarm
6 kw heater	3 (0.9)	No alarm	No alarm
250 w vapor lamp	3 (0.9)	No alarm	No alarm
300 w incandescent lamp	3 (0.9)	No alarm	No alarm
500 w unshielded quartz halogen lamp	8 (2.4)	No alarm	No alarm
500 w shielded quartz halogen lamp	8 (2.4)	No alarm	No alarm
1500 w electric radiant heater	3 (0.9)	No alarm	No alarm
Two 34 w fluorescent lamps	3 (0.9)	No alarm	No alarm

Medium Sensitivity

False Alarm Source	Distance feet (m)	Modulated Response	Unmodulated Response
Sunlight, direct, reflected	—	No alarm	No alarm
Vibration	N/A	No alarm	N/A
Radio frequency interference	1 (0.3)	No alarm (keyed)	No alarm (steady)
Arc welding	10 (3)	No alarm	No alarm
6 kw heater	3 (0.9)	No alarm	No alarm
250 w vapor lamp	3 (0.9)	No alarm	No alarm
300 w incandescent lamp	3 (0.9)	No alarm	No alarm
500 w unshielded quartz halogen lamp	8 (2.4)	No alarm	No alarm
500 w shielded quartz halogen lamp	3 (0.9)	No alarm	No alarm
1500 w electric radiant heater	3 (0.9)	No alarm	No alarm
Two 34 w fluorescent lamps	3 (0.9)	No alarm	No alarm

Low Sensitivity

False Alarm Source	Distance feet (m)	Modulated Response	Unmodulated Response
Sunlight, direct, reflected	—	No alarm	No alarm
Vibration	—	No alarm	No alarm
Radio frequency interference	N/A	No alarm	N/A
Arc welding	5 (1.5)	No alarm	No alarm
6 kw heater	3 (0.9)	No alarm	No alarm
250 w vapor lamp	3 (0.9)	No alarm	No alarm
300 w incandescent lamp	3 (0.9)	No alarm	No alarm
500 w shielded quartz halogen lamp	3 (0.9)	No alarm	No alarm
1500 w electric radiant heater	3 (0.9)	No alarm	No alarm
Two 34 w fluorescent lamps	3 (0.9)	No alarm	No alarm

FIELD OF VIEW

Very High Sensitivity

Fuel	Size	Distance feet (m)	Horizontal (degrees)	Avg. Horiz. Response Time (seconds)***	Vertical (degrees)	Avg. Vert. Response Time (seconds)***
n-Heptane	1 x 1 foot	150* (45.7)	+45 -45	12 14	+45 -30	13 5
n-Heptane	1 x 1 foot	100 (30.5)	+45 -45	6 3	+45 -30	3 2
n-Heptane	6 in. x 6 in.	80 (24.4)	+45 -45	5 6	+45 -30	4 4
Isopropanol	6 in. x 6 in.	70 (21.3)	+45 -45	5 5	+45 -30	4 6
Diesel**	1 x 1 foot	100 (30.5)	+45 -45	2 3	+45 -30	4 3
Ethanol	1 x 1 foot	150 (45.7)	+45 -45	13 10	+45 -30	10 8
Methanol	6 in. x 6 in.	40 (12.2)	+45 -45	4 6	+45 -30	3 3
Methanol	1 x 1 foot	110 (33.5)	+45 -45	9 7	+45 -30	9 3
Methane	30 inch plume	100 (30.5)	+45 -45	7 3	+45 -30	2 2
JP-5**	1 x 1 foot	100 (30.5)	+45 -45	2 4	+45 -30	3 2
JP-5**	2 x 2 feet	180* (54.9)	+45 -45	2 5	+45 -30	3 2
JP-5**	2 x 2 feet	90 (27.4)	+45 -45	2 3	+45 -30	1 2
Office Paper 0.5 lb.	19" x 19" x 8"	80 (24.4)	+45 -45	4 2	+45 -30	2 1
Corrugated Panel	18" x 36"	80 (24.4)	+45 -45	1	+45 -30	3 2

Outdoor test condition.
 Pre-burn from ignition.
 *** Add 2 seconds for EQP Model.

Medium Sensitivity

Fuel	Size	Distance feet (m)	Horizontal (degrees)	Avg. Horiz. Response Time (seconds)***	Vertical (degrees)	Avg. Vert. Response Time (seconds)***
n-Heptane	1 x 1 foot	75 (22.9)	+45 -45	9 6	+45 -30	10 7
n-Heptane	1 x 1 foot	50 (15.2)	+45 -45	4 3	+45 -30	3 3
Diesel**	1 x 1 foot	60 (18.3)	+45 -45	4 4	+45 -30	4 2
Ethanol	1 x 1 foot	60 (18.2)	+45 -45	12 9	+45 -30	12 9
Methanol	1 x 1 foot	50 (15.2)	+45 -45	9 3	+45 -30	9 1
Methane	32 inch plume	45 (13.7)	+45 -45	3 3	+45 -30	7 1
JP-5**	2 x 2 feet	90 (27.4)	+45 -45	4 2	+45 -30	2 2
Office Paper 0.5 lb.	19" x 19" x 8"	40 (12.2)	+45 -45	2 1	+45 -30	1
Corrugated Panel	18" x 36"	40 (12.2)	+45 -45	2 1	+45 -30	1 1

** Pre-burn from ignition. *** Add 2 seconds for EQP Model.

Low Sensitivity

Fuel	Size	Distance feet (m)	Horizontal (degrees)	Avg. Horiz. Response Time (seconds)***	Vertical (degrees)	Avg. Vert. Response Time (seconds)***
n-Heptane	1 x 1 foot	35 (10.7)	+45 -45	13 13	+45 -30	9 18
Methanol	1 x 1 foot	15 (4.6)	+45 -45	14 12	+45 -30	10 8
Methane	32 inch plume	15 (4.6)	+45 -45	10 11	+45 -30	8 10

*** Add 2 seconds for EQP Model.



HIGH RESOLUTION FIELD OF VIEW

Field of View at Indicated Distance in Feet for **n-Heptane** at Very High Sensitivity (1 x 1 foot)









Field of View at Indicated Distance in Feet for **Isopropanol** at **Very High** Sensitivity (6 in. x 6 in.)



Field of View at Indicated Distance in Feet for **Diesel** at **Very High** Sensitivity (1 x 1 foot)



Field of View at Indicated Distance in Feet for Ethanol at Very High Sensitivity (1 x 1 foot)



Field of View at Indicated Distance in Feet for **Methanol** at **Very High** Sensitivity (6 in. x 6 in.)





Field of View at Indicated Distance in Feet for **JP-5** at **Very High** Sensitivity (2 x 2 feet)

FM Approval and Performance Report – Continued



Field of View at Indicated Distance in Feet for **n-Heptane** at **Medium** Sensitivity (1 x 1 foot)



Field of View at Indicated Distance in Feet for **Diesel** at **Medium** Sensitivity (1 x 1 foot)



Field of View at Indicated Distance in Feet for Ethanol at Medium Sensitivity (1 x 1 foot)



Field of View at Indicated Distance in Feet for **Methanol** at **Medium** Sensitivity (1 x 1 foot)



Field of View at Indicated Distance in Feet for **Methane** at **Medium** Sensitivity (30 inch plume)



Field of View at Indicated Distance in Feet for JP-5 at Medium Sensitivity (2 x 2 foot)

NOTE

FM Approvals minimum requirements are response distance measurements at 0° (on axis) and the limits of the field of view. These high resolution field of view diagrams show the measured response distances at all the indicated angles in the horizontal plane.

APPENDIX B

CSA APPROVAL

PRODUCTS

CLASS 4818 04 - SIGNAL APPLIANCES - Systems - For Hazardous Locations Class I, Division 1, Groups B, C, and D (T4A); Class II, Division 1, Groups E, F, and G (T4A); Class I, Division 2, Groups A, B, C, and D (T3C); Class II, Division 2, Groups F and G (T3C); Class III; Enclosure Type 4X;

Multispectrum IR Flame Detector/Controller X3301 Series, rated 18-30 Vdc, 4.6 Watts to 17 Watts. Relay contacts rated 30 Vdc, 5 Amps.

NOTE

Hazardous location testing has been successfully completed on the Model X3301 series from an ambient temperature range of –55°C to +125°C; however, the detector label marking indicates –40°C to +75°C.

APPLICABLE REQUIREMENTS

CSA Std C22.2 No. 25-1966 - Enclosures for use in Class II Groups E, F & G Hazardous Locations.
CSA Std C22.2 No. 30-M1986 - Explosion-Proof Enclosures for use in Class I Hazardous Locations.
CAN/CSA C22.2 No. 94-M91 - Special Purpose Enclosures.
CSA Std C22.2 No. 142-M1987 - Process Control Equipment.
CSA Std C22.2 No. 213-M1987 - Nonincendive Electrical Equipment for use in Class I, Division 2 Hazardous Locations.

APPENDIX C

ATEX / CE APPROVAL

EC-TYPE EXAMINATION CERTIFICATE

DEMKO 01 ATEX 130204X

Increased Safety Model

Flameproof Model € 0539 € II 2 G II 2 D Ex d IIC T4-T6 Gb Ex tb IIIC T130°C T6 (Tamb -55°C to +60°C) T5 (Tamb -55°C to +75°C) T4 (Tamb -55°C to +125°C) IP66/IP67.

Compliance with:

EN 60079-0: 2009 EN 60079-1: 2007 EN 60079-7: 2007 EN 60079-31: 2009 EN / IEC 60529: 2001.

INSTALLATION INSTRUCTIONS

The field wiring connections in the terminal compartment are ATEX certified and accepts wiring diameter from 14 AWG (2.08 mm²) to 22 AWG (0.33 mm²).

The Multispectrum infrared (IR) flame detector type X3301 shall be installed according to the instructions given by the manufacturer.

The cable entry devices shall be certified in type of explosion protection flameproof enclosure "d" for use with the terminal compartment in type of explosion protection flameproof enclosure "d", or in type of explosion protection increased safety "e" for use with the terminal compartment in type of explosion protection increased safety "e". They shall be IP66/IP67 rated, suitable for the conditions of use and correctly installed.

Unused entries shall be closed with suitable certified blanking elements.

The metal housing for the Multispectrum infrared (IR) flame detector type X3301 must be electrically connected to earth ground.

For ambient temperatures below -10°C and above +60°C use field wiring suitable for both minimum and maximum ambient temperature.

Special conditions for safe use:

The front window assembly contains a special cemented joint construction. In accordance with EN60079-1 clause 5.1.c, all inspections, repair and/or adjustments to this front window assembly shall be done by Detector Electronics Corporation only.

The EOL resistor can only be used within the flameproof terminal compartment.

EOL resistors must be ceramic, wirewound type, rated 5 watts minimum, with actual power dissipation not to exceed 2.5 watts.

The Multispectrum infrared (IR) flame detector type X3301 is to be installed in places where there is a low risk of mechanical damage.

NOTE

Operational performance verified from -40°C to +75°C.

NOTE

An optional third party addressable module can only be used within the Ex d flameproof model unless the addressable module is component certified as Ex e for use within the Ex d e increased safety model.

NOTE

Refer to "EOL Resistors" section for installation details. All cable entry devices and blanking elements shall be certified to "E-generation" or "ATEX" standards, in type of explosion protection increased safety "e" or flameproof enclosure "d" (as applicable), suitable for the conditions of use and correctly installed. They shall maintain the degree of ingress protection IP66 for the apparatus. Unused apertures shall be closed with suitable blanking elements.

NOTE

For ATEX installations, the X3301 detector housing must be electrically connected to earth ground.

APPENDIX D

IECEx APPROVAL

IECEX CERTIFICATE OF CONFORMITY

DEMKO

IECEx ULD 06.0017X

Ex d e IIC T5-T6 Gb Ex tb IIIC T130°C T6 (Tamb =-50°C to +60°C) or T5 (Tamb =-50°C to +75°C) IP66/IP67. Ex d IIC T4-T6 Gb Ex tb IIIC T130°C T6 (Tamb =-55°C to +60°C) T5 (Tamb =-55°C to +75°C) T4 (Tamb =-55°C to +125°C) IP66/IP67.

Compliance with:

IEC 60079-0: 2007, Ed. 5 IEC 60079-1: 2007, Ed. 6 IEC 60079-7: 2006, Ed. 4 IEC 60079-31: 2008, Ed. 1 EN/IEC 60529: 2001.

INSTALLATION INSTRUCTIONS

The field wiring connections in the terminal compartment are suitably certified and accepts wiring diameter from 14 AWG (2.08 mm²) to 22 AWG (0.33 mm²).

The Multispectrum infrared (IR) flame detector type X3301 shall be installed according to the instructions given by the manufacturer.

The cable entry devices shall be certified in type of explosion protection flameproof enclosure "d" for use with the terminal compartment in type of explosion protection flameproof enclosure "d" or in type of explosion protection increased safety "e" for use with the terminal compartment in type of explosion protection increased safety "e". They shall be IP66/IP67 rated, suitable for the conditions of use and correctly installed.

Unused entries shall be closed with suitable certified blanking elements.

The metal housing for the Multispectrum infrared (IR) flame detector type X3301 must be electrically connected to earth ground.

For ambient temperatures below –10°C and above +60°C use field wiring suitable for both minimum and maximum ambient temperature.

Special conditions for safe use:

The front window assembly contains a special cemented joint construction. In accordance with IEC 60079-1 clause 5.1.c, all inspections, repair and/or adjustments to this front window assembly shall be done by Detector Electronics Corporation only.

The EOL resistor can only be used within the flameproof terminal compartment.

EOL resistors must be ceramic, wirewound type, rated 5 watts minimum, with actual power dissipation not to exceed 2.5 watts.

The Multispectrum infrared (IR) flame detector type X3301 is to be installed in places where there is a low risk of mechanical damage.

APPENDIX E

VdS Schadenverhütung GmbH APPROVAL



Performance per EN54-10, Certificate of Approval G-202136.

EC-Certificate of Conformity 08 0786 – CPD – 20453 EN54-10 Flame detectors - Point detectors.

SUBJECT MATTER OF THE APPROVAL

IR Flame Detector Type X3301 for use in Automatic Fire Detection and Fire Alarm Systems.

BASIS OF APPROVAL

DIN EN 54, Part 10 (05/02) - Flame Detectors.

INSTRUCTIONS FOR THE APPLICATION OF THE APPROVAL COMPONENT/SYSTEM

The installation shall take into account, that the orientation arrow on the flame detector is directed upwards, as the view angle in this direction is <90°.

The IR-flame detector corresponds to class 1.

APPENDIX F

OFFSHORE APPROVALS

DNV

Type Approval Certificate No. A-11022.

SUBJECT MATTER OF THE APPROVAL

IR Flame Detector Type X3301 for use in Ships, High Speed & Light Craft, and Offshore Applications.

Application Location Classes:

Location classes for X3301 IR Flame Detector with Mounting Bracket Q9033B / Q9033A (Shaded areas indicate Det-Tronics approved location classes)

	COLUMN 1	COLUMN 2						
	LOCATION WITHIN MAIN AREA		MAIN AREAS ON BOARD					
TYPE			Control room, Accommodation	Bridge	Pump room, Holds, Rooms with no heating	Open Deck		
Temperature	Inside cubicles, desks, etc. with temperature rise of 5°C or more	В	В	В	D	D		
lemperature	All other locations	A	A	А	С	D		
Locations where special precautions are taken to avoid Humidity		А	А	А	А	А		
	All other locations	В	В	В	В	В		
	On machinery such as internal combustion engines, compressors, pumps, including piping on such machinery	В	—	_	В	в		
Vibration	Masts	_	—	—	—	_		
	All other locations	A	A	А	A	A		
EMC (Electro- magnetic compatibility	All locations within specified main areas	А	А	в	A	в		
	Submerged application	D	—	_	D	D		
Enclosure	Below floor plates in engine room	С	—	_	—	_		
	All other locations	В	A	A	В	C		

MED

Certificate No. MED-B-5872.

Is found to comply with the requirements in the following Regulations / Standards: Annex A.1, item No. A.1/3.51 and Annex B, Module B in the Directive. SOLAS 74 as amended, Regulation II-2/7 & X/3, 2000 HSC Code 7, FSS Code 9 and IMO MSC.1/Circ. 1242.

The equipment are found to comply with following location / application dependent requirements (for definition of each of the location classes, see below the table):

MODEL	TEMPERATURE	VIBRATION	EMC	ENCLOSURE
X3301	TEM-D	VIB-B	EMC-B	ENC-C

Definition of the location classes with reference to relevant standards:

Temperature

TEM-D Location (-25°C-70°C) (ref. IEC 60092-504 (2001) table 1 item 6-7)

Vibration

VIB-D For eq. on reciprocating machines etc. (ref IEC 60092-504 (2001) table 1 item 10)

EMC

EMC-B Bridge and open deck zone (ref. IEC 60092-504 (2001) table 1 item 19-20)

Enclosure

ENC-C Open deck (IP56) (ref. IEC 60092-201 table 5)

Conformity to Module D, E and F.

Lloyd's Register

Type Approval Certificate No. 09/00027.

Models Available: Relay output, relay 0-20 mA output, and EQP LON output versions.

APPENDIX G

ADDITIONAL APPROVALS

SIL 2



IEC 61508

Certified SIL 2 Capable. Certificate DET070417 COO1 Applies to specific models – refer to the SIL 2 Certified X3301 Safety Manual (95-8582) for details.

FRENCH



NF-SSI AFNOR Identification No: LIR 007 A0. www.marque-nf.com

APPENDIX H

APPROVED ACCESSORIES



Q9033A/B MOUNTING ARM (for use with FM/CSA/ATEX/CE/IECEx/DNV certified X-Series Detectors)

The Q9033A (Aluminum) and the Q9033B (Stainless Steel) Mounting Arms are designed for all Det-Tronics X-Series flame detectors. They allow for mounting to walls or immovable objects, enabling the detector to be installed in virtually any location. For additional information, refer to instruction manual 95-8686.



Q9033 COLLAR ATTACHMENT (for use with FM/CSA/ATEX/CE/IECEx certified X-Series Detectors)

The Q9033 Collar Attachment is designed for all Det-Tronics X-Series flame detectors and is used in conjunction with the Q9033A/B Mounting Arm. The Collar Attachment adds versatility to the mounted detector by allowing a wider (3-dimensional) range of motion and improved viewing angles. For additional information, refer to instruction manual 95-8686.



Q1130 FLANGE MOUNT ASSEMBLY (for use with FM/CSA/ATEX/CE/IECEx certified X3301 and X3302 Detectors)

The Q1130 Flange Mount Assembly is designed specifically for Det-Tronics X3301 and X3302 Flame Detectors, and allows the detector to be mounted directly to a wall or panel in order to monitor an enclosed process or geodome tank. For additional information, refer to instruction manual 95-8662.





X3301 Multispectrum IR Flame Detector



PointWatch Eclipse® IR Combustible Gas Detector



FlexVu® Universal Display w/ GT3000 Toxic Gas Detector



Eagle Quantum Premier® Safety System

Detector Electronics Corporation 6901 West 110th Street Minneapolis, MN 55438 USA

T: 952.941.5665 or 800.765.3473 F: 952.829.8750 W: http://www.det-tronics.com E: det-tronics@det-tronics.com



Det-Tronics, the DET-TRONICS logo, Protect•IR, and Automatic Optical Integrity (•i) are registered trademarks or trademarks of Detector Electronics Corporation in the United States, other countries, or both. Other company, product, or service names may be trademarks or service marks of others.